YRC1000/YRC1000micro INSTRUCTIONS FOR Smart Pendant

(JZRCR-APP30-1)

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

MOTOMAN INSTRUCTIONS

YRC1000 INSTRUCTIONS YRC1000 OPERATOR'S MANUAL (GENERAL) (SUBJECT SPECIFIC) YRC1000 MAINTENANCE MANUAL YRC1000 ALARM CODES (MAJOR ALARMS) (MINOR ALARMS)

YRC1000micro INSTRUCTIONS YRC1000micro OPERATOR'S MANUAL YRC1000micro MAINTENANCE MANUAL YRC1000micro ALARM CODES (MAJOR ALARMS) (MINOR ALARMS)

YRC1000/YRC1000micro INSTRUCTIONS FOR Smart Pendant (JZRCR-APP30-1)

Have the following information available when contacting the YASKAWA Representative:

- System
- Primary Application
- Software Version (Located on Programming Pendant by selecting: {Main Menu} - {System Info} - {Version})
- Warranty ID (Located on Robot Controller)
- Robot Serial Number (Located on Manipulator data plate)
- Robot Sales Order Number (Located on Robot controller data plate)

Jse for urgent or emergency needs for technical support, service and/or replacement parts 24-hour Telephone Number: (937) 847-3200

Routine Technical Inquiries: techsupport@motoman.com

Allow up to 36 hours for response

Part Number: 184775-1CD Revision: 5 MANUAL NO. HW1485509 \$

This instruction manual is applicable to both YRC1000 and YRC1000micro.



The description of "YRC Controller" refers to both"YRC1000" and "YRC1000micro", and the descriptions of "the INSTRUCTIONS of the YRC Controller" refers to both "YRC1000 INSTRUCTIONS (RE-CTO-A221)" and "YRC1000micro INSTRUCTIONS (RE-CTO-A222)" in this manual unless otherwise specified.



- This manual describes the various components of the Smart Pendant the teaching device of the YRC Controller. Read this manual carefully and be sure to understand its contents before handling the YRC Controller. Any matter not described in this manual, including operation, usage, measures, and an item to use, must be regarded as "prohibited" or "improper".
- General information related to safety is described in "chapter 1. Safety" of the YRC CONTROLLER INSTRUCTIONS.



- In some drawings in this manual, protective covers or shields are removed to show details. Make sure that all the covers or shields are installed in place before operating this product.
- YASKAWA is not responsible for incidents arising from unauthorized modification of its products. Unauthorized modification voids the product warranty.

NOTICE

- The drawings and photos in this manual are representative examples and differences may exist between them and the delivered product.
- YASKAWA may modify this model without notice when necessary due to product improvements, modifications, or changes in specifications. If such modification is made, the revision number next to the manual number will also be revised.
- If your copy of the manual is damaged or lost, contact a YASKAWA Representative to order a new copy. Representatives are listed on the back cover. Be sure to tell the representative the manual number listed on the front cover.

Notes for Safe Operation

Read this manual carefully before installation, operation, maintenance, or inspection of the YRC Controller.

In this manual, the Notes for Safe Operation are classified as "DANGER", "WARNING", "CAUTION", or "NOTICE".



Indicates an imminently hazardous situation which, if not avoided, may result in death or serious injury.

Indicates a potentially hazardous situation which, if not avoided, may result in death or serious injury.

Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury. It may also be used without the safety alert symbol as an alternative to "NOTICE".

NOTICE

"NOTICE" is the preferred signal word to address practices not related to personal injury. The safety alert symbol should not be used with this signal word. As an alternative to "NOTICE", the word "CAUTION" may be used without the safety alert symbol to indicate a message not related to personal injury.

Even items described with the word "CAUTION" may result in a serious accident in some situations.

Be sure to follow the important guidelines below.

iii



To ensure safe and efficient operation at all times, be sure to follow all instructions, even those not designated as "DANGER", "WARNING" and "CAUTION".

<YRC1000>



- Before operating the manipulator, make sure the servo power is turned OFF by performing the following operations. When the servo power is turned OFF, the SERVO ON LED on the Smart Pendant is turned OFF.
 - Press the Emergency Stop buttons on the front door of the YRC1000 (some models do not have this button), on the top of the Smart Pendant, on the external control device, etc.
 - Disconnect the safety plug of the safety fence, if in the play mode or in the REMOTE mode

If the manipulator cannot be stopped in an emergency, personal injury and/or equipment damage may result.

Fig. : Emergency Stop Button



Before releasing the Emergency Stop Button, make sure to remove any obstacle or error caused the emergency stop and then turn the servo power ON.

Failure to observe this instruction may cause unintended movement of the manipulator, which may result in personal injury.

Fig. : Release of Emergency Stop Button




- Observe the following precautions when performing a teaching operation within the manipulator's operating range:
 - Be sure to perform lockout by putting a lockout device on the safety fence when going into the area enclosed by the safety fence. In addition, the operator of the teaching operation must display a sign indicating that an operation is being performed so that no other person closes the safety fence.
 - View the manipulator from the front whenever possible.
 - Always follow the predetermined operating procedure.
 - Always keep emergency response measures against unexpected movement from the manipulator's unexpected movement in mind.
 - Ensure a safe place to retreat to in case of emergency.

Failure to observe this instruction may cause improper or unintended movement of the manipulator, which may result in personal injury.

- Confirm that no person is present in the manipulator's operating range and that the operator is in a safe location before:
 - Turning ON the YRC1000 power
 - Moving the manipulator by using the Smart Pendant
 - Running the system in the check mode
 - Performing automatic operations

Personal injury may result if a person enters the manipulator's operating range during operation. Immediately press the Emergency Stop button whenever there is a problem. The Emergency Stop buttons are located on the front panel of the YRC1000 (some models do not have this button) and on the top of the Smart Pendant.

<YRC1000micro>



Personal injury may result if a person enters the manipulator's operating range during operation. Immediately press the Emergency Stop button whenever there is a problem. The Emergency Stop button is located on the top of the Smart Pendant.

v

<YRC1000micro only>



- In the case of not using the Smart Pendant, be sure to supply a Emergency Stop button on the equipment. Then before operating the manipulator, check to be sure that the servo power is turned OFF by pressing the Emergency Stop button.
- Upon shipment of the YRC1000micro, this signal is connected by a jumper cable in the safety signal short circuit connector. To use this signal, make sure to supply a new connector, and then input it.

If the signal is input with the jumper cable connected, it does not function, which may result in personal injury or equipment damage.

<YRC1000/YRC1000micro>

vi

WARNING Perform the following inspection procedures prior to conducting manipulator teaching. If there is any problem, immediately take necessary steps to solve it, such as maintenance and repair. - Check for a problem in manipulator movement. Check for damage to insulation and sheathing of external wires. Always return the Smart Pendant to a safe place after use. If the Smart Pendant is left unattended on the manipulator, on a fixture, or on the floor, etc., the Enable Switch may be activated due to surface irregularities of where it is left, and the servo power may be turned ON. In addition, in case the operation of the manipulator starts, the manipulator or the tool may hit the Smart Pendant left unattended, which may result in personal injury and/or equipment damage. Make sure that a system administrator stores the key of the Mode Switch of the Smart Pendant. After operation is completed, the key must be removed and stored by the system administrator. Failure to observe this instruction may result in personal injury due to inappropriate or unintended manipulator's operation. If the Smart Pendant is dropped with the key inserted, the key or the Mode Switch may be damaged.

General Safety on the Smart Pendant



Do not connect the Smart Pendant to except for the YRC Controller.

vii

Definition of Terms Used Often in This Manual

<YRC1000>

The MOTOMAN is the YASKAWA industrial robot product.

The MOTOMAN Robot usually consists of the manipulator, the YRC1000 Controller, the Smart Pendant, and the manipulator cables.

In this manual, the equipment is designated as follows:

| Equipment | Manual Designation |
|--|--------------------|
| YRC1000 Controller | YRC1000 Controller |
| YRC1000 Smart Pendant | Smart Pendant |
| Cable between the manipulator and the YRC Controller | Manipulator cable |

<YRC1000micro>

The MOTOMAN is the YASKAWA industrial robot product.

The MOTOMAN Robot usually consists of the manipulator, the YRC1000micro Controller, the Smart Pendant, manipulator cables, and the YRC1000micro Smart Pendant safety signal short circuit connector. (optional).

In this manual, the equipment is designated as follows:

| Equipment | Manual Designation |
|--|--|
| YRC1000micro Controller | YRC1000micro Controller |
| YRC1000micro Smart Pendant | Smart Pendant |
| Cable between the manipulator and the YRC Controller | Manipulator cable |
| YRC1000micro Smart Pendant safety signal short circuit connector | Smart Pendant safety signal short circuit connector (optional) |

Descriptions of the Smart Pendant, buttons, and displays are shown as follows:

| <yrc1000< th=""><th>/YRC10</th><th>00micro></th></yrc1000<> | /YRC10 | 00micro> |
|--|--------|----------|
|--|--------|----------|

| Equipme | nt | Manual Designation | |
|------------------|--|---|--|
| Smart Pendant | Membrane Key | The membrane keys are denoted with []. ex. [JOG MODE] | |
| | Jog Keys | "Jog Keys" is generic names for the keys for jog operation. | |
| | Keys pressed simultaneously (for membrane key only) | When two keys are to be pressed simultaneously, the keys are shown with a "+" sign between them, ex. [S+] + [L+]. | |
| | Displays | The buttons and items displayed in the Smart Pendant is denoted with { }. ex. {Save} | |

Description of the Operation Procedure

<YRC1000/YRC1000micro>

In the explanation of the operation procedure, the expression "Select . . . "

means that the item is directly selected by touching the screen.

Registered Trademark

<YRC1000/YRC1000micro>

ix

In this manual, names of companies, corporations, or products are trademarks, registered trademarks, or brand names for each company or corporation. The indications of (R) and TM symbols are omitted.

Table of Contents

| 1 | Smart F | endant | | |
|---|---------|-----------------|---|------|
| | 1.1 | General Produc | t Description | 1-1 |
| | 1.2 | Smart Pendant | Contents Confirmation | 1-1 |
| | 1.3 | Smart Pendant | Specification | 1-2 |
| | 1.4 | Smart Pendant | Overview | 1-3 |
| | 1.5 | Connection of t | he Smart Pendant | 1-4 |
| | | 1.5.1 Connec | ting to the YRC Controller | 1-4 |
| | | 1.5.2 Connec | cting to the YRC1000micro | 1-5 |
| | 1.6 | Holding the Sm | art Pendant | 1-6 |
| | 1.7 | Display and Op | erating Elements | 1-7 |
| | | 1.7.1 Status | LED | 1-7 |
| | | 1.7.2 Key De | scription on Membrane Keypads | 1-7 |
| | | 1.7.3 Enable | Switch | 1-9 |
| | | 1.7.4 Mode S | Switch | 1-10 |
| | | 1.7.5 Touch | Screen | 1-10 |
| | | 1.7.6 Emerge | ency Stop Button | 1-10 |
| | | • | ency Stop Output | |
| | | | Emergency Stop Output for YRC1000 Emergency Stop Output for YRC1000micro | |
| | 1.8 | | Display | |
| | 110 | | /out | |
| | | • | uration Layout | |
| | | Ū. | formation | |
| | 1.9 | | 1 | |
| | 1.10 | Home Screen | | |
| | 1.11 | Main Menu | | |
| | 1.12 | | | |
| | | | ut Operation | |
| | | | cter Input | |
| | | | numeric Input | |
| | | | ol Input | |
| | 1.14 | | Input Operation | |
| | 1.15 | | ting | |
| | - | 0 0 11 | • | |

| | 1.16 | Mode | | 1-30 |
|---|--------|----------|---|------|
| | | 1.16.1 | I MANUAL (TEACH) Mode | 1-30 |
| | | 1.16.2 | 2 AUTOMATIC (PLAY) Mode | 1-30 |
| | | 1.16.3 | 3 REMOTE Mode | 1-30 |
| | 1.17 | Secur | ity Level Setting | 1-31 |
| | | 1.17.1 | 1 Types of Security Level | 1-31 |
| | | 1.17.2 | 2 Default Security Level Passcodes | 1-33 |
| | | 1.17.3 | 3 Security Level Access Information | 1-33 |
| | | 1.17.4 | Selecting Security Level | 1-34 |
| | | 1.17.5 | 5 Security Level Settings 1.17.5.1 Changing Passcode 1.17.5.2 Changing Startup Security Level | 1-35 |
| 2 | Manipu | lator Co | ordinate Systems and Operations | 2-1 |
| | 2.1 | Control | Groups and Coordinate System | 2-1 |
| | | 2.1.1 | Control Group | 2-1 |
| | | 2.1.2 | Types of Coordinate System | 2-2 |
| | 2.2 | Genera | al Operations | 2-3 |
| | | 2.2.1 | Check Safety | 2-3 |
| | | 2.2.2 | Select Operation Mode | 2-3 |
| | | 2.2.3 | Select Coordinate System | 2-3 |
| | | 2.2.4 | Select Jogging Speed | 2-3 |
| | | 2.2.5 | Servo ON | 2-4 |
| | 2.3 | Operati | ion Check for Emergency Stop Buttons | 2-5 |
| | 2.4 | Coordir | nate Frames and Manipulator Jogging | 2-6 |
| | | 2.4.1 | Smart Frame Mode | 2-8 |
| | | 2.4.2 | Joint Mode | 2-13 |
| | | 2.4.3 | XYZ – World Mode | 2-14 |
| | | 2.4.4 | XYZ - Tool Mode | 2-15 |
| | | | 2.4.4.1 Selecting Tool | |
| | | 2.4.5 | XYZ - User Frame Mode 2.4.5.1 Selecting User Frame | |
| | | 246 | Hand Guiding Mode | |
| | | 2.1.0 | 2.4.6.1 ALL JOINTS | |
| | | | 2.4.6.2 TOOL JOINTS | |
| | | | 2.4.6.3 XYZ + TOOL | |
| | | 2.4.7 | Motion at Robot TCP | 2-21 |

xi

| | | 2.4.8 | Move to Position Panel | 2-23 |
|---|---------|---------------------|--|------|
| | | | 2.4.8.1 Joint Panel | 2-23 |
| | | | 2.4.8.2 TCP Position Panel | |
| | | | 2.4.8.3 TCP Orientation Panel | 2-26 |
| 3 | Managi | ing Jobs | | 3-1 |
| | 3.1 | Prepar | ation for Teaching | 3-1 |
| | | 3.1.1 | Create New Job | 3-1 |
| | | | 3.1.1.1 Setting the Job Name | 3-2 |
| | | | 3.1.1.2 Setting the Tag | |
| | | | 3.1.1.3 Setting the Comment | 3-3 |
| | 3.2 | Job Lis | .t | 3-4 |
| | | 3.2.1 | Default Job and Current Job | 3-4 |
| | | 3.2.2 | Sorting Job | 3-5 |
| | | 3.2.3 | Searching Job | 3-5 |
| | 3.3 | Copyin | g Jobs | 3-6 |
| | 3.4 | Deletin | g Jobs | 3-7 |
| | 3.5 | Modifyi | ing Job | 3-8 |
| | | 3.5.1 | Modifying Job Names | 3-9 |
| | | 3.5.2 | Modifying Tag | 3-9 |
| | | 3.5.3 | Modifying Comment | 3-10 |
| | | 3.5.4 | Setting Default Job | 3-10 |
| | | 3.5.5 | Setting Edit Lock | 3-11 |
| | | 3.5.6 | Accessing Job Details | 3-11 |
| | 3.6 | Additio | nal Settings | 3-12 |
| 4 | Teachir | ng | | 4-1 |
| | 4.1 | Teachi | ng Operation | 4-1 |
| | | 4.1.1 | Job Contents View | 4-1 |
| | | 4.1.2 | Jogging the Robot for Teaching | 4-2 |
| | | 4.1.3 | Motion Type (Interpolation Type) | 4-2 |
| | | | 4.1.3.1 Joint Interpolation | 4-2 |
| | | | 4.1.3.2 Linear Interpolation | 4-2 |
| | | | 4.1.3.3 Circular Interpolation | |
| | | | 4.1.3.4 Spline Interpolation | |
| | | 4.1.4 | Teaching Steps | |
| | | | 4.1.4.1 Teaching Motion Instructions4.1.4.2 Setting Timer Instruction | |
| | | 415 | Overlapping: The First and Last Steps | |
| | | - 1 .1.J | evenapping. The First and Last Oteps | |

HW1485509

| 4.2 | Checki | ng a Step | 4-11 |
|-----|---------|---|------|
| | 4.2.1 | GO TO POINT Operation | 4-11 |
| | 4.2.2 | Circular Movements with the GO TO POINT Operation | 4-11 |
| | 4.2.3 | Spline Curve Movements with the GO TO POINT Operation | 4-11 |
| 4.3 | Test Jo | ъ | 4-12 |
| | 4.3.1 | Test Start | 4-13 |
| 4.4 | Comma | ands | 4-15 |
| | 441 | Command Group | 4-15 |
| | | Color Coordinates | |
| | | Inserting Commands | |
| | | 5 | |
| | | Editing Commands | |
| | | Favorites | |
| | | Command Builder | |
| | | Expanded Inform Line | |
| 4.5 | Editing | Job | 4-31 |
| | 4.5.1 | Edit Menu | |
| | | 4.5.1.1 Undo Operation | |
| | | 4.5.1.2 Redo Operation | |
| | | 4.5.1.3 Cut Operation | |
| | | 4.5.1.4 Copy Operation | |
| | | 4.5.1.5 Paste Operation | |
| | | 4.5.1.6 Delete Operation | |
| | | 4.5.1.7 Suppress Operation | |
| | | 4.5.1.8 Multi-Edit Operation | 4-34 |
| | 4.5.2 | Find Menu | |
| | | 4.5.2.1 To Start | |
| | | 4.5.2.2 To End | 4-37 |
| | | 4.5.2.3 To Previous | |
| | | 4.5.2.4 Go To | |
| | 4.5.3 | Display Menu | |
| | | 4.5.3.1 Display Classic View | |
| | | 4.5.3.2 Display Tool Number | |
| | | 4.5.3.3 Display Variable Names | 4-39 |
| | | 4.5.3.4 Display I/O Names | 4-39 |
| | | 4.5.3.5 Display Favorites bar | |
| | | 4.5.3.6 Display Job Stack | |

| | 4.5.4 | Direct Open | 4-41 |
|--------|---------|---|------|
| | | 4.5.4.1 User Variable | 4-41 |
| | | 4.5.4.2 Position Variable | |
| | | 4.5.4.3 Input/Output Number Direct Open | |
| | | 4.5.4.4 Job Name Direct Open | |
| 4.6 | User Va | ariables | 4-44 |
| | 4.6.1 | Setting Byte, Integer, Double, and Real Type Variables | 4-46 |
| | 4.6.2 | Setting String (Character) Type Variable | 4-47 |
| | 4.6.3 | Setting Position Variable with Variable Screen | 4-48 |
| | | 4.6.3.1 Setting Position Variable by Moving the Manipulator | 4-48 |
| | | 4.6.3.2 Setting Position Variable Using the Numeric Keypad | 4-49 |
| | | 4.6.3.3 Closure Setting | |
| | 4.6.4 | Specifying Motion Commands using Position Variables | 4-55 |
| | 4.6.5 | Deleting Variable | 4-57 |
| 4.7 | Monito | ring Variables | 4-58 |
| | 4.7.1 | Monitoring Variables using Watch Window | 4-58 |
| | | 4.7.1.1 Variables (Byte / Integer / Double / Real / String) | |
| | | 4.7.1.2 Positions | |
| | 4.7.2 | Monitoring Variables using Variable Setting Screen | 4-62 |
| 4.8 | Local V | /ariables | 4-63 |
| | 4.8.1 | Local Variable | 4-64 |
| | | 4.8.1.1 Allocation | |
| | | 4.8.1.2 Entering Local Variables | |
| | | 4.8.1.3 Usage of Local Variable | 4-67 |
| | 4.8.2 | Job Arguments | 4-68 |
| | | 4.8.2.1 Configuration | |
| | | 4.8.2.2 Using Job Arguments | 4-70 |
| | | 4.8.2.3 Job Argument Type Conversion | 4-73 |
| 4.9 | Teachii | ng Coordinate | 4-75 |
| | 4.9.1 | Changing Teaching Coordinate | 4-76 |
| | 4.9.2 | Application Example | 4-80 |
| Playba | ck | | 5-1 |
| 5.1 | Prepara | ation for Playback | 5-1 |
| | 511 | Selecting a Job | 51 |
| | 5.1.1 | 5.1.1.1 Open a Job | |
| | | | |

5

| | 5.1.2 | Test/Rur | n Job Panel | 5-3 |
|------------------|--|---|--|---------------------------|
| | | 5.1.2.1 | Operation Buttons | 5-3 |
| | | 5.1.2.2 | Operation Cycle | |
| | | 5.1.2.3 | Playback Speed | |
| | | 5.1.2.4 | Time Indicators | 5-5 |
| 5.2 | Playba | ck | | |
| | 5.2.1 | Playback | k Operation | |
| | | 5.2.1.1 | Selecting the Start Mode | |
| | | 5.2.1.2 | Servo ON | 5-6 |
| | | 5.2.1.3 | Run Operation | |
| 5.3 | Stop ar | nd Restart | t | |
| | 5.3.1 | Pause | | |
| | | 5.3.1.1 | Using the Smart Pendant | 5-7 |
| | | 5.3.1.2 | Using an External Input Signal (System Input) | 5-7 |
| | 5.3.2 | Emerger | ncy Stop | |
| | 0.012 | - | Emergency Stop | |
| | | | Release | |
| | | | Restart After an Emergency Stop | |
| | 5.3.3 | | Alarm | |
| | | | | |
| | 5.5.4 | | Temporary Stop by Mode Change | |
| | | | | |
| | | 5312 | Lemporary Stop by the PALISE Instruction | 5_0 |
| | | | Temporary Stop by the PAUSE Instruction | |
| 5.4 | Job Sta | | Temporary Stop by the PAUSE Instruction | |
| | | ick | | 5-10 |
| 6 Robot S | Settings | ack | | 5-10 |
| 6 Robot S | Settings Tool Se | ack | | 5-10 6-1 6-1 |
| 6 Robot S | Settings Tool Se 6.1.1 | ettings | 95 | 5-10 6-1 6-1 6-2 |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 | ettings Tool File Tool Nar | ne | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 | ettings Tool File Tool Nar Tool Mas | es me ss Properties | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 | ettings Tool File Tool Nar Tool Mas 6.1.3.1 | es me ss Properties Weight | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 | ettings Tool File Tool Nar Tool Mas 6.1.3.1 6.1.3.2 | ne ss Properties | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 | ettings Tool File Tool Nar Tool Mar 6.1.3.1 6.1.3.2 6.1.3.3 | es me ss Properties Weight Center of Gravity Moment of Inertia | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 6.1.3 | ettings Tool File Tool Nar Tool Mas 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 | es me ss Properties Weight Center of Gravity Moment of Inertia Automatic Estimation of Tool Mass Properties | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 6.1.3 | ettings Tool File Tool Mar 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra | es me ss Properties Weight Center of Gravity Moment of Inertia Automatic Estimation of Tool Mass Properties me | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 6.1.3 | ettings Tool File Tool Nar 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 | es me ss Properties Weight Center of Gravity Moment of Inertia Automatic Estimation of Tool Mass Properties me Tool Center Point | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 6.1.3 | ettings Tool File Tool Nar 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 6.1.4.2 | es | |
| 6 Robot S | Settings Tool Se 6.1.1 6.1.2 6.1.3 | ettings Tool File Tool Nar Tool Nar 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 6.1.4.2 6.1.4.3 | res | 5-10 |
| 6 Robot 9 | Settings Tool Se 6.1.1 6.1.2 6.1.3 6.1.4 | ettings Tool File Tool Nar Tool Mas 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 6.1.4.2 6.1.4.3 Setting T | res | 5-10 |
| 6 Robot 9 6.1 | Settings Tool Se 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 I/O for | ettings Tool File Tool Nar Tool Mas 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 6.1.4.2 6.1.4.3 Setting T Tool | es me ss Properties | 5-10 |
| 6 Robot 9 6.1 | Settings Tool Se 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 I/O for T User Fr | ettings Tool File Tool Nar Tool Mas 6.1.3.1 6.1.3.2 6.1.3.3 6.1.3.4 Tool Fra 6.1.4.1 6.1.4.2 6.1.4.3 Setting T Tool rames | res | 5-10 |

xν

HW1485509

| | 6.3.2 | Methods for User Frame Setting | 6-22 |
|--------|----------|--|------|
| | 6.3.3 | User Frame Number | 6-22 |
| | 6.3.4 | User Frame Setting | 6-23 |
| | 6.3.5 | Deleting the User Frame | 6-25 |
| 6.4 | Zones. | | 6-26 |
| | 6.4.1 | Cubic Zone | 6-26 |
| | | 6.4.1.1 Cubic Zone Setting Operation | 6-27 |
| | 6.4.2 | Axis Zone | |
| | 640 | 6.4.2.1 Axis Zone Setting Operation | |
| 6 5 | | Zone Status | |
| 0.5 | | Detection Setting | |
| | | Shock Detection Overview | |
| | | Shock Detection Setting Interface | |
| | | Using Multiple Shock Detection Settings | |
| | | Shock Detection Watch | |
| 6.6 | Robot (| Configuration Positions | 6-40 |
| | 6.6.1 | Robot Position Types | 6-41 |
| | | Move to a Robot Position | |
| | 6.6.3 | Edit a Robot Position | 6-42 |
| | 6.6.4 | Robot Position Confirm Procedure | 6-43 |
| 6.7 | Home F | Position Calibration | 6-46 |
| | 6.7.1 | Verification of Home Position Calibration | 6-48 |
| | 6.7.2 | Home Position Calibration Methods | |
| | | 6.7.2.1 Individual Axis Calibration Procedure6.7.2.2 All Axes Calibration Procedure | |
| | | 6.7.2.3 Manual Calibration Procedure | |
| Concur | rent I/O | (Input/Output) | 7 1 |
| | | | |
| | | es of Concurrent I/O | |
| | | cation of I/O signals | |
| 7.3 | I/O Inst | ructions | 7-3 |
| | | DigitalOut Output#() | |
| | 7.3.2 | Digital Output for a Group | 7-4 |
| 7.4 | Monitor | ring I/O from Smart Pendant Interface | 7-5 |
| | 7.4.1 | Monitoring I/O Signals by I/O Monitor | 7-5 |

7

| | | 7.4.2 | I/O Windows | 7-6 |
|---|-------------------|---|--|-------------------|
| | 7.5 | I/O Det | 7.4.2.2 I/O Screens | |
| | - | | I/O Detailed View Overview | |
| | | | Editing Output Values | |
| | 7.6 | | et/IP Status Warning | |
| | 7.7 | Block I/ | /O | 7-30 |
| | | 7.7.1 | Edit a Block I/O Setting | 7-33 |
| | | 7.7.2 | Using Block I/O for Tool Operation | 7-34 |
| | 7.8 | I/O Allo | ocation and EtherNet/IP Configuration | 7-37 |
| | | 7.8.1 | I/O Device List | 7-38 |
| | | 7.8.2 | Input/Output Table | 7-40 |
| | | 7.8.3 | EtherNet/IP Adapter | 7-41 |
| | | | 7.8.3.1 Creating an Adapter | |
| | | | 7.8.3.2 Configuring the Adapter | |
| | | 7.8.4 | EtherNet/IP Scanner | |
| | | | 7.8.4.1 Creating a Scanner7.8.4.2 Configuring a Scanner | |
| | | | | |
| | | 7.8.5 | Modifying Allocations using Input/Output Table | 7-48 |
| 8 | System | | Modifying Allocations using Input/Output Table | |
| 8 | - | and YR | C Controller Setting | 8-1 |
| 8 | System 8.1 | and YR Genera | C Controller Setting | 8-1 8-3 |
| 8 | - | and YR Genera 8.1.1 | C Controller Setting | 8-1 8-3 8-3 |
| 8 | - | and YR Genera 8.1.1 8.1.2 | C Controller Settingal Organization Date & Time | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 | C Controller Setting al Organization Date & Time Language | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit | C Controller Setting Organization Date & Time Language y Level Settings | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 | C Controller Setting Organization Date & Time Language y Level Settings | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 | C Controller Setting Organization Date & Time Language y Level Settings Access Startup Level | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar | C Controller Setting Organization Date & Time Language y Level Settings Access Startup Level nt Software | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 | C Controller Setting Organization Date & Time Language y Level Settings Access Startup Level Version | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 8.3.2 | C Controller Setting Organization Date & Time Language y Level Settings Access Startup Level nt Software | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 8.3.2 8.3.3 | C Controller Setting | |
| 8 | 8.1 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 8.3.2 8.3.3 8.3.4 | C Controller Setting Organization Date & Time Language y Level Settings Access Startup Level t Software Version Release Pendant ID USB ID | |
| 8 | 8.1 8.2 8.3 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 8.3.2 8.3.3 8.3.4 8.3.5 | C Controller Setting | |
| 8 | 8.1 8.2 8.3 | and YR Genera 8.1.1 8.1.2 8.1.3 Securit 8.2.1 8.2.2 Pendar 8.3.1 8.3.2 8.3.3 8.3.4 8.3.5 Bundle | C Controller Setting Organization Date & Time Language | |

xvii

HW1485509

| | | 8.4.2 | Software Pendant Application | 8-7 |
|----|---------|---------|--|------|
| | | 8.4.3 | Licenses | 8-7 |
| | 8.5 | System | n Features | 8-8 |
| | | 8.5.1 | YRC Controller Software | 8-8 |
| | | 8.5.2 | Robot Model | 8-8 |
| | | 8.5.3 | Functional Safety Unit (FSU) | 8-8 |
| | | 8.5.4 | Power & Force Limiting (PFL) | 8-8 |
| | | 8.5.5 | Restart YRC Controller | 8-8 |
| | | 8.5.6 | Output Full Selection Layout | 8-9 |
| | 8.6 | Networ | k | 8-11 |
| | | 8.6.1 | YRC1000 Network | 8-11 |
| | | 8.6.2 | YRC1000micro Network | 8-11 |
| | | 8.6.3 | MAC Address | 8-12 |
| | | 8.6.4 | Setting IP Address | 8-12 |
| | 8.7 | Setting | s and Parameters | 8-13 |
| | 8.8 | Remote | e Screen Sharing | 8-14 |
| οı | Itility | | | 0_1 |
| 0 | | | elease | |
| | | 9.1.1 | Soft Limits | |
| | | | Self-Interference | |
| | | 9.1.3 | All Limits | 9-2 |
| | 9.2 | Brake I | Release | 9-3 |
| | | 9.2.1 | Brake Release for YRC1000 | |
| | | 9.2.2 | Brake Release for YRC1000micro | |
| | | | Execute Brake Release | |
| | 9.3 | Backup | and Restore | 9-6 |
| | | 9.3.1 | System Backup | 9-6 |
| | | | System Restore | |
| | 9.4 | | ansfer | |
| | | 9.4.1 | File Transfer Overview | |
| | | | Procedures for File Transfer from YRC Controller | |
| | | | 9.4.2.1 Overwrite or Skip Files | 9-10 |
| | | | 9.4.2.2 Overwrite or Skip Individual File | 9-11 |
| | | 0 4 0 | Procedures for File Transfer to YRC Controller | 0.10 |

| | | 9.4.4 Selection of Target/Source Folder | |
|----|----------|--|-------|
| | | 9.4.4.1 Create a New Folder | |
| | | 9.4.4.2 Rename an Existing Folder | |
| | | 9.4.4.3 Select the Target/Source Folder | |
| | 9.5 | Robot Status Watch | 9-17 |
| 10 | Direct 7 | Teach | 10-1 |
| | 10.1 | Direct Teach Description | 10-1 |
| | 10.2 | Direct Teach Access and Setup Panel | 10-2 |
| | | 10.2.1 Set Jog Mode | 10-2 |
| | | 10.2.2 Select Motion Type | 10-2 |
| | | 10.2.3 Select Tool for Direct Teach | 10-3 |
| | | 10.2.4 Enable Direct Teach | 10-3 |
| | 10.3 | Direct Teach Settings | 10-4 |
| | | 10.3.1 Enable Teach Button and Enable Tool Button | 10-5 |
| | | 10.3.2 Tool Number for Block I/O State | 10-5 |
| | | 10.3.3 Example on Setting Direct Teach | 10-6 |
| | 10.4 | Direct Teach Example | 10-7 |
| 11 | Safety | Function | 11-1 |
| | 11.1 | System Structure | 11-1 |
| | | 11.1.1 Safety Circuit Board (JANCD-ASF01-E) | 11-1 |
| | | 11.1.2 PFL Circuit Board (JANCD-ASF04-E) | 11-1 |
| | | 11.1.3 Expansion Safety I/O Board (JANCD-ASF02-E) | 11-2 |
| | | 11.1.4 Expansion Safety Terminal Block Board | 11-2 |
| | 11.2 | Common Operation | 11-3 |
| | | 11.2.1 Security Level | 11-3 |
| | | 11.2.2 Readback Operation | 11-3 |
| | | 11.2.3 Tool Configuration | 11-4 |
| | | 11.2.4 Tool Interference Configuration | 11-5 |
| | 11.3 | Safety Logic Circuit | 11-6 |
| | | 11.3.1 Introduction | 11-6 |
| | | 11.3.2 Available I/O Signals in Safety Logic Circuit | 11-8 |
| | | 11.3.3 Operation of Safety Logic Circuit | |
| | | 11.3.3.1 Display the Screen | |
| | | 11.3.3.2 Selecting System and User Circuits | |
| | | 11.3.3.3 Create New Safety Logic Circuit | 11-17 |

xix

HW1485509

| | 11.3.3.4 Edit Input Relays | 11-18 |
|------|--|-------|
| | 11.3.3.5 Edit Output Relays | 11-20 |
| | 11.3.3.6 Add Relay | 11-23 |
| | 11.3.3.7 Delete Relay | 11-24 |
| | 11.3.3.8 Delete Line | 11-25 |
| | 11.3.3.9 Move Relay | 11-25 |
| | 11.3.3.10 Cancel Edit | 11-25 |
| | 11.3.3.11 Transferring and Updating Safety Logic Circuit File | 11-26 |
| | 11.3.3.12 Execute Safety Logic Circuit | 11-27 |
| | 11.3.4 Setting of Input/Output Signals | 11-27 |
| | 11.3.4.1 Setting of General Purpose Input Signal (FSBIN) | 11-28 |
| | 11.3.4.2 Setting of General Purpose Output Signal (FSBOUT) | |
| | 11.3.4.3 Setting of Safety Fieldbus Input Signals (SFBIN (Fieldbus)) | |
| | 11.3.4.4 Setting of Safety Fieldbus Output Signals (SFBOUT (Fieldbus)) | |
| | 11.3.4.5 Setting of Safety Functions Output signals (FSOUT) | |
| | 11.3.4.6 Setting of Safety Logic Circuit Output Signals (MSOUT) | |
| | 11.3.4.7 Settings of Specific Input Signals (SPIN) | |
| | 11.3.5 Setting ON/OFF Status to the Input Signals | |
| | | |
| | 11.3.6 About Output Signals | |
| | 11.3.6.1 Correspondence with Hard Wire | |
| | 11.3.6.2 Display of the Message on the Pendant | |
| | 11.3.6.3 Full Speed Mode | 11-39 |
| | 11.3.7 General-Purpose Safety Output Monitoring Signal | 11-40 |
| | 11.3.7.1 Activate Signals | 11-40 |
| | 11.3.7.2 Correspondence between General Purpose Output Signals and Monitoring Signals | 11-41 |
| | 11.3.7.3 Example of Setting for Monitoring Signals | 11-42 |
| | 11.3.8 Safety Data Monitoring | 11-43 |
| | 11.3.9 Example of Safety Logic Circuit | 11-48 |
| | 11.3.9.1 Example1 (AND) | 11-48 |
| | 11.3.9.2 Example 2 (OR) | 11-49 |
| | 11.3.9.3 Example3 (Pulse) | 11-50 |
| | 11.3.9.4 Example4 (ON Delay) | 11-51 |
| | 11.3.9.5 Example 5 (Decelerate and Stop the Robot) | 11-52 |
| | 11.3.9.6 Example 6 (Temporarily Disable PFL for Human Collaborative Robots) | 11-53 |
| 11.4 | Functional Safety Functions | 11-55 |
| | 11.4.1 Outline | 11-55 |
| | 11.4.2 List of Safety Functions | 11-55 |
| | 11.4.3 Safety Functions List View | |
| | 11.4.3.1 List View | |
| | 11.4.3.2 Create New Setting | |
| | 11.4.3.3 Delete Setting | |
| | \sim | - |

| | 11.4.4 Robot Range Limit | 11-60 |
|------|--|--------|
| | 11.4.4.1 Condition Setting | |
| | 11.4.4.2 Confirming the Safety Range and Starting the Robot Range Limit. | |
| | 11.4.4.3 Switch the Monitoring Area | |
| | 11.4.4.4 Estimated CPU Load | 11-71 |
| | 11.4.5 Axis Range Limit | |
| | 11.4.5.1 Condition Setting | |
| | 11.4.5.2 Confirming the Safety Range and Starting the Axis Range Monitor | |
| | 11.4.6 Speed Limit | |
| | 11.4.6.1 Outline of the Speed Limit | |
| | 11.4.6.2 Condition Setting | |
| | 11.4.6.3 Starting the Speed Limit | |
| | 11.4.6.4 Speed Limit in MANUAL (TEACH) Mode | |
| | 11.4.7 Axis Speed Monitor | |
| | 11.4.7.1 Condition Setting | |
| | 11.4.7.2 Starting the Axis Speed Monitor | |
| | 11.4.8 Tool Angle Monitor | 11-87 |
| | 11.4.9 Tool Change Monitor | 11-87 |
| | 11.4.10 External Force Monitor | 11-87 |
| | 11.4.10.1 Condition Setting | 11-89 |
| | 11.4.10.2 Confirming and Starting the External Force Monitor | |
| | 11.4.10.3 Temporarily Disable All External Force Monitors | |
| | 11.4.10.4 Daily Inspection | 11-91 |
| | 11.4.11 Safety Signal | |
| | 11.4.11.1 Allocation of Safety Logic Circuit Extended Signal | |
| | 11.4.11.2 Allocation of Safety Fieldbus Signal | |
| | 11.4.11.3 Enable Condition of Safety Functions Setting | |
| | 11.4.11.4 Safety Signal Output Value | |
| 11.5 | Safety Caution | 11-100 |
| | 11.5.1 How to Restart the YRC Controller | 11-100 |
| | 11.5.2 Check Items before Operating the Manipulator | 11-100 |
| | 11.5.3 About the Behavior near Singularity | 11-101 |
| 11.6 | Data Protection | 11-102 |
| | 11.6.1 Duplicate Data | 11-102 |
| | 11.6.2 Safety Board FLASH Reset | 11-102 |
| | 11.6.3 Verify Safety Settings (CRC) | 11-103 |
| | 11.6.3.1 Overview | 11-103 |
| | 11.6.3.2 Verify Safety Settings (CRC) Screen | 11-104 |
| | 11.6.3.3 Change of Condition File by an External Device | 11-105 |

xxi

| | 11.7 | Setting | Example of the Safety Functions | 11-106 |
|----|---------|----------|--|--------|
| | | 11.7.1 | Single Safety Laser Scanner to Pause Robot Motion | 11-106 |
| | | 11.7.2 | Single Safety Laser Scanner to Activate Collaborative Operation | 11-109 |
| | | 11.7.3 | Reduce the Robot Speed by Robot Position | 11-111 |
| | | 11.7.4 | Reduce the Robot Speed by Robot Position only when Collaborative Operation Mode | 11-114 |
| | | 11.7.5 | Add the Resume Switch for Collaborative Operation | 11-115 |
| 12 | Softwa | re Penda | ant | 12-1 |
| | 12.1 | Introdu | ction | 12-1 |
| | | 12.1.1 | Overview of Software Pendant | 12-1 |
| | | 12.1.2 | Functions | 12-1 |
| | 12.2 | Softwa | re Pendant Installation | |
| | | 12.2.1 | Export Software Pendant Application from Smart Pendant | |
| | | 12.2.2 | Install Software Pendant for YRC Controller on PC | 12-3 |
| | | 12.2.3 | Network Configuration | 12-6 |
| | 12.3 | Conne | ction Process | 12-7 |
| | | 12.3.1 | Wiring | 12-7 |
| | | 12.3.2 | IP Setting | 12-8 |
| | | 12.3.3 | Startup of Software Pendant | |
| | 12.4 | Softwa | re Pendant Function | 12-14 |
| | | 12.4.1 | Screen & Keyboard Function Locations | |
| | | 12.4.2 | Pendant Switch | 12-15 |
| | | 12.4.3 | Settings on Software Pendant | |
| | | | 12.4.3.1 Security Mode Change | |
| | | | 12.4.3.2 Safety Logic Circuit Editing | |
| | 12.5 | | 12.4.3.3 Safety Board Flash Reset | |
| | | - | - | |
| | | | ct the Software Pendant to the YRC Controller using Wireless (Wi-Fi) | |
| 13 | Externa | al Memo | ry Device | 13-1 |
| | 13.1 | Memor | y Device | 13-1 |
| | | 13.1.1 | USB Memory Stick | 13-1 |
| | | 13.1.2 | Recommended USB Memory Stick | 13-1 |
| | | 13.1.3 | Notes on Handling USB Memory Stick | 13-1 |
| | | 13.1.4 | Rules for USB Connectors and USB Memory Sticks | 13-2 |
| | | 13.1.5 | Inserting a USB Memory Stick in Smart Pendant | 13-3 |

| | | 13.1.6 | Inserting a USB Memory Stick in the CPU Board (JANCD-ACP01) | 13-3 |
|-----|----------|----------|---|------|
| | 13.2 | Handlir | ng Data | 13-4 |
| | 13.3 | Macro | Installation | 13-8 |
| 14 | Startup | Error | | 14-1 |
| | 14.1 | Startup | Errors and Notifications | 14-1 |
| | | 14.1.1 | Startup Error Overview | 14-1 |
| | | 14.1.2 | Startup Errors | 14-3 |
| 15 | Alarm | | | 15-1 |
| | 15.1 | Alarm I | History | 15-1 |
| | 15.2 | Alarms | & Notifications | 15-3 |
| | | 15.2.1 | Alarm Overview | 15-3 |
| | | 15.2.2 | Major Alarm | 15-4 |
| | | 15.2.3 | Minor Alarm | 15-5 |
| | | 15.2.4 | User Alarm | 15-6 |
| | | 15.2.5 | Notifications | 15-6 |
| 16 | Help / S | Support. | | |
| | 16.1 | Take S | creenshot | 16-1 |
| | 16.2 | YASKA | WA Representative | |
| 17 | Mainter | nance | | |
| | 17.1 | Cleanir | ng the Smart Pendant | 17-1 |
| | 17.2 | Cleanir | ng the Smart Pendant Cable | 17-1 |
| Арр | pendix A | | | A-1 |
| | A.1 | Open So | ource License | A-1 |

- 1 Smart Pendant
- 1.1 General Product Description

1 Smart Pendant

1.1 General Product Description

With this Smart Pendant, even users who have no experience of robot operation can easily perform teaching operation.

1.2 Smart Pendant Contents Confirmation

1-1

Confirm the contents of the delivery when the product arrives.

- Smart Pendant (JZRCR-APP30-1) (with 8 m cable connected)
- Two Switch Keys



- 1 Smart Pendant
- 1.3 Smart Pendant Specification

1.3 Smart Pendant Specification

| Material | Reinforced thermoplastic enclosure with a detachable suspending strap | |
|---|--|--|
| Dimensions 215(W) × 284(H) × 69(D) mm (excluding protrusions) | | |
| Weight | Approx. 1120 g | |
| Protection Class | IP54 | |
| Displayed Units | 256.5 mm (10.1 inch) wide WXGA TFT Display 1280 x 800 pixel, LED back light, Touch panel | |
| Operated Units | Three-position enable switch, mode switch (with key, three mode) Type of the key for the mode switch: KeTop EKY002 (manufactured by KEBA) * Two keys are shipped with the Smart Pendant. | |
| Cable Length | Standard: 8 m maximum (optional): YRC1000 : 36 m (Standard 8 m + Extension 28 m) YRC1000micro: 20 m (Standard 8 m + Extension 12 m) | |
| Others | USB connector (USB2.0) X 1 The software pendant installer built into the pendant can be downloaded to the USB memory and installed on the PC for use. | |

For environmental conditions, refer to the INSTRUCTIONS of the YRC Controller for installation environment.


1-2


HW1485509


- 1 Smart Pendant
- 1.4 Smart Pendant Overview


1.4 Smart Pendant Overview

Smart Pendant has several physical characteristics that a user will interact with. These are shown below:









- 1 Smart Pendant
- 1.5 Connection of the Smart Pendant


1.5 Connection of the Smart Pendant

For information on setup, installation, and connection of the YRC Controller, refer to the INSTRUCTIONS of the YRC Controller.

1.5.1 Connecting to the YRC Controller

Connect the Smart Pendant cable to the connector (-X81) on the door lower right side of the YRC Controller cabinet.

Fig. 1-3: Connection of Smart Pendant Cable to the YRC Controller



The YRC Controller has the main power switch and the door lock that are located in the upper left on the front panel. The Emergency Stop button is installed in the upper right of the front panel (some models do not have this button), and the Smart Pendant can be hung from a hook below the button.






Fig. 1-4: YRC1000 Front View with Smart Pendant

- 1 Smart Pendant
- 1.5 Connection of the Smart Pendant

1.5.2 Connecting to the YRC1000micro


Connect the Smart Pendant cable to the connector (-X81) on the front panel of the YRC1000micro.







If the Smart Pendant is not used, connect the Smart Pendant safety signal short circuit connector to connector (-X81).




- 1 Smart Pendant
- 1.6 Holding the Smart Pendant

1.6 Holding the Smart Pendant

The Smart Pendant can be held in two ways: using the right hand, press the enable switch with the thumb or, using the left hand, press the enable switch with the index finger. Adjust the strip band to make the hand comfortable.

Fig. 1-6: Holding the Smart Pendant



- 1 Smart Pendant
- 1.7 Display and Operating Elements

1.7 Display and Operating Elements

Operating elements include:

- Status LED
- Membrane keypads
- Enable switch
- Mode key
- Touch screen
- Emergency Stop button

1.7.1 Status LED


The status LEDs are found on the top right side of the Smart Pendant. POWER: indicates the power status of the Smart Pendant. SERVO: indicates the servo power status of the manipulator. ERROR: indicates the alarm status of the YRC Controller.

Fig. 1-7: Status LED



1.7.2 Key Description on Membrane Keypads

The membrane keypads are found on the right side of the Smart Pendant.



1 Smart Pendant

1.7 Display and Operating Elements

| GO TO POINT | GO TO POINT When the [GO TO POINT] is pressed and a motion instruction is selected in the Job Contents view, the manipulator moves to the selected position. Only available in MANUAL (TEACH) mode. |
|----------------|--|
| | RUN When pressed in AUTOMATIC (PLAY) mode, a taught job is played back. In MANUAL (TEACH) mode, the taught job is played back as long as the button is pressed and held down. |
| п | PAUSE When pressed in AUTOMATIC (PLAY) mode, the playing job can be paused at the current position. Press [RUN] to restart. |
| - + - + | Jog Key Moves a specific axis or Tool Center Point (TCP) coordinate of the manipulator. An indicator panel will show on the screen next to the jogging keys to show what each set of keys is controlling when the jog mode is changed. The manipulator operates only while the key |
| - + | is pressed. • By pressing two or more keys simultaneously, multiple axes can be operated at the same time. (Except when Plus and Minus is for the same pair) |
| | The manipulator operates in the selected coordinate system at the selected jogging speed. Before operating the axis, make sure that the selected coordinate system and the jogging speed are set as intended. |
| SLOW FAST | Jogging Speed Key The FAST and SLOW Keys toggle through the jogging speed settings; LOW, MED, HIGH, TOP. The user can see the jog speed setting change on the Status Bar. |
| | NOTE: Pressing the [FAST] and [SLOW] membrane keys simultaneously will trigger a screenshot if a USB storage device is present. |

- 1 Smart Pendant
- 1.7 Display and Operating Elements

| JOG MODE Selects the operation coordinate system when the manipulator is manually operated. |
|--|
| The coordinate system can be selected from the four coordinate systems: Joint, XYZ- World, XYZ-Tool, and XYZ-User. |
| Each time this key is pressed, the coordinate system is switched in the following order: Joint → XYZ-World → XYZ-Tool → XYZ-User |
| The selected coordinate system is shown in the Status Bar. |
| SMART FRAME Changes the Jog Mode to Smart Frame jogging. |
| |

1.7.3 Enable Switch

When the Mode Switch is in MANUAL (TEACH) mode and the Enable Switch is half pressed while the {SERVO} is in orange, the servo power turns ON.

If this switch is released or firmly squeezed while the power is turned ON, the servo turns OFF.

Fig. 1-8: Enable Switch









Release \rightarrow OFF

Squeeze → ON

Squeeze Tightly \rightarrow OFF



MOTOMAN-HCxxDT does not require to squeeze the Enable Switch to turn ON the servos. The servos will turn on when the {SERVO} on the screen is pressed and MOTOMAN-HCxxDT can be jogged.



- 1 Smart Pendant
- 1.7 Display and Operating Elements

Mode switch is used for toggling between MANUAL (TEACH) mode, AUTOMATIC (PLAY) mode, and REMOTE Mode.

- MANUAL (TEACH) mode

Axis can be operated. Job and other settings can be edited using the Smart Pendant. This mode is also called TEACH mode.

- AUTOMATIC (PLAY) mode
 Playback of a taught job can be performed. This mode is also called
 PLAY mode.
- REMOTE mode

Operation by an external signal is enabled. The Software Pendant can only be used under the REMOTE mode. During the REMOTE mode, [GO TO POINT] of the Smart Pendant is disabled. Use of Servo OFF and pause are allowed.

If communication between the YRC Controller and the Smart Pendant is cut off, the mode of the YRC Controller cannot be changed. When the teaching process is completed, a qualified engineer should remove the mode switch key and keep it in a safe place. For more information, refer to *chapter 1.16 "Mode"*.

1.7.5 Touch Screen

A Projected Capacitive Touch (PCT) screen is used for the Smart Pendant. The touch screen may be operated with fingers or a touch-pen that is specifically designed for PCT use.

1.7.6 Emergency Stop Button

The Emergency Stop button is used to turn OFF the servo power.

When the servo power is turned OFF, the SERVO LED on the Smart Pendant turns OFF. Emergency Stop message is shown on the display.



• When the Smart Pendant (JZRCR-APP30-1) is used, the Emergency Stop output signals (ESPOUT1 & ESPOUT 2) do not interface with the Smart Pendant's Emergency Stop button. Therefore, when configuring a safety circuit externally using the Emergency Stop output, confirm safety beforehand and make it an appropriate circuit configuration. Refer to *chapter 1.7.7 "Emergency Stop Output"* for further details.

- 1 Smart Pendant
- 1.7 Display and Operating Elements

1.7.7 Emergency Stop Output

1.7.7.1 Emergency Stop Output for YRC1000

When using the Smart Pendant, only the contact of the Emergency Stop button on the front of the door is output (some models do not have this button). These contact outputs are always valid regardless of the YRC1000 main power supply status ON or OFF (Status output signal: normally closed contact). These outputs are dual output.

| Signal Name | Connection No. IM-YE250/5-80P | Function | Factory Setting |
|----------------|----------------------------------|---------------------------------------|--------------------|
| ESPOUT1+ | -37 | Used to output a contact point of the | Open |
| ESPOUT1- | -38 | Emergency Stop button on the Smart | |
| | | Pendant (JZRCR-APP01) and the | |
| ESPOUT2+ | -39 | front door of the YRC1000 Control | |
| ESPOUT2- | -40 | panel.(Some models do not have | |
| | | this button) | |
| | | However, when using the Smart | |
| | | Pendant (JZRCR-APP30-1), it does | |
| | | not work with the Emergency Stop | |
| | | button of the Smart Pendant. | |

Table 1-1: Emergency Stop Output for YRC1000



When the Smart Pendant (JZRCR-APP30-1) is used, the Emergency Stop output signals (ESPOUT1 & ESPOUT 2) do not interface with the Smart Pendant's Emergency Stop button. Therefore, when configuring a safety circuit externally using the Emergency Stop output, confirm safety beforehand and make it an appropriate circuit configuration.

- 1 Smart Pendant
- 1.7 Display and Operating Elements




Fig. 1-9: Emergency Stop Output Circuit for YRC1000



If contact output that interlocks with the Emergency Stop button on the Smart Pendant it is necessary, refer to "YRC1000 INSTRUCTION (RE-CTO-A221)" for the section on "Safety Logic Circuit".

PPESP signal, and other signals can be combined and output to the general safety signal output (GSOUT 1, 2).

HW1485509

- 1 Smart Pendant
- 1.7 Display and Operating Elements

1.7.7.2 Emergency Stop Output for YRC1000micro

When using the Smart Pendant, it does not interlock with the Emergency Stop button of the Smart Pendant.

The contact Close status is output at all times. These outputs are dual output.


In case of YRC1000micro, it cannot be used as Emergency Stop output.


Table 1-2: Emergency Stop Output for YRC1000micro

| Signal Name | Connection No. Robot Specific Signal Input Connector (SAFETY) | Function | Factory Setting |
|----------------------|---|--|--------------------|
| ESPOUT1+ ESPOUT1- | -9 -19 | While using a Programming Pendant (JZRCR-APP01), this signal is used | Open |
| | | to output the contact of the | |
| ESPOUT2+ | -10 | Emergency Stop button. | |
| ESPOUT2- | -20 | However, when using the Smart | |
| | | Pendant (JZRCR-APP30-1), it does not work with the Emergency Stop | |
| | | button on the Smart Pendant. | |



When the Smart Pendant (JZRCR-APP30-1) is used, the Emergency Stop output signals (ESPOUT1 & ESPOUT 2) do not interface with the Smart Pendant's Emergency Stop button. Therefore, when configuring a safety circuit externally using the Emergency Stop output, confirm safety beforehand and make it an appropriate circuit configuration.





1 Smart Pendant

SUPPLE

1.7 **Display and Operating Elements**

> If contact output that interface with the Emergency Stop button of the Smart Pendant is necessary, refer to "YRC1000micro INSTRUCTION (RE-CTO-A222)" for the section on "Safety Logic Circuit".

PPESP signal, and other signals can be combined and output to the functional safety board's general purpose outputs (FSBOUT $1 \rightarrow 8$).

In this case the Functional Safety option must be enabled

and the Expansion Safety I/O Board (JANCD-ASF32-E) must be installed in the YRC Controller. Refer to "YRC1000micro OPTION INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION" (HW1484544) for more information.

HW1485509

1-14

- 1 Smart Pendant
- 1.8 Smart Pendant Display

1.8 Smart Pendant Display

The Smart Pendant Display is a 10-inch color Touch Screen Display. The layout of each screen is different; however, there are two main screen layouts that will be described in this section:

- Job Layout

This is the active view when editing or running a job

- Configuration Layout

This is the active view when viewing or editing a configuration setting such as Tools, User Frames, Zones, etc.

1.8.1 Job Layout

This is the screen that will be displayed after opening a job or selecting {JOG} or {RUN} from the Home Screen. It is divided into four main display areas:

① Status Bar

View status and access common actions such as {MENU} and {SERVO}.

2 Job Contents View

Contains the contents of the Current Job. Basic job actions such as Teaching Positions, Copying/Pasting operation, and editing instruction parameters can be performed.

③ Programming Panel


Contents will change based on Navigation Bar. For example, the Robot Jog panel is shown in *fig. 1-11 "Job Layout*".

④ Navigation Bar

Use this to change the content of the Programming Panel.

1-15

- 1 Smart Pendant
- 1.8 Smart Pendant Display



1.8.2 Configuration Layout

The screen is displayed in configuration layout when viewing or editing a setting (e.g. Tool, User Frame). The screen is divided into four main display areas:

① Status Bar

View status and access common actions such as Main Menu and Servo ON/OFF.

2 Configuration List

This contains a list of configured items as well as controls for adding/ deleting and searching.

③ Configuration Details

1-16

This contains the details of the item selected in the Configuration List.

④ Robot Jog Panel

Press it to use the Robot Jog Panel during configuration. Only Configuration (e.g. User Frames, Zones) that may require teaching positions shows this display area.

- 1 Smart Pendant
- 1.8 Smart Pendant Display

Fig. 1-12: Configuration Layout




HW1485509


- 1 Smart Pendant
- 1.8 Smart Pendant Display

1.8.3 Help Information

Smart Pendant also has built-in Help Information to further describe the interfaces. This information can be accessed by pressing the *(i)* icon that shows up on many pages. This will open a pop-up window with more information that can be dismissed by either pressing the X or by pressing outside the pop-up window. For example, the help icon on the Home Screen will display the following information:



1-18



HW1485509

- 1 Smart Pendant
- 1.9 Startup Window

1.9 Startup Window

The YRC Controller performs an initial diagnosis when the main power is turned ON. The startup window is shown on the Smart Pendant screen.

Fig. 1-14: Startup Window



In case the Smart Pendant does not complete the startup sequence due to an error, such as YRC Controller incompatibility, an {Export Logs...} will appear. This button can be used to save internal logs to a USB storage device to aid troubleshooting by a YASKAWA Representative.



The MODE switch will not work during Smart Pendant startup. MODE switch will work once the Smart Pendant startup is complete.



- 1 Smart Pendant
- 1.10 Home Screen

1.10 Home Screen

When the YRC Controller boots up, the Home Screen displays.

Fig. 1-15: Home Screen



1-20

HW1485509

- Smart Pendant
- 1.10 Home Screen

1

The home screen contains short-cuts to three common actions for the manipulator:

| JOG/EDIT | Use this button to view the Current Job (i.e. last Job opened) for editing/programming. To use this function, the Key Switch must be switched to the MANUAL (TEACH) position. |
|----------|---|
| RUN | Use this button to view the Current Job for running. To use this function, the Key Switch must be switched to the AUTOMATIC (PLAY) position. If a job is currently running, this button will change to "View Running Job". |
| JOBS | Use this button to view a list of Jobs, choose a job to open, create a new job, lock a job, and set a Default job. |

- 1 Smart Pendant
- 1.11 Main Menu

1.11 Main Menu

The main menu is accessed by pressing on the MENU button on the top left-hand side of the interface from any screen. After pressing this button, a menu tree will scroll from the left-hand side of the screen. This tree provides access to the Main Menu Items:

Table 1-3: Main Menu Items


| Main Menu Item | Description |
|-------------------|---|
| Security | Select Security Access Level and Enter Passcode |
| Home | Home Screen shortcut |
| Job List | Shows the list of jobs saved |
| Current Job | Open the Current Job |
| Program / Operate | Contains sub-items related to programming the manipulator, such as {I/O}, {Variables} and {Variable and I/O Watch} |
| Robot Settings | Contains sub-items related to manipulator configuration such as {Tools}, {User Frames}, and {Zones} |
| Safety Settings | Contains sub-items of {Torque Sensor Calibration} and {Safety Function} which is related to limits and monitoring, such as {Axis Range Limit} and {Axis Speed Monitor}. |
| Utility | Contains sub-items such as {Limits Release}, {Brake Release}, {Force/Torque Watch} and {File Transfer} |
| Alarms | Shows the Alarm History and Alarm Descriptions |
| System Settings | Contains sub-items of {General} and {Network} |
| Help / Support | Contains a YASKAWA contact list, and screenshot |

- Smart Pendant
- 1.12 Status Bar

1.12 Status Bar

1

The Status Bar shows the YRC Controller status.



The following configuration can be accessed from the Status Bar:

1 Menu



Use this button to access the menu.

2 Tool Number



Use this control to change the current Active Tool in MANUAL (TEACH) mode. The tool numbers are from 0 to 63. In AUTOMATIC (PLAY) mode, this button is disabled.

③ Jogging Speed

Use this control to change the Jogging Speed.



Low Speed



Medium Speed



High Speed




Top Speed



- 1 Smart Pendant
- 1.12 Status Bar

④ Operation Coordinate System

The current Jogging Mode can be checked.



Jogging Mode can be switched in MANUAL (TEACH) mode for Joint Coordinates, XYZ World Coordinates, and XYZ Tool Coordinates by pressing this button. XYZ User Frame Coordinates requires a User Frame be defined to select. Hand Guiding and Smart Frame cannot be selected via the Status Bar. They can be selected on the Robot Jog panel.

⑤ Servo Status

| SERVO |
|-------|
| SERVO |
| SERVO |

Shows the status of the current servo. Color of icon is:

- Blue when the servo is OFF.
- Orange when the servo is Servo On Ready state.
- Green when the servo is ON.

6 Status LED

This section will display the indicators listed below. If none of these conditions are present, this area will be blank.

Emergency Stop



 Displays when the EMERGENCY STOP button (i.e. on Smart Pendant, YRC1000 remote button) is pressed.

Protection Stop by PFL Function

 Only for the manipulator that has PFL function which enables the human collaborative operation. Icon appears when PFL function has performed stop of motion, alerts user to reset the amber Resume Switch on the robot.



- 1 Smart Pendant
- 1.12 Status Bar



Motion Status

 This indicates that the robot is motion. This will be active during Job Execution or Jogging.

Pause Status

 This indicates that the robot is paused. This will be active after the PAUSE button is pressed during Job Execution.

⑦ Alarms

This section will display the alarm information shown below. If none of these conditions are present, this area will be blank.



Alarm Status

 shows the number of active alarms when the YRC Controller has active alarms.

Low Battery

 This alerts the user to a lower battery condition of the YRC Controller CPU battery. Contact a YASKAWA representative when this occurs.

⑧ Messages



 shows the number of messages when the YRC Controller has active messages

9 Mode



MANUAL (TEACH) mode



AUTOMATIC (PLAY) mode



REMOTE mode

- 1 Smart Pendant
- 1.13 Character Input Operation

1.13 Character Input Operation


Tap on the data or text for which characters are to be input and the software keypad will be displayed.

1.13.1 Character Input

There are two types of software keypads: alphanumeric keypads and symbol keypads. To switch between the alphanumeric and symbol keypads, tap the button on left top of the keyboard. To switch the alphanumeric keypad between upper-case and lower-case characters, tap the "Shift" key (marked with an upward arrow).

The cursor is moved by tapping {LEFT} and {RIGHT} on the top of the keypad. Close the keyboard by tapping the keyboard icon.

Fig. 1-16: Keyboard for Switching Keypads and Moving the Cursor





1-26

Alphanumeric values and symbols to be input are limited to certain content. When values cannot be input, the keys turn gray and cannot be selected.

- 1 Smart Pendant
- 1.13 Character Input Operation

1.13.2 Alphanumeric Input

Number input is performed with the Numeric Value Keypad or on the alphanumeric input keypad. Numbers include 0 to 9, the decimal point (.), the minus sign/hyphen (-), and the hash sign (#).

Tap the desired character and tap {Enter} to enter the character.

Fig. 1-17: Keyboard for Numbers and Lower-Case Characters



Fig. 1-18: Keyboard for Numbers and Upper-Case Characters

| SYMBC |)L | | < LE | FT F | RIGHT 🕨 | CLE | AR | | | • |
|-------|----|---|------|------|---------|-----|----|---|---|-------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | # |
| q | w | е | r | t | у | u | i | 0 | p | × |
| a | S | d | f | g | , h | j | k | : | E | Inter |
| Ŷ | z | x | с | v | b | n | m | - | • | ŵ |
| | | | | | space | | | | | |

1.13.3 Symbol Input

Press the {SYMBOL} on the left top of the keypad to display the symbol keypad.

Tap the desired symbol and press {Enter} to enter the symbol.

Fig. 1-19: Keyboard for Symbols



- 1 Smart Pendant
- 1.14 Numeric Value Input Operation

1.14 Numeric Value Input Operation

Press the numeric value input area to display the numeric value keypad.

Fig. 1-20: Keypad for Numeric Value



| Keypad | Key on the Smart Pendant | Description |
|---------------------|-----------------------------|---|
| Cancel | | Clears all the characters being typed and closes the numeric value keypad |
| Clear | CLEAR | Clears all the characters being typed |
| Right | RIGHT ► | Moves the cursor to the right |
| Left | | Moves the cursor to the left |
| Backspace | × | Deletes one number at the cursor position |
| Enter | Enter (Save) | Enters the input numeric values |
| Numeric keys | 0 to 9 | Inputs number |
| Decimal point | • | Enters the decimal point |
| Minus | - | Enters the minus symbol |
| Scientific notation | е | Enters "e" as the real number |

NOTE

1-28

Numeric values to be input are limited to certain content. When values cannot be input, the keys turn gray and cannot be selected.

- 1 Smart Pendant
- 1.15 Language Setting

1.15 Language Setting

Two languages can be displayed alternately.

- 1. Go to $\{HOME\} \rightarrow \{System Setting\} \rightarrow \{General\}$
- 2. Select the language from the pull-down list. The available languages are:

1-29

- English
- Japanese

Fig. 1-21: Language Setting in General Settings Screen

| | | SERV0 | P 🛆 🕿 |
|----------------------------------|---------|---------------------------------------|-------|
| ← General Sett | tings | | |
| Organization Your organizatio | on name | Date & Time 2018-03-08 05:36:41 PM | |
| Language English | ~ | | |
| <u></u> | | | |

| | The following terms cannot be translated even when the language setting is changed: |
|--------|---|
| SUPPLE | Job name that is already created |
| -MENT | Other names created |
| | – Comment |
| | |

- 1 Smart Pendant
- 1.16 Mode

1.16 Mode

Three mode selections determine control of the manipulator system. These modes are MANUAL (TEACH), AUTOMATIC (PLAY) and REMOTE. Traditionally, MANUAL is also called TEACH, and AUTOMATIC is also called PLAY.

1.16.1 MANUAL (TEACH) Mode

In MANUAL (TEACH) mode, the following actions can be performed:

- Preparation and teaching of a job
- Modification of an existing job
- Setting of various manipulators and the YRC Controller settings and configurations

In MANUAL (TEACH) mode, the user has control for jogging the manipulator. Programming, editing, customizing, and other menu choices become available based on the level of Security.

1.16.2 AUTOMATIC (PLAY) Mode

In AUTOMATIC (PLAY) mode, the following can be done.

- Playback of a taught job
- Viewing of status, variables, I/O, Job, etc.

1.16.3 REMOTE Mode

In the REMOTE mode, certain operations can be commanded by external input signals. The Software Pendant can only be used under the REMOTE mode. Refer to *chapter 12 "Software Pendant"* for more information.

1 Smart Pendant

1.17 Security Level Setting

1.17 Security Level Setting

Permissions are controlled through the Security Access Level. This allows to change the operation and settings according to the operator's level of knowledge and training. User should operate and perform tasks with appropriate security level.

1.17.1 Types of Security Level

Operation:

Users at the Operation level can operate the manipulator, but it does not allow editing jobs or changing settings. A user on this level, can start and stop jobs, repair and jog the manipulator, but cannot modify programs, variables or settings. Repairs, etc. can be performed if any abnormalities are detected. This level does not require a passcode.

Edit:

Users at the Edit level can perform teaching, manipulator job operations, editing of jobs and various robot settings, in addition to operations enabled in the Operation level. This level requires a numeric passcode consisting of 4 to 16 numbers.

Management:

In addition to the functions enabled in the Edit level, this level allows setup and maintenance of the system, setting of machine control parameters, time, changing the passcode, etc. This level requires a numeric password consisting of 4 to 16 numbers.

Safety:

In this level, an operator can edit the files related to the safety function in addition to the operations enabled in the Management level. Safety level is required to perform any functions associated with the optional Functional Safety Unit and Power & Force Limiting functions. This includes Tool Setting only for the manipulator with PFL function enabled (ex. MOTOMAN-HC10). This level requires a numeric password consisting of 9 to 16 numbers. For more details about the Safety level, refer to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY BOARD OPERATION (HW1483576)" / "YRC1000micro OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY BOARD OPERATION (HW1484544)".

Support:

The Support access level allows some additional abilities that are normally inaccessible. This aids a YASKAWA representatives in troubleshooting and addressing issues that may occur with the Smart Pendant or YRC Controller. Support can only be accessed with a onetime management passcode provided by a YASKAWA representative. The YRC Controller serial number is required to generate a valid one-time passcode, which displays on the Security Access Popup window. This access is to be used by a YASKAWA representative. Once accessed,

- 1 Smart Pendant
- 1.17 Security Level Setting

Support access will persist until the Smart Pendant or YRC Controller is restarted.

Fig. 1-22: Security Support Access

| Security Access | | |
|--|--------------------|------------|
| 🖏 Please selec | et access level: | |
| OPERATION | EDIT (current) | MANAGEMENT |
| SAFETY | SUPPORT | |
| 0 | ase enter passoo | |
| Please contact <u>Yas</u> l a one-time-manage Provide Controller S | ment support passo | ode. |
| | | SAVE |

HW1485509

1-32

- 1 Smart Pendant
- 1.17 Security Level Setting

1.17.2 Default Security Level Passcodes

Operation in **Edit**, **Management**, and **Safety level** require a passcode. The default passcodes for each security level are:

- Editing: 00000000000000 (all 0s' 16 digits)
- Managing: 9999999999999999 (all 9s' 16 digits)



- In some regions, the YRC Controller may be shipped with a randomized Safety passcode, included with the shipment.
- When entering all the same digit, the numeric key can be held to automatically repeat to the maximum of 16 digits.

Passcodes for Edit and Management levels can be customized. For details, refer to *chapter 1.17.5* "Security Level Settings".

1.17.3 Security Level Access Information

Various security levels with varying levels of system access are supported. These are summarized below:

| Items | Lowest Accessible Security Level |
|---|-------------------------------------|
| View System Status & Runtime | Operation |
| Jog Robot | Operation |
| Start/Stop Jobs | Operation |
| Simple System Reset / Repair | Operation |
| Teach Points and Edit Robot Setting | Edit |
| Edit Jobs and Variables | Edit |
| Edit Machine/Robot Control Parameters | Management |
| Edit Settings (System Time, Passcodes etc.) | Management |
| Ability to Create System Backup | Management |
| Safety Functions (FSU, PFL, Safety Logic) | Safety |

- 1 Smart Pendant
- 1.17 Security Level Setting

1.17.4 Selecting Security Level

- 1. Go to {Security: ---} under the {MENU}.
- 2. Select the desired Security Access Level from {OPERATION}, {EDIT}, {MANAGEMENT}, or {SAFETY}.

| Security Access | | |
|---|-------------------|-----------------|
| 🖏 Please selec | ct access level: | (\tilde{l}) |
| OPERATION | EDIT (current) | MANAGEMENT |
| | (current) | |
| SAFETY | SUPPORT | |
| Plea | ase enter passo | ode: |
| ø | | |
| Management acces settings (except if S | | bot and pendant |
| | × CANCE | SAVE |

3. Insert passcode, if required.

1-34

- Switching to a lower level access does not require inserting a passcode.
- 4. Tap {Enter} or {SAVE}.
 - The Security Level changes when the correct passcode is inserted.

HW1485509

- 1 Smart Pendant
- 1.17 Security Level Setting

1.17.5 Security Level Settings

1.17.5.1 Changing Passcode

The passcode for Edit and Management level can be changed. The passcode for Safety Level must be changed using Software Pendant (refer to *chapter 12 "Software Pendant"*).

- 1. Operate in Management Level or higher.
- 2. Go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{General\}$
- 3. Under {Security Level Settings}, select the security mode from the pull-down list below the "Access".

| Security Level Security | ettings | | |
|-------------------------|---------|--------------|--|
| Access Edit | ~ | SET PASSCODE | |
| Startup Level | | | |
| Edit | ~ | | |

- 4. Tap {SET PASSCODE}.
 - The entry popup appears.
- 5. Type in the current passcode and tap {Enter}.
 - The entry popup appears again if the current passcode is correct.
- 6. Type in the new passcode and tap {Enter}.
 - The passcode is now changed.

| Set Security Passcode |
|--|
| Please enter new passcode for "Edit" access |
| ~ |
| Ø |
| |
| CANCEL SAVE |
| |

- 1 Smart Pendant
- 1.17 Security Level Setting

1.17.5.2 Changing Startup Security Level

The Security Level at startup/restart can be set to Operation, Edit or Management level.

- 1. Operate in Management Level or higher.
- 2. Go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{General\}$
- 3. Under {Security Level Settings}, select the Security Level from the pull-down list under the {Startup Level}.

| Security Level S | ettings | | |
|------------------|---------|--------------|--|
| Access Edit | ~ | SET PASSCODE | |
| Startup Level | | | |
| Edit | ~ | | |

HW1485509

- 2 Manipulator Coordinate Systems and Operations
- 2.1 Control Groups and Coordinate System

2 Manipulator Coordinate Systems and Operations

2.1 Control Groups and Coordinate System


2.1.1 Control Group

For the YRC Controller, a group of axes to be controlled is called a "Control Group". The Control Group is split into two units:

- "ROBOT" moves the joints of the manipulator itself
- "BASE" moves the entire manipulator

The "BASE" is called an "external axis", and is not supported by the Smart Pendant.

Fig. 2-1: Control Group




This is an axis that moves the entire manipulator. (e.g. servo track) This axis can be linear or rotational.

- 2 Manipulator Coordinate Systems and Operations
- 2.1 Control Groups and Coordinate System

2.1.2 Types of Coordinate System

The following coordinate systems are used to operate the manipulator.

| Туре | Description |
|-----------------------------|---|
| Joint Coordinate | Allows user to move each joint axis independently. |
| XYZ - World Coordinate | Allows user to move the manipulator in Cartesian directions relative to the manipulator base. |
| XYZ - Tool Coordinate | Allows user to move the manipulator in Cartesian directions relative to the tool. The direction of the tool attached to the wrist flange of the manipulator is defined as Z-axis, and Cartesian coordinates are defined at the tip of the tool. |
| XYZ - User Frame Coordinate | Allows user to move the manipulator in Cartesian directions relative to a "user frame." |



- 2 Manipulator Coordinate Systems and Operations
- 2.2 General Operations

2.2 General Operations

2.2.1 Check Safety

Before operating the YRC Controller, read chapter 1 "Safety" of the INSTRUCTIONS of the YRC Controller. Always use caution around the manipulator system and peripherals.

2.2.2 Select Operation Mode

Set the mode switch on the Smart Pendant to "MANUAL (TEACH)".

2.2.3 Select Coordinate System

Select a coordinate system by:

- Tapping the Jog Mode on the Status Bar



Verify the selected coordinate on the status display area of the Smart Pendant.

2.2.4 Select Jogging Speed

Select the jogging speed of operation by:

Tapping the Jogging Speed on the Status Bar



- Changing the jogging speed using the Robot Jog Panel



- Pressing [FAST] and [SLOW] membrane keys

2-3



Four speeds are available for jogging speed: LOW, MID, HIGH, and TOP.



MANUAL (TEACH) mode restricts the maximum speed of both the tool center point and the flange center point to 250 mm/s.

- 2 Manipulator Coordinate Systems and Operations
- 2.2 General Operations


2.2.5 Servo ON


Before the manipulator can be moved in MANUAL (TEACH) mode or AUTOMATIC (PLAY) mode, the servos must be turned ON. This can be accomplished by:

Pressing the {SERVO} on the Status Bar



If the system is in AUTOMATIC (PLAY) mode, the servos will turn ON.





2-4

HW1485509

- 2 Manipulator Coordinate Systems and Operations
- 2.3 Operation Check for Emergency Stop Buttons

Once servos' power is turned ON in MANUAL (TEACH) mode, jogging operations on the robot can be performed. Jogging can be accomplished using various methods in different coordinate frames. These are described in *chapter 2.4 "Coordinate Frames and Manipulator Jogging"*.

2.3 Operation Check for Emergency Stop Buttons

Before operating the manipulator, perform the following operations to ensure the Emergency Stop buttons on both the YRC Controller (some models do not have this button) and Smart Pendant are functioning correctly.

- 1. Press the {SERVO} on the touch screen.
 - The {SERVO} turns orange when the servo power supply is turned ON.
- 2. Press Emergency Stop button.
 - The Emergency Stop button is on the YRC1000 (some models do not have this button) or the Smart Pendant.
- 3. Confirm servo power is turned OFF
 - When the Emergency Stop button is pressed and the servo power is turned OFF, the {SERVO} will be deactivated (grayed out).
 - After confirming the step above, turn the Emergency Stop button to release it.
- 4. Press {SERVO} on the touch screen again, and grip the Enable Switch.
 - The servo power can be turned ON by gripping the Enable Switch when the {SERVO} is in orange. The {SERVO} will turn to green and the [SERVO] status LED will turn ON. Verify that servo power turns off when the Enable Switch is released or when the Enable Switch is squeezed tightly as described in *chapter 2.2.5 "Servo ON"*.



When the Smart Pendant (JZRCR-APP30-1) is used, the Emergency Stop output signals (ESPOUT1 & ESPOUT 2) do not interface with the Smart Pendant's Emergency Stop button. Therefore, when configuring a safety circuit externally using the Emergency Stop output, confirm safety beforehand and make it an appropriate circuit configuration. Refer to *chapter 1.7.7 "Emergency Stop Output"* for further detail.

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4 Coordinate Frames and Manipulator Jogging

A manipulator can be jogged in MANUAL (TEACH) mode using different methods supported by the Smart Pendant. The various jogging modes can be selected using three different controls:

- {Operation Coordinate System} on Status Bar
- {Mode} on Robot Jog panel
- [Jog Mode] membrane key (can be used only for Joint, World, Tool, User and Hand Guiding mode selection)

Fig. 2-2: Changing Jogging Mode



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

All jogging modes have the following items in common on the Robot Jog panel.

| ● Mode Joint J≥ ~ | Tool 3 #0: Vacuum | ~ |
|----------------------|----------------------|--------------------------------|
| 0 | 4 BLOCK I/O: TOOL #0 | 5 |
| Speed | | Motion Command Not Selected |

① Jogging Mode

- Control for selecting jogging mode (MANUAL (TEACH) mode).

② Jog Speed

 Control for selecting robot jogging speed (MANUAL (TEACH) mode). The user can select one of four different speeds

③ Active Tool

 Control to select the active tool. The active tool stores physical parameters (input by the user) that are often critical to proper operation

④ Block I/O for Tool

 Control used to toggle between user-defined ON & OFF Block I/O states for the active tool. The ON/OFF states are configured on the Block I/O screen

5 Current Axis Status Panel

 Panel with interactive indicator bars that visually display the position of each axis

6 GO TO POINT Button

 Control for moving the robot to programmed points in a job file. The user can highlight a "Move" command on the Job Contents view above the Robot Jog panel. Then press and hold the {GO TO POINT} to move to that command. An accompanying message will be displayed to the right of this button.

The following sections provide more detail on the different jogging modes and the coordinated systems they represent.

2

Manipulator Coordinate Systems and Operations


2.4 Coordinate Frames and Manipulator Jogging

2.4.1 Smart Frame Mode

Use of Smart Pendant in an area with strong geomagnetic disturbance or around metal objects (such as wire fences or steel frames) may result in manipulator motion directions not matching Smart Frame jogging directions.

Smart Frame Mode makes Cartesian jogging more intuitive to the user. In this mode, the manipulator moves in Cartesian directions relative to the position of the Smart Pendant with respect to the robot base. There are two panels in this mode as shown in *fig. 2-4 "Smart Frame Panel"* : ① Robot and ② Tool.

Fig. 2-4: Smart Frame Panel



① Robot Panel

This panel can be used to jog the position of the Robot TCP in directions relative to the Smart Pendant using the {LEFT}, {RIGHT}, {TOWARD}, {AWAY}, {UP} and {DOWN}. For example, pressing the {LEFT} will always move the robot in the left direction relative to the Smart Pendant even as the position of the Smart Pendant changes.

2 Tool Panel

This panel can be used to jog the orientation of the Robot TCP as well as move/rotate it along the TCP Z direction. To jog the orientation, press and hold the {ROTATE} and then tilt the Smart Pendant in the desired directions of orientation.

2-8

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

Fig. 2-5: Smart Frame Orientation



Table 2-1: Smart Frame Tool Buttons


| Tool Button | Description |
|--------------------|---|
| Ŕ | Move robot TCP in +Z direction with respect to Tool Frame |
| Ŕ | Move robot TCP in -Z direction with respect to Tool Frame |
| R | Rotate robot TCP around +Z Tool Frame axis (+Rz) |
| Ŕ | Rotate robot TCP around -Z Tool Frame axis (-Rz) |

The Robot/Tool Toggle button in the middle of the screen can be used to flip the Robot/Tool Panels to the other side.

HW1485509


- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

Fig. 2-6: Robot/Tool Toggle




Additionally, the membrane [Jog Keys] can be used for Joint Axis jogging in Smart Frame Mode.

Each time the YRC Controller is turned off, Smart Frame will lose its calibration. This calibration is used to align the frame of the pendant to the base of the manipulator. For Smart Frame to accurately determine left, right, etc. directions, it must be calibrated.



To calibrate, the operator holding the pendant should stand facing the front of the robot and press the {CALIBRATE}. The calibration procedure can be repeated at any time if the robot TCP motion does not reflect the operator's physical position.

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging







2-11

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

The robot can be in any position for sensor calibration.

- 1. Hold the Smart Pendant and stand facing the front of the robot.
 - The top edge of the Smart Pendant must be held parallel to the base of the manipulator.
- 2. Press {CALIBRATE} in the Smart Frame,

| Mode Smart Frame 🔔 🗸 🔶 🕧 | Tool <u>#0: LL </u> |
|-----------------------------|--|
| 🔅 CALIBRATE | BLOCK I/O: TOOL #0 |
| Speed | GO TO POINT Motion Command Not Selected |

- After the calibration completes:
 - {CALIBRATE} shows a check mark

• pendant angle shows next to the heading indicator graphic..

| Mode Smart Frame 🛓 💉 存 | Tool #0: LL <u>~</u> (j) |
|---------------------------|--|
| | () BLOCK I/O: TOOL #0 |
| Speed | GO TO POINT Motion Command Not Selected |

To aid with accurate jogging, the jogging directions can be locked to the Manipulator-frame axis directions.

• Toggle axis-locked and free jogging by clicking the angle indicator.



When axis-locked, the indicator circle shows four quadrants and will snap to the directions -90, 0, 90, and 180 degrees.



2-12

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.2 Joint Mode


When the manipulator is operating in Joint Mode, each axis of the manipulator can be moved independently.


Axis Operation in Joint Mode

SUPPLE

When two or more [Jog Keys] are pressed at the same time on the membrane key, the manipulator performs a combined movement. However, if two different directional keys for the same axis are pressed at the same time (such as [S-] + [S+]), this axis will not operate. The touch screen {Jog Keys} only operate one button at a time.







| S Swing 0.00 ° | + ^s | R Rotate | 0.00 ° | + R |
|-------------------|----------------|----------|--------|----------------|
| L Lower Arm | + " | B Bend | 0.00 ° | + ^B |
| U Upper Arm | + | T Twist | 0.00 ° | + |


2-13

HW1485509

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.3 XYZ - World Mode

In the XYZ – World mode, the manipulator moves parallel to the X, Y, or Z axes defined with respect to the manipulator base.








Fig. 2-11: Programming Panel of Robot Jog Panel for XYZ – World Mode



2-14

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.4 XYZ - Tool Mode

In XYZ – Tool mode, the manipulator moves parallel to the X-, Y-, and Zaxes defined with respect to the tip of the tool.

Axis Operation in the XYZ - Tool Mode

When two or more [Jog Keys] are pressed at the same time on the membrane key, the manipulator performs a combined movement. However, if two different directional keys for the same axis are pressed simultaneously (such as [X-] + [X+]), this axis will not operate. The touch screen {Jog Keys} only operate one button at a time.

Fig. 2-12: XYZ-Tool Mode Operation

SUPPLE





Fig. 2-13: Programming Panel of Robot Jog Panel for XYZ – Tool Mode




The tool coordinates are defined at the tip of the tool, assuming the effective direction of the tool mounted on the manipulator's tool flange is the Z-axis. Therefore, the tool coordinates axis direction moves with the wrist.

2-15

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

In tool coordinates, the manipulator can be moved using the effective tool direction as a reference, regardless of the manipulator's position or orientation. These motions are best suited for moving the manipulator parallel to the tool frame while maintaining tool orientation with respect to the workpiece.





To use the tool frame, the tool file must be registered in advance. For further details, refer to *chapter 6.1 "Tool Settings*".

2.4.4.1 Selecting Tool

Tool numbers are allocated to tools. When two or more tools are used in the system, each tool is allocated a tool number. User can then select the desired tool number from tools.

1. Select {XYZ -Tool} for Jogging Mode.

2-16



 Select desired tool number. For more information on the tool setting, refer to *chapter 6.1 "Tool Settings"*.

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.5 XYZ - User Frame Mode


In XYZ – User Frame mode, the manipulator moves parallel to each axis of the user-defined coordinates. A user-specified coordinate frame is typically attached to an object such as a work surface, pallet, or conveyor. The user defines the X, Y, and Z axes with the desired slopes and positions available within the manipulator's motion range. Up to 63 user frames, each of which is registered with a unique number, can be configured.

Axis Operation in the User Frame Mode

SUPPLE m -MENT Sa th

When two or more [Jog Keys] are pressed at the same time on the membrane key, the manipulator performs a combined movement. However, if two different directional keys for the same axis are pressed simultaneously (such as [X-] + [X+]), this axis will not operate. The touch screen {Jog Keys} operate only one button at a time.

Fig. 2-14: Programming Panel of Robot Jog Panel for XYZ – User Frame Mode



2.4.5.1 Selecting User Frame

- 1. Select {XYZ User} for Jogging Mode
- 2. Select the desired User Frame number.

2 - 17





To enable the user frame function, the User Frame must be configured before selecting User Frame mode. For further detail, refer to *chapter 6.3 "User Frames"*.

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.6 Hand Guiding Mode

Hand Guiding mode can be used on manipulators that have the PFL (Power and Force Limiting) function for human collaborative operation (ex. MOTOMAN-HC10) only. In this mode, the user can directly position the Manipulator by physically moving the arm by hand.

To use the Hand Guiding mode, set and verify the following:

- Verify PFL function is ON. The Collaborative Operation LED (green lamp) on the manipulator (ex. on the wrist for MOTOMAN-HC10) is turned ON when PFL function is ON/Enabled.
- Tool is correctly configured. Refer to chapter 6.1 "Tool Settings".
- Current tool number matches with the currently attached tool. Check the Status Bar for the tool number.
- Jogging Speed is on High initial speed setting can be changed for accuracy and ease of motion.

There are three sub-modes in Hand Guiding mode:

- ALL JOINTS
- TOOL JOINTS
- XYZ+TOOL

When Hand Guiding mode is entered, the message shown in *fig. 2-15 "Low Speed for Hand Guiding"* will appear. In Low Speed, the robot can be difficult to move with Hand Guiding (especially for large motions) and can cause alarms if pressed too hard. Select {CHANGE TO HIGH SPEED} to change the jogging speed or select {DISMISS} to remain in Low Speed.





Fig. 2-15: Low Speed for Hand Guiding






- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.6.1 ALL JOINTS

In this mode, all axes of the robot can be guided by hand. This mode is most useful for large motions and recovering from faults / collisions.

Fig. 2-16: Hand Guiding with All Joints



2.4.6.2 TOOL JOINTS

In this mode, the three axes on the wrist (R, B, T) of the robot can be moved by hand. This mode can be used to modify the tool orientation.

Fig. 2-17: Hand Guiding with Tool Joints

2-19



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.6.3 XYZ + TOOL

In this mode, the robot can be guided in the X, Y, Z directions by hand. This is the most useful mode for teaching robot positions. The tool axis of the robot (T-axis) can also be rotated to orient the tool.

Fig. 2-18: Hand Guiding with XYZ + Tool

2-20



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.7 Motion at Robot TCP

For motion at the TCP (Tool Center Point), the manipulator's posture can be modified without changing the position of the tool's tip (TCP). The motion at TCP is available in the World Coordinate Frame, Tool Coordinate Frame, and User Coordinate Frame.

The motion of each axis is described in the table below.


Table 2-2: Axis Motion in Motion at TCP

| Axis | Axis Operation Key | Motion |
|------------|--------------------|--|
| Wrist Axes | + Rx - | Only the tool's posture changes with the TCP fixed. The tool's posture changes around the axes of the specified coordinates. |
| | + Ry - Ry | |
| | + Rz - Rz | |


Turning of each wrist axis differs in each coordinate system.

2-21

 In World Frame, wrist axis rotations are based on the X, Y, and Z axes of the manipulator.




- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging
 - In Tool Frame, wrist axis rotations are based on the X, Y, and Z axes of the tool coordinates.



Y-axis

 In User Frame, wrist axis rotations are based on the X, Y, and Z axes of the user coordinates.



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.8 Move to Position Panel

The Move to Position Panel is a utility that can be used to more precisely position a robot while jogging. This feature will let the user enter the desired position and jog directly to the entered coordinates as well as "snapping" the positions for accurate alignment.


There are three separate panels which will be described in the following sections:

- Joint Panel
- TCP Position Panel
- TCP Orientation Panel.

2.4.8.1 Joint Panel

The Joint Panel can be used whenever the Jogging Mode is set to Joint. To open the Joint Panel, press any of the joint positions on the screen:

Fig. 2-19: Move to Position Panel (Joint Mode)



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

Fig. 2-20: Joint Position Panel



① Current Axis Position display

② **Target Position Selection/Display** - By default, this value is the "User Target" which allows for entering custom positions. The drop-down selection contains standard robot configurations such as Work Home and Robot Position Confirmation.

NOTE

To change/configure these positions, refer to *chapter 6.6 "Robot Configuration Positions"*.

③ **Move to individual axis** - Each button jogs the specific axis to its target position. The button has an orange border if the Current Position of the axis is not equal to Target Position of the axis (e.g. S-Axis in *fig. 2-20*).

④ Speed Jogging Selection

2-24

(5) **Snap to Position** - This will "snap" each axis to the nearest 10 degree increment. For example, the L-axis value above (33.404 degrees) would snap to 30.000 degrees.

6 **Move to Position button** - This will move all axes towards their target. This button will have an orange border if any the Current Position of any axis is not equal to it's Target Position.

- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging


2.4.8.2 TCP Position Panel

The TCP Position Panel can be used whenever the Jogging Mode is set to XYZ-World, XYZ-User, or XYZ-Tool. To open it, press any of the TCP XYZ positions on the screen:

Fig. 2-21: Move to Position Panel (XYZ-World)



Fig. 2-22: TCP Position Panel



① Current XYZ Position display.

② **Target XYZ Position display** - The target X, Y, or Z position can be entered into the text fields.

③ Jogging Speed Selection

Snap to Position - This "snaps" each coordinate to the nearest
 mm increment. For example, the Y value is above (7.834 mm) it will snap to 10.000 mm.

(5) **Move to Position button** - This moves the robot towards the target X, Y, or Z position. These buttons will have an orange boarder if any of the Current X, Y, or Z Positions do not match the target X, Y, or Z Positions.



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

2.4.8.3 TCP Orientation Panel

The TCP Orientation Panel is used whenever the Jogging Mode is set to XYZ-World, XYZ-User, or XYZ-Tool. To open the TCP Orientation Panel, press any of the TCP Rx, Ry, or Rz positions on the screen.

Fig. 2-23: Move to Position Panel (XYZ-World)




Fig. 2-24: TCP Orientation Panel

| Curre | U | Turg | et ② | | |
|-------|------------|----------|-------------------|--|--|
| Rx | 0.445 ° | Rx | 0.445 ° | | |
| Ry | -89.290 ° | Ry | -89.290 ° | | |
| Rz | -179.689 ° | Rz | -179.689 ° | | |
| Speed | | <u> </u> | nap to Position ④ | | |
| | | | MOVE TO POSITION | | |
| | | | 5 | | |

① Current RxRyRz Position display

2-26

② **Target RxRyRz Position display** - The target Rx, Ry, Rz positions can be entered into the Text Fields.

③ Jogging Speed Selection

④ **Snap to Position** - This "snaps" each rotation to the nearest five degree increment. For example, if the Ry value is above (-89.920 degrees) it will snap to -90.000 degrees.



- 2 Manipulator Coordinate Systems and Operations
- 2.4 Coordinate Frames and Manipulator Jogging

5 **Move to Position button** - This moves the robot towards the target Rx, Ry, Rz positions. These buttons will have an orange boarder if any the Current Rx, Ry, Rz positions do not match the target positions.

- 3 Managing Jobs
- 3.1 Preparation for Teaching

3 Managing Jobs

This section explains how to manage jobs without moving the manipulator. Copying, deleting, and modifying jobs can only be done in MANUAL (TEACH) mode.



Edit operations on a job are restricted if an edit lock is applied to the job. Refer to *chapter 3.5.5 "Setting Edit Lock"* for details on an edit lock.

3.1 Preparation for Teaching

To ensure safety, the following operations should always be performed before teaching:

- 1. Check the Emergency Stop buttons to be sure they function properly.
- 2. Set the mode switch to "MANUAL (TEACH) Mode".
- 3. Create a job.

3.1.1 Create New Job

Follow the steps to create a new job:

- 1. Set the mode switch to MANUAL (TEACH) mode.
- 2. Go to {Job List} under {MENU}, or {JOBS} on the home screen.
- 3. Tap {+NEW JOB} at the top of the Job List screen.

3-1

- A job named "NEWJOB1" is automatically created and selected.

• The job settings (e.g. Job Name, Comment, Tag) can be edited from the Detail Panel at the bottom of the screen.

| Job Details: NEWJOB1 | | ~ |
|-----------------------------|-----------------------------------|--------|
| Date 2019-07-11 01:10 AM | Lines 2 | |
| | | |
| Job Name | Туре | |
| NEWJOB1 | Robot Job | \sim |
| Tag | Controlling | |
| e.g. job tag or keyword | Robot 1 | \sim |
| Comment | 🔲 < Make this job the Default Job | |
| e.g. comment about the job | Lock the job to disable editing | |
| Additional Settings | | ^ |
| 리 DELETE 다 DUPLICATE | | |
| | | |
| | | |

- 3 Managing Jobs
- 3.1 Preparation for Teaching

3.1.1.1 Setting the Job Name

The following rules apply to the job name:

- 1 to 32 alphanumeric characters can be used.
- Job names may be written with numerals only.
- Only upper-case letters can be used for alphabets.
- Symbols include: !, &, (,), ', and _. Space cannot be used for a job name. Use an underscore (_) instead.
- Different types of characters can coexist within the same job name.
- If the job name is already used, an input error will occur.

<Examples>

001

JOB-1

WORK_A

3.1.1.2 Setting the Tag

The tag can be used to specify a group or category for a job. Sorting by tag can help see all jobs in a certain group/category. For example, if a job is tagged by workpiece name, or operator's name, they will be grouped together when sorting by tag name is used. Enter an optional tag value. Constraints on tag name are:

- 0 to 32 alphanumeric characters can be used.
- Letters can only be entered in upper-case.
- Only the underscore (_) and dash () can be used as a symbol.
- 1. Insert a tag.
 - For information on character input operation, refer to *chapter 1.13 "Character Input Operation"*.
- 2. Press {ENTER}.

- 3 Managing Jobs
- 3.1 Preparation for Teaching

3.1.1.3 Setting the Comment

Comments are a means to provide description about the Job's purpose. Constraints on comment are:

- 0 to 32 alphanumeric and symbol characters can be used.
- Symbols that are not grayed out can be used.
- 1. Insert a comment.

For information on character input operation, refer to chapter 1.13.

2. Press {ENTER}.

To finish the setting, press the {Create Job}.

3-3



Up to 10000 instructions can be registered per JOB. (Including "Start Job" and "End Job", line 1 to 10000).

- 3 Managing Jobs
- 3.2 Job List

3.2 Job List

3.2.1 Default Job and Current Job

In the Job List, there are two specially designated jobs:

Default Job

The job designated as the default job can be opened and executed from external I/O signals. It is designated with a green "Check Mark" in the Attributes column and displays in bold font.


- Current Job

The last job that was opened. It is a useful shortcut back to the most recent job the user was editing. It is designated with a "robot" icon in the Attributes column and displays in orange font.

Fig. 3-1: Default Job and Current Job

| ← Job List | (+) NEW | JOB Sear | ch by name | Q |
|--------------|---------|---------------------|------------|-----|
| Job Name | Tag 🜲 | Edited | Attributes | (1) |
| CAMERA | | 2019-07-11 01:16 AN | <u>Mc</u> | |
| PICKANDPLACE | | 2019-07-11 01:17 AM | 1 😔 | |
| ARM | | 2019-07-11 01:18 AN | r - | |
| PERFTEST | | 2019-07-03 05:22 AN | E. | |
| SAMPLE | | 2019-06-29 03:40 AN | E. | |
| TEST | | 2019-06-27 04:30 AM | | |

- When creating a new job, the new job will become the current job.
- When duplicating a job, the newly created duplicate will become the current job.
- When deleting a current job, the default job will become the current job.



- 3 Managing Jobs
- 3.2 Job List

3.2.2 Sorting Job

In the Job List, jobs can be sorted according to:

- Job Name
- Tag
- Edited date

To sort items, press the title of the item and the sorting order symbol will appear. Tap it again to flip the sorting order.

| | 1 JE SERVO | E 2 |
|------------|------------|---------------------|
| ← Job List | (NEW JOB | Search by name Q |
| Job Name | Tag \$ Ed | ited 🛊 Attributes 🥧 |

3.2.3 Searching Job

In the Job List, a job can be searched for using the search field. Type in the Job Name (or part of the Job Name) to search for it from the Job List.

| | S | L | | SER | vo | | F | 2m |
|----------|----------|---|-----|-----|--------|---|----------------|------------|
| ← Job L | list | | | | V JOB | | Search by name | Q |
| Job Name | | | Tag | • | Edited | ¢ | Attributes | <i>(i)</i> |

- 3 Managing Jobs
- 3.3 Copying Jobs

3.3 Copying Jobs

This operation is used to copy existing jobs, which are then used to create new jobs. It can be performed in the Job List.

On the Job List, select the job to be copied from the list.

- 1. Select {Job List} under {MENU}
 - The Job List appears.
- 2. Highlight the job to be copied.
- 3. Press {DUPLICATE} on the Job Details panel.
 - The duplicated job will be displayed on the Job List.
 - The job is named with "-COPY" at the end of the original job name.

Fig. 3-2: Copying Jobs

| Job Details: SAMPLE | | \sim |
|---------------------------------------|--|--------|
| Date 2017-07-19 10:01 AM | Lines 3 | |
| Job Name SAMPLE | Type Robot Job | |
| Tag e.g. job tag or keyword | Controlling Robot 1 ~ | |
| Comment e.g. comment about the job | □ S Make this job the Default Job □ ⊕ Lock the job to disable editing | |
| Additional Settings | | ^ |
| | EDIT DIT | |



There is a maximum of ten copies for the same job. If the limit has already been reached, duplication will fail, and show an error message. Job names have a 32 character limit. If the job name is

longer than that, it will be shortened to 32 characters. If a job with that shortened name already exists, the duplication will fail and show an error message.

- 3 Managing Jobs
- 3.4 Deleting Jobs

3.4 Deleting Jobs

This operation is used to delete jobs from the YRC Controller. It can be performed from the Job List.

From the Job List, select the job to be deleted from the list of registered jobs.

- 1. Select {Job List} under {MENU}.
 - The Job List will appear.
- 2. Select the job from the list to delete it.
- 3. Press {DELETE} in the Job Details panel.
 - A confirmation pop-up window will appear.

Fig. 3-3: Deleting Jobs

| Job Details: SAMPLE | | \sim |
|----------------------------|--------------------------|-------------|
| Date | Lines | <i>(i)</i> |
| 2017-07-19 10:01 AM | 3 | |
| Job Name | Туре | |
| SAMPLE | Robot Job | ~ |
| Tag | Controlling | |
| e.g. job tag or keyword | Robot 1 | ~ |
| Comment | 🔲 🔗 Make this job the De | efault Job |
| e.g. comment about the job | Lock the job to disal | ole editing |
| Additional Settings | | ^ |
| | | |
| 📋 DELETE | EDIT | RUN |
| | | |

4. Press {DELETE}.



3-7

- 3 Managing Jobs
- 3.5 Modifying Job

3.5 Modifying Job

This operation is performed to modify a job that has already been created. The operation is performed from the Job List.

From the Job List, select the job to be modified.

- 1. Select {Job List} under {MENU}.
 - The Job List will appear.
- 2. Select the job to modify.
 - The Job Details will appears as shown below.

Fig. 3-4: Modifying Job

| | SEF | RVO |) | | Ē | 1 2 |
|--------------------------------|-------|------------------|-----------|---------------|--------------|--------------|
| ← Job List | + NE | EW JOB | | Search | n by name | Q |
| Job Name 🔺 | Tag 븆 | | Edited 🛊 | | Attributes | † (i) |
| LONGJOB | | | 2017-07-1 | 9 08:54 AM | | |
| IFTHEN | | | 2017-07-1 | 9 08:56 AM | | |
| SAMPLE | | | 2017-07-1 | 9 10:01 AM | 2 | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| Job Details: SAMPLE | | | | | | \sim |
| Date 2017-07-19 10:01 AM | | Lines 3 | | | | |
| Job Name | | Туре | | | | |
| SAMPLE | | Robot | Job | | | ~ |
| Tag e.g. job tag or keyword | | Control Robot | | | | ~ |
| Comment | | | Make th | is job the De | fault Job | |
| e.g. comment about the job | | 6 | Lock t | ne job to dis | able editing | |
| Additional Settings | | | | | | ^ |
| | | -2- | EDIT | 18 | > RUN | |
| | | | EDIT | | > RUN | |

- 3 Managing Jobs
- 3.5 Modifying Job

3.5.1 Modifying Job Names

- 1. Tap on the Job Name.
- Fig. 3-5: Modifying Job Names

| Job Details: SAMPLE | | \sim |
|---------------------------------------|--|--------|
| Date 2017-07-19 10:01 AM | Lines 3 | (i) |
| Job Name SAMPLE | Type Robot Job | |
| Tag e.g. job tag or keyword | Controlling Robot 1 | |
| Comment e.g. comment about the job | □ ▷ Make this job the Default Job □ □ □ Lock the job to disable editing | |
| Additional Settings | | ^ |
| Delete D duplicate | | |

- 2. Edit using the alphanumeric keypad.
- 3. Press {Enter} on the keypad.

For detail on Job Names, refer to chapter 3.1.1.1 "Setting the Job Name".

3.5.2 Modifying Tag

- 1. Tap on the Tag.
- Fig. 3-6: Modifying Tag

| Job Details: SAMPLE | | |
|----------------------------|---------------|-----------------------|
| Date | Lines | |
| 2017-07-19 10:01 AM | 3 | |
| Job Name | Туре | |
| SAMPLE | Robot Job | ~ |
| Tag | Controlling | |
| e.g. job tag or keyword | Robot 1 | ~ |
| Comment | 🔲 🔗 Make this | ; job the Default Job |
| e.g. comment about the job | | ob to disable editing |

2. Edit using the alphanumeric keypad.

3-9

3. Press {Enter} on the keypad.

For details on Tag, refer to chapter 3.1.1.2 "Setting the Tag".

- 3 Managing Jobs
- 3.5 Modifying Job

3.5.3 Modifying Comment

1. Tap on the Comment

Fig. 3-7: Modifying Comment

| Job Details: SAMPLE | | \sim |
|---------------------------------------|------------------------|--|
| Date 2017-07-19 10:01 AM | Lines 3 | |
| Job Name SAMPLE | Type Robot Job | ~ |
| Tag e.g. job tag or keyword | Controlling Robot 1 | ~ |
| Comment e.g. comment about the job | - | job the Default Job bb to disable editing |

2. Edit using the entry popup.

3. Press {Enter} on the keypad.

For details on Comment, refer to chapter 3.1.1.3 "Setting the Comment".

3.5.4 Setting Default Job

The Default Job is a job specially designated so that can be triggered by an external I/O signal. There can only be one Default Job per YRC Controller. It will be shown in the Job List. The Default Job cannot be deleted. However, another job can be set as the new Default Job.

Fig. 3-8: Setting Default Job

| Job Details: SAMPLE | | \sim |
|---------------------------------------|------------------------|--|
| Date 2017-07-19 10:01 AM | Lines 3 | (i) |
| Job Name SAMPLE | Type Robot Job | ~ |
| Tag e.g. job tag or keyword | Controlling Robot 1 | Y |
| Comment e.g. comment about the job | | ob the Default Job b to disable editing |

- 3 Managing Jobs
- 3.5 Modifying Job

3.5.5 Setting Edit Lock

The Edit Lock function is used to prevent accidental editing of the Job Contents or its name, tag or comments. Attempting to edit a job when "Lock the Job" is checked will result in a notice asking to unlock the Job. The Edit Lock function can be used in Management Level or higher.

Fig. 3-9: Setting Edit Lock

| Job Details: SAMPLE | | \sim |
|---------------------------------------|------------------------|--|
| Date 2017-07-19 10:01 AM | Lines 3 | () |
| Job Name SAMPLE | Type Robot Job | ~ |
| Tag e.g. job tag or keyword | Controlling Robot 1 | ~ |
| Comment e.g. comment about the job | | job the Default Job ob to disable editing |

3.5.6 Accessing Job Details

Job Detail panel and Additional Settings panel (refer to *chapter 3.6 "Additional Settings"*) can also be accessed from the Job Contents view. Press {ROBOT JOB} on the Job Contents view to open the Job Detail panel and Additional Settings panel for the Current Job.

Fig. 3-10: Job Contents View

3-11

| | SERVO | F 2 |
|----------------------------|-----------|-----|
| လို့နဲ့ ROBOT JOB - SAMPLE | ← → ※ ① L | |
| 1 Start Job | | |
| 2 JointMove Speed=50.00(%) | | \$ |
| 3 End Job | | |

- 3 Managing Jobs
- 3.6 Additional Settings

3.6 Additional Settings

The Additional Settings can be accessed from Job Details panel. Refer to *chapter 4.8 "Local Variables"* and *chapter 4.9 "Teaching Coordinate"* for more information.

| Job Details: SAMPLE | | \sim |
|---------------------------------------|---|------------|
| Date 2017-07-19 10:01 AM | Lines 3 | <i>(i)</i> |
| Job Name SAMPLE | Type Robot Job ~ | |
| Tag e.g. job tag or keyword | Controlling Robot 1 ~ | |
| Comment e.g. comment about the job | □ 🔊 Make this job the Default Jo □ 🔒 Lock the job to disable editir | |
| Additional Settings | | ^ |


- 4 Teaching
- 4.1 Teaching Operation

4.1 Teaching Operation

4.1.1 Job Contents View

Teaching is conducted in the Job Contents view. The Job Contents view contains the following items:

Fig. 4-1: Job Contents View




A. Line Numbers

The number of the job line is automatically displayed. Line numbers are automatically updated, if lines are inserted or deleted.

B. Cursor

The cursor for manipulator control. For test operation, the manipulator motion starts from this cursor point.

C. Instructions, Additional Items, Comments, Etc.



Instructions: These are the instructions needed to process or perform an operation. In the case of Motion instructions, the instruction corresponding to the interpolation type is automatically displayed at the time the position is taught.

Additional items: Speed and time are set depending on the type of instruction. When required, numerical or character data is added to the condition-setting tags. For a full list of supported instructions and parameters, refer to YRC1000/YRC1000micro SUPPLEMENTAL INSTRUCTIONS FOR Smart Pendant (INSTRUCTIONS FOR INFORM LANGUAGE) (HW1485511).



- 4 Teaching
- 4.1 Teaching Operation

4.1.2 Jogging the Robot for Teaching

Before teaching and recording a Robot motion in the INFORM job, the Robot needs to be moved to the position of interest. This motion is manually performed by the operator using any of the methods described in *chapter 2.4 "Coordinate Frames and Manipulator Jogging"*.

4.1.3 Motion Type (Interpolation Type)

Interpolation type determines the path along which the manipulator moves between playback steps. **Play speed** is the rate at which the manipulator moves.

Normally, the **position data, interpolation type** and **play speed** are registered together for a Robot motion step.

4.1.3.1 Joint Interpolation

Joint interpolation is used when the manipulator does not need to move in a specific path toward the next step position. When the joint interpolation is used for teaching a Robot motion, the instruction is JointMove. Use joint interpolation to teach the first step. This will avoid unintentional motion errors in the singularity posture at the beginning of the motion.

Play Speeds are indicated as percentages of the maximum rate of joint speed.

4.1.3.2 Linear Interpolation

When the manipulator TCP moves in a straight line path from one taught step to the next, it is described as linear interpolation. When linear interpolation is used to teach a Robot motion, the instruction to use is LinearMove. The manipulator will move automatically while changing the wrist position as shown in the figure below.

Play Speeds are indicated as mm/sec of the TCP speed. The maximum TCP speed is manipulator dependent.

4.1.3.3 Circular Interpolation

When the manipulator TCP moves in an arc that passes through three points, the movement is described as a circular interpolation. When circular interpolation is used for teaching a Robot motion, the instruction to use is CircleMove.


Play Speeds are indicated as mm/sec of the TCP speed. The maximum TCP speed is manipulator dependent.




- 4 Teaching
- 4.1 Teaching Operation

Single Circular Arc

When a single circular movement is required, teach the circular interpolation for three points, P1 to P3, as shown in the following figure. If joint or linear interpolation is taught at P0, the point before starting the circular operation, the manipulator will move from P0 to P1 in a straight line.





Continuous Circular Arcs

When two or more successive circular movements with different curvatures are required, the movements can be continuously performed by adding an "FPT (Final Point)" tag to the step whose curvature needs to be changed.




Table 4-2: Interpolation Type for Continuous Circular Arcs

If not adding a "FPT" tag, successive circular movements must be separated from each other. Do this by adding joint or linear interpolation step (P4) at a connecting point of the preceding movement and the following movement. However, when steps at the same connecting point are taught, movements cannot be continuously performed. For more information on the "FPT" tag, refer to YRC1000/YRC1000micro SUPPLEMENTAL INSTRUCTIONS FOR Smart Pendant (INSTRUCTIONS FOR INFORM LANGUAGE) (HW1485511).

4-3

4.1 **Teaching Operation**

| | Point | Interpolation Type | Instruction |
|----------------------------|----------------|-----------------------|-------------------------|
| Joint or linear | P0 | Joint or Linear | JointMove LinearMove |
| P2 motion type P3 P7 P8 | P1 P2 P3 | Circular | CircleMove |
| P0 P1 (P4) P5 | P4 | Joint or Linear | JointMove LinearMove |
| P6 | P5 P6 P7 | Circular | CircleMove |
| | P8 | Joint or Linear | JointMove LinearMove |

| Table 4-3: Interpolation | Type for | Continuous | Circle Curve |
|--------------------------|----------|------------|--------------|
| , | 21 | | |

<Play Speed>

- The play speed set display is identical to that for the linear interpolation.
- The speed taught at P2 is applied from P1 to P2. The speed taught at P3 is applied from P2 to P3.
- If a circular operation is taught at high speed, the actual arc path will have a shorter radius than that taught.

4.1.3.4 Spline Interpolation

When performing operations such as welding, cutting, and applying primer, using the spline interpolation simplifies the teaching process for workpieces with irregular shapes. The path of motion is a parabola passing through three points. When spline interpolation is used for teaching a robot motion, the instruction to use is SplineMove.

Single Spline Curve

When a single spline curve movement is required, teach the spline interpolation for three points, P1 to P3, as shown in the figure below. If joint or linear interpolation is taught at point P0, the point before starting the spline interpolation, the manipulator moves from P0 to P1 in a straight line.


| P2 | | Point | Interpolation Type | Instruction |
|-----------------------|-------|----------------|-----------------------|-------------------------|
| Automatically becomes | N | P0 | Joint or Linear | JointMove LinearMove |
| a straight line. | P3 P4 | P1 P2 P3 | Spline | SplineMove |
| P0 P1 | P3 P4 | P4 | Joint or Linear | JointMove LinearMove |


Table 4-4: Interpolation Type for Single Spline Curve

4.1 Teaching Operation

Continuous Spline Curves

This describes a manipulator moving through a path created by combining parabolic curves. This differs from circular interpolation in that steps at an identical point or an FPT tag are not required at the connecting point between two spline curves.






When the parabolas overlap, a composite motion path is created.



Play Speed

- The play speed setting window is identical to that for linear interpolation.
- As with circular interpolation, the speed taught at P2 is applied from P1 to P2, and the speed taught at P3 is applied from P2 to P3.



4-5


4.1 Teaching Operation

4.1.4 Teaching Steps

There are two basic teaching steps for the manipulator: move or stop. The following sections describe the method of how to teach Motion Instruction and Timer in the job.

4.1.4.1 Teaching Motion Instructions

Whenever one step is taught, a motion instruction is inserted. Steps can be taught in sequence as shown in *fig. 4-2 "Registering Motion Instruction"*. Steps can also be inserted between already registered steps, as shown in the right *fig. 4-3 "Inserting Motion Instructions"*



- 1. Before jogging the Robot, select the desired Jogging Mode for easier movement. Refer to *chapter 4.1.3 "Motion Type (Interpolation Type)"* for details.
- 2. Use the jogging buttons on the touch screen or membrane keys to move the manipulator to the desired position.
- 3. Select the Inserting Line, Tool Number and Interpolation Type.
- Hold the Enable Switch ON with Servo ON, and press {+ TEACH} to register. If long press {+ TEACH}, teaches the current position with Position Level = 0. This means that the manipulator will stop at this position.



Selecting the Inserting Line

- 1. Select {Current Job} under {MENU}.
 - The contents of the currently-selected job are displayed.
- 2. Move the cursor to a line immediately before the position where a motion instruction is to be registered.
- 3. Grip the Enable switch to turn the servo power ON.

4-6

4. Move the manipulator to the desired position using {Jog Keys}.

4.1 Teaching Operation

Selecting the Tool Number

1. Before teaching the position, press the {Tool} text. Tool setting needs to be completed in advance. For tool setting instruction, refer to *chapter 6.1 "Tool Settings"*.



2. Select the Active Tool from the list and press {Select}.

Setting the Interpolation Type

- 1. Press {JOINT MOVE} next to the {+ TEACH} to change the interpolation type. The order will be shown as:
 - 1. Joint Move
 - 2. Linear Move
 - 3. Circle Move
 - 4. Spline Move

Each time the interpolation type button is pressed, the interpolation type switches in this order. If pressed again after it reaches Spline Move, it will return to the Joint Move.

| 📀 TEACH | JOINT MOVE |
|---------|------------|
|---------|------------|

Setting the Play Speed

The speed of the manipulator can be changed using the motion instruction.

- 1. Press {Speed}.
 - A numeric keypad appears.



- 4 Teaching
- 4.1 Teaching Operation
- 2. Insert the desired speed and press {SAVE}.
 - If an entered value is outside the allowable range, the input value will be replaced to with the nearest value within the allowable range.
- 3. The speed is now registered.

4.1.4.2 Setting Timer Instruction

The timer instruction function stops the manipulator for a specified length of time.


Follow these steps to register time instructions.

- 1. Select {Current Job} under {MENU}.
- 2. Move the cursor to the line before the position where the timer instruction is to be inserted.
- 3. Open the {COMMANDS} tab from the Navigation Bar.
- 4. Select the {Timer} under the {General} Tab.
 - The timer instruction is now inserted to the line.
- 5. Change the timer value by pressing the highlighted time value.
 - The numeric keypad will appear.
- 6. Input the desired values and press {SAVE}.
 - The timer instruction is now registered.

HW1485509

- 4 Teaching
- 4.1 Teaching Operation

4.1.5 Overlapping: The First and Last Steps



- 1. Move the cursor to the first step line.
- 2. Hold {GO TO POINT} until the manipulator reaches the first step position.

| Mode Joint [2, ~ | | Tool #0: Vacuum ~ | | |
|---------------------|--|-------------------------------|--|--|
| | | BLOCK I/O: TOOL #0 | | |
| Speed | | GO TO POINT Target: Line 5 | | |

- 3. Move the cursor to the last step line.
- 4. Open the detail edit of the last step line, using the method described in *chapter 4.4.4 "Editing Commands"*.
- 5. Check that the {Position} is selected to the left.

4-9

- Recorded position and current position are shown on the right.

- 4 Teaching
- 4.1 Teaching Operation
- 6. Press {RE-TEACH}
 - The position data for the first step is registered on the last step.
 - This changes the position data in the last step ONLY. Interpolation type and play speed will not change.

| | TaughtPosition | 10000 | | 122.117 | |
|-----------------|----------------|-------|-------|---------|----------|
| 0 | | Reco | orded | Curr | ent |
| Speed | 20.00 | s | 0.00° | s | 0.00 |
| osition Level 🔻 | Unused | L | 0.00° | L | 0.00 |
| Acceleration | Unused | υ | 0.00° | υ | 0.00 |
| Deceleration | Unused | R | 0.00° | R | 0.00 |
| Comment | Unused | в | 0.00° | в | 0.00 |
| | | т | 0.00° | т | 0.00 |
| | | | | F | RE-TEACH |

- 4 Teaching
- 4.2 Checking a Step

4.2 Checking a Step

4.2.1 GO TO POINT Operation


To check the position of a taught reference point, move the manipulator to the reference point with the {GO TO POINT}.



- 1. Move the cursor to the step to be checked.
- 2. Hold {GO TO POINT} until it reaches the position.

| Mode Joint [Ž. 🗸 🗸 | Tool #0: Vacuum → |
|------------------------|-------------------------------|
| | BLOCK I/O: TOOL #0 |
| Speed | GO TO POINT Target: Line 5 |

3. When the manipulator reaches the target position, the box on the right will turn green and the manipulator will stop.



4.2.2 Circular Movements with the GO TO POINT Operation

- The manipulator will move in a straight line for the steps of the circular interpolation.
- To check the trajectory of the circular movement, use the test operation described in *chapter 4.3*.

4.2.3 Spline Curve Movements with the GO TO POINT Operation

- The manipulator will move in a straight line for the steps of spline interpolation.
- To check the trajectory of the spline curve movement, use the test operation described in *chapter 4.3*.

4-11

HW1485509

- 4 Teaching
- 4.3 Test Job

4.3 Test Job

Playback operations can be tested and verified in MANUAL (TEACH) mode.

- 1. Place operations in MANUAL (TEACH) mode.
- 2. Open the job from the {Job List} under {MENU}.
- 3. Go to {TEST/RUN JOB} from the Navigation Bar.

| | Î↓ DIGITAL I/O | B= variables | | COMMANDS | TEST/RUN JOB |
|--|-------------------|------------------------|--|----------|--------------|
|--|-------------------|------------------------|--|----------|--------------|


| | | Test 🔵 Run | i - | () |
|-------------------------|---------------------------|----------------------------|----------|--------------|
| | Test Run Mod One Cycle | | | |
| | | TEST STA (Selected Line | | |
| | | | | |
| | | | | |
| ↑ DIGITAL I/O | B= VARIABLES | | COMMANDS | TEST/RUN JOB |

- 4 Teaching
- 4.3 Test Job

4.3.1 Test Start

Test Start simulates playback operation in MANUAL (TEACH) mode. This function is convenient for verifying operation instructions and motions, helping to achieve continuous paths. Test operation differs in the following ways from actual playback in the AUTOMATIC (PLAY) mode:

- Operation speeds greater than the maximum teaching speed (default setting: 250 mm/sec) are reduced to the maximum teaching speed by default.
- There may be a slight difference between the motion path for the test operation and the motion path for playback operation due to a mechanical error or control delay, etc.
- Fig. 4-4: Motion Path for Test Operation



Make sure that there are no obstacles around the manipulator.

1. Tap the {TEST/RUN JOB} icon on the Navigation Bar.

| | B= | 2 | | |
|-------------|-----------|---------|----------|--------------|
| DIGITAL I/O | VARIABLES | JOGGING | COMMANDS | TEST/RUN JOB |

2. Turn Servo Power ON for the Robot.

4-13

3. Select the Test Run Mode by tapping the Test Run Mode Drop Down. Valid options are:





- 4 Teaching
- 4.3 Test Job
- 4. Press and hold {TEST START}.
 - The speed of the motion will be limited to 250 mm/sec.
 - Job execution will start from the selected line.





To run the job in full speed, switch to the AUTOMATIC (PLAY) position and press the {RUN}.

- 4 Teaching
- 4.4 Commands

4.4 Commands

4.4.1 Command Group

The commands are divided into five groups by processing or each work.

| Display | Content | Example |
|---------|-----------------------------------|-----------------------|
| General | General commands to the job | Timer, Comment |
| Motion | Moves the manipulator | JointMove, LinearMove |
| I/O | Controls input and output | DigitalOut, PulseOut |
| Math | Performs arithmetic calculation | Add, Set |
| Control | Controls processing and each work | Jump, Pause |

With Macro functionality there are potentially six groups, if the Macro feature is enabled.

| Display | Content | Example |
|---------|---|------------|
| Macro | Predefined job for a specific reuseable | Macro Mane |
| | purpose | |

Command List

Press {COMMANDS} on the Navigation Bar to display the command group tabs.

| | B= | 2 | <> | |
|-------------|-----------|---------|----------|--------------|
| DIGITAL I/O | VARIABLES | JOGGING | COMMANDS | TEST/RUN JOB |

Select a group from the Command Bar to display its command list.

| Favorites | General | Motion | 1/0 | Math | Control | COMMAND BUILDER | (i |
|-----------|---------|--------|-----|------|---------|-----------------|----|
| | | | | | | | |

If macros are enabled, the macro tab displays on the command bar. Macros can be inserted using the same process as other commands. For instructions on how to install macros, see *chapter 13.2 "Handling Data"*.

| rites General Motion I/O Math Control Mac |
|---|
|---|

4 Teaching

4.4 Commands

4.4.2 Color Coordinates

There are nine colors displayed in Job Contents view.

| Color | Item |
|------------|-------------------------------|
| Pink | General Commands |
| Orange | Motion Commands |
| Red | I/O Commands |
| Dark Blue | Operating Commands |
| Light Blue | Control Commands |
| Purple | Variables |
| Green | Comment |
| Brown | Macro |
| Black | Parameter, Start Job, End Job |

4.4.3 Inserting Commands

- 1. In MANUAL (TEACH) mode, move the cursor to the line immediately before where the command is to be inserted in the Job Contents view.
- 2. Press {COMMANDS}.
- 3. Select the command group from the Tab Bar.
 - The command list of the selected command group will appear.
- 4. Select the command.
 - Press the checkbox of "Show Advanced Commands" for further command options.
- 5. Change additional items or variables as required.
 - When nothing is to be changed, the process is complete.
 - When additional items are to be edited, refer to *chapter 4.4.4 "Editing Commands"*.

- 4 Teaching
- 4.4 Commands

4.4.4 Editing Commands

Move the cursor to the command to be edited, in the MANUAL (TEACH) mode.

- (1) Changing numeric data
 - I) Select the highlighted item on the instruction.

| 1 Start Job | Speed | | | CANCEL | |
|---|-------|---|---|--------|------------|
| 2 JointMove Speed=50.00(%) 3 End Job | 1 | 2 | 3 | × | \$ |
| | 4 | 5 | 6 | | |
| | 7 | 8 | 9 | Enter | |
| | (|) | · | (Save) | JOINT MOVE |
| | | | | - | |

- II) Input the value using the numeric keypad.
- III) Press {SAVE} to register the edit.
- (2) Adding, modifying, or deleting an additional item Press Detail Edit icon on the right side of the Job Contents view.

2 JointMove Speed=50.00(%)

Detail Edit panel appears.

4-17

- I) To add an additional item, press "UNUSED". Input the desired value for the item. Press {SAVE ALL}.
- II) To modify an additional item, press the existing item. Input the desired value for the item. Press {SAVE ALL}.
- III) To delete an additional item, press the existing item and cross will appear on the right. Press the {X} and it will change to "UNUSED". Press {SAVE ALL}.

The Detail Edit panel appears and shows each editable item. Items for motion command are shown as an example.

- 4 Teaching
- 4.4 Commands

Modifying Position

There are two methods for modifying (i.e. re-teaching) a position.

 Modifying from Job Contents View The {RE-TEACH} inside the Job Contents View is visible when selecting a motion instruction. When pressing this button, the selected line blinks indicating the position is re-taught.

| 1 Start Job 2 JointMove Speed=50.00(%) 3 End Job () RETEACH () TEACH JOINT MOVE () DigitalOut () Timer () Wait | ද්ථු} ROBOT JOB - SAMPLE | 0 | | 錼 |
|--|----------------------------|-------|---------|----------|
| 3 End Job © RE-TEACH © TEACH JOINT MOVE | 1 Start Job | | | |
| 🤵 RE-TEACH 🎯 TEACH JOINT MOVE | 2 JointMove Speed=50.00(%) | | | ٠ |
| | Re-teach 🎯 T | FEACH | JOINT M | ove ~ |

- (2) Modifying from Detail Edit Panel
- 1. Jog the Robot to the new position and open the Detail Edit panel.
- 2. Select the Position.
- 3. Press {RE-TEACH} to modify the position.

- After re-teaching, "Recorded" and "Current" positions should match.

| Motion Type | JointMove | | |
|----------------|----------------|---------------------|---------------------|
| Position | TaughtPosition | Recorded S 0.00° | Current S 90.00° |
| Speed | 50.00 | L 0.00° | L -45.00° |
| Position Level | Unused | U 0.00° | U 12.73° |
| Acceleration | Unused | R 0.02° | R -121.21° |
| Deceleration | Unused | B 0.01° | B -174.90° |
| Comment | Unused | T -0.00° | T 0.01° |
| | | | RE-TEACH |
| | | Recorded Tool: | 0 |

116 of 493

4 Teaching

4.4 Commands



The tool number is seen in the box. The tool number cannot be edited, because the TCP may change when changing the tool. To change the tool number teach a new step.

Modifying Motion Type

A motion instruction can be changed between all types (JointMove, LinearMove, CircleMove, SplineMove) from the Job Contents view or from the Detail Edit panel.

- (1) Modifying from Job Contents View
- 1. Select the desired line
- 2. Press the motion instruction
 - A drop-down list will appear
- 3. Select the new motion type

| ROBOT JOB - SAMPLE | 0 | 1 |
|-----------------------------|---|----------|
| 1 Start Job | | |
| 2 JointMove ~ eed=50.00(%) | | ŝ |
| 3 JointMove | | |
| LinearMove | | |
| CircleMove | | |
| SplineMove | | |
| | | |
| 👳 RE-TEACH 👳 | | IOVE |
| ⊖ DigitalOut 统 Timer 统 Wait | | ~ |

- 4 Teaching
- 4.4 Commands
 - (2) Modifying from Detail Edit Panel
- 1. Select the motion instruction and open Detail Edit panel
- 2. Select the "Motion Type" parameter
- 3. Select the desired Motion Type from the list

| n using on. |
|-------------------|
| n using ion. |
| n using ation. |
| n using |
| |
| |
| |
| |

- 4 Teaching
- 4.4 Commands

Modifying Speed

1. Select the Speed.

The number that can be entered are different among interpolation type.

- Joint mode: specifies the Joint Speed, which is shown as a percentage of the Robot's highest speed. Speed: 0.01% to 100%
- Linear mode: specifies the tool center point speed, using the Detail Edit screen. The maximum speed is unique for each Manipulator model. Units: mm/sec
- Circle mode: specifies the tool center point speed, using the Detail Edit screen. Units: mm/sec
- Spline mode: specifies the tool center point speed, using the Detail Edit screen. Units: mm/sec

| 2a. | For | Constant, | enter th | ne prefe | erred s | peed | usina | the I | numeric | kevpa | ad. |
|-----|-----|-----------|----------|----------|---------|------|-------|-------|---------|-------|-----|
| | | | | | | | | | | | |

| Detail Edit: JointMove | e Job Line #: 2 | Job St | tep #: 1 | | | > | ĸ |
|------------------------|-----------------|--------|--------------------------------------|------------------|----------------|--------|------|
| | | | Constant | User Variable | Loca Varial | | |
| Motion Type | JointMove | ļ | Specifies the joir to the highest sp | | | | atio |
| Position | TaughtPosition | | | | | | |
| Speed | 50.00 😣 | | | | | | |
| Position Level | Unused | | | | | | |
| Acceleration | Unused | | 1 | 2 | 3 | × | |
| Deceleration | Unused | | | | | | |
| Comment | Unused | | 4 | 5 | 6 | - | |
| | | | 7 | 8 | 9 | Enter | |
| | | | | 0 | • | Linter | |

- 4 Teaching
- 4.4 Commands
- 2b. For Variable, select the variable type from Byte, Integer, and Double type, and its number on the numeric keypad. Variable's content can be browsed from the {Browse Variable}.



When the variable is used for speed with a LinearMove instruction, the unit is 0.1mm/s. When the variable is used for the speed with a JointMove instruction, the unit is 0.01%.

| | | Constant | User Variable | Lo Varia | cal able |
|----------------|----------------|----------|--|-------------|-------------|
| Motion Type | JointMove | | Specifies the joint speed. The joint speed is shown in the to the highest speed. Speed: 0.01% to 100.00% | | |
| Position | TaughtPosition | Brows | se Variables | Array VA | R: Unuse |
| Speed | B000 🙁 | (B)yte | (I)nte | ner | (D)oub |
| Position Level | Unused | | (1)110 | | (0)000 |
| Acceleration | Unused | 1 | 2 | 3 | × |
| Deceleration | Unused | | | | |
| Comment | Unused | 4 | 5 | 6 | - |
| | | 7 | 8 | 9 | |
| | | | 0 | | Ente |

4 Teaching

4.4 Commands

2c. For Local Variable, select the variable type and enter its number on the numeric keypad.



Local Variable types will only be available if they have been allocated for the job. For more information on Local Variables, refer to *chapter 4.8 "Local Variables"*.

| | | | | × |
|---------------|---------------------------------------|--|---|--|
| | Constant | User Variable | Loca Varia | |
| pintMove | | | | ipulator passes |
| aughtPosition | | | Array VAR | : Unused 🔻 |
| 0.00 | (LB)yte | (LI)nte | eger | (LD)ouble |
| 3000 🙁 | | | | |
| nused | 1 | 2 | 3 | × |
| nused | | | | |
| nused | 4 | 5 | 6 | - |
| | 7 | 8 | 9 | Fatas |
| | C |) | • | Enter |
| | aughtPosition 0.00 wood Solused | Specifies the appr the taught position 0.00 (LB)yte 1 1 1 1 1 1 1 1 1 1 1 1 1 | Specifies the approach level w the taught position. Level: 0 to sught Position (LB)yte (LI)nte sused 1 2 used 4 5 | Specifies the approach level when the man the taught Position Level: 0 to 8 Array VAR (LB)yte (LI)nteger used 1 2 3 used 1 2 6 7 8 9 |

3. Press {SAVE} when the modification is completed.



Setting Position Level


The position level can be changed after the motion instruction is registered.

Position Level: The position level is the degree of approximation of the Robot motion with respect to a taught position. The position level can be added to motion instructions Joint Move (joint interpolation) and Linear Move (linear interpolation). If the position level is not set, precision will depend on the operating speed. Setting an appropriate operating speed level will ensure that the Robot moves in a path that is safe and suitable to circumferential conditions and the workpiece. The position level must be a whole number from 0 to 8, total of 9 levels.

- 4 Teaching
- 4.4 Commands

The relationship between path and accuracy for position levels is as follows.

Fig. 4-5: Position Level



1. Select the Position Level.

2a. For Constant, enter the preferred position level on the numeric keypad.

| Detail Edit: JointMov | e Job Line #: 2 | Job S | tep #: 1 | | | × |
|-----------------------|-----------------|-------|--|------------------|--------------|------------------|
| | | | Constant | User Variable | Loc Varia | |
| Motion Type | JointMove |] | Specifies the app the taught positi | | | nipulator passes |
| Position | TaughtPosition |] | | | | |
| Speed | 50.00 |] | | | | |
| Position Level | 4 |] < | | | | |
| Acceleration | Unused |] | 1 | 2 | 3 | × |
| Deceleration | Unused |] | | | | |
| Comment | Unused |] | 4 | 5 | 6 | - |
| | | | 7 | 8 | 9 | |
| | | | | ם | | Enter |

4 Teaching

4.4 Commands

2b. For Variable, select the variable type from Byte, Integer, and Double type, and its number on the numeric keypad. The variable's content can be browsed from the {Browse Variable}. For array variables, refer to *chapter 4.6 "User Variables"*.

| Detail Edit: JointMove | e Job Line #: 2 Jo | b Step #: 1 | | | × |
|------------------------|--------------------|--------------------------------------|------------------|--------------|------------------|
| | | Constant | User Variable | Loo Varia | |
| Motion Type | JointMove | Specifies the ap the taught posit | | | nipulator passes |
| Position | TaughtPosition | Brows | se Variables | Array VA | R: Unused 🔻 |
| Speed | 50.00 | (B)yte | (I)nte | ger | (D)ouble |
| Position Level | B000 🔇 | | | 90. | |
| Acceleration | Unused | 1 | 2 | 3 | × |
| Deceleration | Unused | | | | |
| Comment | Unused | 4 | 5 | 6 | - |
| | | 7 | 8 | 9 | |
| | | | 0 | | Enter |

- 4 Teaching
- 4.4 Commands

2c. For Local Variable, select the variable type and enter its number on the numeric keypad.

| NOTE | |
|------|--|
|------|--|

Local Variable types will only be available if they have been allocated for the job. For more information on Local Variables, refer to *chapter 4.8 "Local Variables"*.

| | | Constant | User Variable | | cal able |
|----------------|----------------|---|------------------|----------|----------------|
| Motion Type | JointMove | Specifies the appr the taught position | | | nipulator pass |
| Position | TaughtPosition | | | Array VA | R: Unused |
| Speed | 50.00 | (LB)yte | (LI)nte | eger | (LD)ouble |
| Position Level | LB000 😣 | | | | (/ |
| Acceleration | Unused | 1 | 2 | 3 | × |
| Deceleration | Unused | | | | |
| Comment | Unused | 4 | 5 | 6 | |
| | | 7 | 8 | 9 | |
| | | C | | | Enter |

3. Press {SAVE} once the modification is complete.

| Detail Edit: JointMove Job Line #: 2 Job Step #: 1 | CANCEL SAVE ALL |
|--|-----------------|
|--|-----------------|

Setting Comment

The comment is written next to the instruction. The comment can be from 0 to 32 alphanumeric and symbol characters in length.

- 1. Select {Comment}.
- 2. Enter the comment under "Enter Comment".
- 3. Press {SAVE} on the input keyboard.
- 4. Press {SAVE ALL} once the modification is completed.

| Detail Edit: Join | ntMove Job Line #: | 2 Job Step | o #: 1 | × CANCEL | SAVE ALL |
|-------------------|--------------------|--------------|--------------|--------------|----------|
| 5. The comr | ment is displaye | d in the jol | o, next to t | the instruct | ion. |
| 1 Start Job | | | | | |
| 2 JointMove | Speed=50.00(%) | //comment | inserted | | \$ |
| 3 End Job | | | | | |

- 4 Teaching
- 4.4 Commands

4.4.5 Favorites

Frequently used commands can be saved to {Favorites} for quick access. To access favorites, open the {Favorites} tab in the command group. There is no limit on the amount of commands to save in {Favorites}.

- 1. Open any other command group.
- 2. Tap the star on the right side of the command.

4-27

- Check the star's color has changed to yellow.
- 3. Check that the starred command is saved on Favorites, as well as above the command group.
 - The commands will be saved in the order they were tagged as favorites.

| ⊖ Digita | alOut දි | } Timer | දිාී Wait | J | | ~ |
|-----------|--------------|--------------|------------------------------------|--------------|------------------|-------------------------|
| Favorites | General | Motion | 1/0 | Math | Control | |
| Show | advanced com | mands | | | | (\tilde{l}) |
| ⊖ Dig | gitalOut | Turns the g | eneral output | signal on an | d off | * |
| _ چې ا | Timer | Stops for th | ne specified tir | ne | | * |
| 쓚 | Wait | | the status of t e specified sta | | ignal or byte ty | ype variable is the 🔶 📩 |

HW1485509

- 4 Teaching
- 4.4 Commands

4.4.6 Command Builder

Command Builder is used to add basic commands to a job. Command Builder uses simple instructions to support ease of use for users.

Command Builder can be used to add three basic types of command:

- SET
- READ
- WAIT
- 1. Open the Command Builder from the {COMMANDS} tab.



2. Select the command type from the tab.

| What do you want to do? SET | READ | WAIT | × |
|-----------------------------|------|------|---|
|-----------------------------|------|------|---|

3. Select the command from the list.

| S | et B001 1 | Add Command |
|--------|--|-------------|
| 0 | Set a Variable to a Constant Value Variable: B001 Y Constant: 1 | |
| 0 | Set a Variable to Another Variable | |
| 0 | Set a Digital Output to ON/OFF | |
| \cap | Set a Digital Output ON for a specified Time | |

4. Select the variable from the list or insert the value in the box. (Ex. B003 and 10)

| Set B003 10 | 1 | Add Command |
|-------------|-------------------------|-------------|
| | | |
| Set a Varia | ble to a Constant Value | |

5. Press {Add Command}.

| his is the command that will be added to your job: | |
|--|-------------|
| Set B003 10 | Add Command |

- 4 Teaching
- 4.4 Commands

Command Builder limits the number of variables, I/O, etc. that can be modified. However, the commands generated by Command Builder can be modified in the Job Contents view to use any variable and I/O.

6. The added command is displayed in the Job Contents view. Press the {Detail Edit} icon to the right of the added line.

| 1 Start Job |) | |
|-------------|----|----|
| 2 Set 8003 | 10 | \$ |
| 3 End Job | | |

 Other variables that were not listed in the Command Builder can also be selected. Replace the variables to desired variables, if a triangle ▼ is being displayed next to the input, other items are available for selection. (Ex. R000 and R002)

| Detail Edit: Set J | ob Line #: 2 | | | × CANCEL | | SAVE ALL |
|--------------------|--------------|---|----------|------------------|----------------|----------|
| | | 7 | Constant | User Variable | Loca Variab | |
| Result - Real 🔻 | R000 | | | | - | |
| Result-Int | R002 | | ~ | | | |
| Result - Real | 3 | | Brow | se Variables | Array VAR: | Unused V |
| Position | | | | (D) | | |
| | | | | (R)ea | <u>u</u> . | |
| | | | | | | |

8. Press {SAVE ALL}, and the command is modified.

4-29



HW1485509

- 4 Teaching
- 4.4 Commands

4.4.7 Expanded Inform Line

In cases where an instruction has more parameters than can be displayed in one line, an arrow indicator displays.

| 1 | Start Job | | | | | | |
|---|-----------|------|------------------|---------------|--------|---|------------|
| 2 | JointMove | P000 | Speed= 45.00 (%) | Acceleration= | 25 (%) | • | ۲ <u>۵</u> |
| 3 | End Job | | | | | | |

To view all of the parameters, press the arrow to expand the Inform line and press again to minimize the Inform line.

| 1 Start Jo | b | | |
|------------|---------------------|---|-----|
| 2 JointMov | e | • | 503 |
| F | 000 | | |
| S | peed= 45.00 (%) | | |
| ł | cceleration= 25 (%) | | |
| C | eceleration= 22 (%) | | |
| 3 End Job | | | |

- 4 Teaching
- 4.5 Editing Job

4.5 Editing Job

The Job Content Header provides access to three menus that make it easier to quickly navigate and edit the INFORM job:

- Edit
- Find
- Display

These menus are described in the following sections.

Fig. 4-6: Job Content Header

| | | Ľ⊿ | SERVO | e 2 |
|-------------|-------------|----|-------|-------------------|
| င့်} ROBOT. | JOB - SAMPI | LE | | Edit Find Display |

4.5.1 Edit Menu

Press the {Edit} to bring up the Edit Menu. The following operations can be used from this menu.

- Undo
- Redo
- Cut
- Сору
- Paste
- Delete
- Suppress

Fig. 4-7: Edit Menu

| ≡ м | ENU | Γ ₃ 4 | 1 | | SERVO | | | P 2 |
|-----|--------------|------------------|---|---|-------|---|-------|--------|
| 8 | \leftarrow | \rightarrow | * | ß | | Û | //abc | 🖉 Edit |

Bring the cursor to the line to be processed and press the desired button.

Additionally, some of these commands (Cut, Copy, Delete, Suppress) can be executed on multiple lines at one time. To select multiple lines, press and hold on the line and then drag to select more lines.

- 4 Teaching
- 4.5 Editing Job

Fig. 4-8: Multi-Selection

| 1 Start Job | |
|---|---|
| 2 For I000 = 1 to 5 | |
| 3 JointMove Speed=100.00(%) | |
| 4 JointMove Speed=100.00(%) | |
| 5 Next 1000 | |
| 6 Timer Time=2.50(seconds) | |
| 7 DigitalOut Output#(1) ON | |
| 8 End Job | |
| | |
| DigitalOut (혔 Timer (했 Wait | ~ |

4.5.1.1 Undo Operation

| Toolbar button | Name | Description |
|----------------|------|--|
| \leftarrow | Undo | Undo reverses the most recent editing command from Commands tab. |

After inserting, deleting or modifying an instruction, operations can be undone. The undo operation can be performed even after the manipulator is moved by the test operation. However, undo operations cannot be performed if motion instructions are inserted or edited. The undo operation works for the last ten edited instructions only.

4.5.1.2 Redo Operation

| Toolbar button | Name | Description |
|----------------|------|---|
| \rightarrow | Redo | Redo reverts the effects of the undo action |

Redo can only be used after the undo operation has been used.

4-32

4.5.1.3 Cut Operation

| Toolbar button | Name | Description |
|----------------|------|--|
| \gg | Cut | Deletes the selected command(s) from a job and copies command(s) to a buffer. |

HW1485509

- 4 Teaching
 - 4.5 Editing Job

4.5.1.4 Copy Operation

| Toolbar button | Name | Description |
|----------------|------|---|
| ß | Сору | Copies the selected command(s) to the buffer. |

4.5.1.5 Paste Operation

| Toolbar button | Name | Description |
|----------------|-------|--|
| | Paste | Inserts the content of the buffer on a line below the selected step. |


4.5.1.6 Delete Operation

| Toolbar button | Name | Description |
|----------------|--------|----------------------------------|
| | Delete | Deletes the selected command(s). |

4.5.1.7 Suppress Operation

| Toolbar button | Name | Description |
|----------------|----------|--|
| //abc | Suppress | Suppress the selected command(s). Suppressed commands will be skipped during job execution. For example, the Timer and DigitalOut command would not execute in <i>fig.</i> <i>4-9 "Example of Suppressed Commands"</i> . |

Fig. 4-9: Example of Suppressed Commands



4 Teaching

4.5 Editing Job

4.5.1.8 Multi-Edit Operation

| Toolbar button | Name | Description |
|----------------|------------|--|
| | Multi-Edit | Change the value of multiple parameters at once. This is useful for bulk editing of motion instructions. |


Pressing the Multi-Edit button will bring up a popup allowing a user to edit the parameters of all selected instructions. This button will only be available when multiple lines are selected. The following parameters can be edited through this popup:

- Joint Speed
- · Linear Speed
- Rotation Speed
- Max Speed
- Acceleration
- Deceleration
- Position Level

To perform a Multi-Edit, follow these steps:

- 1. Select multiple lines of code containing some subset of the parameters listed above and press {Multi-Edit}.
 - This opens the Multi-Edit Panel that contains all supported parameters that appear in the selection.
 - For example, the selection in *fig. 4-10* contains Joint Speed, Linear Speed, Deceleration, and Position Level.

Fig. 4-10: Press {Multi-Edit}



- 4 Teaching
- 4.5 Editing Job

Fig. 4-11: Multi-Selection Edit Panel


| Joint Speed | % | (3 selected) | |
|---------------|--------|--------------|--|
| Linear Speed | | (2 colocted) | |
| | mm/sec | (2 selected) | |
| Deceleration | % | (2 selected) | |
| PositionLevel | | _ | |
| | | (2 selected) | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

 Only constant parameters can be edited from this popup.
 For example, "Speed=50.00" can be edited but "Speed=D001" cannot be edited.
 If selection does not contain any parameters that can be edited, a message displays indicating supported parameters.

- 4 Teaching
- 4.5 Editing Job
- 2. Enter values for desired parameters and press {SAVE}.
 - In the following example, the Joint Speed is set to 50.00, the Linear Speed is set to 250.00, and the Deceleration is set to 25.
 - A value is not entered for Position Level which means this parameter will be unaffected by the changes.
- Fig. 4-12: Multi-Selection Edit Parameter Values

- The code displays the updated values.

```
Fig. 4-13: Updated Values in Displayed Code
```





• The Multi-Edit popup contains {Select All Job Lines} which expands the Multi-Selection to include the entire job.

This is useful for quickly editing large jobs.

- 4 Teaching
- 4.5 Editing Job

4.5.2 Find Menu

Press the {Find} to bring up the Find Menu. This menu can be used to quickly navigate a long INFORM program.

Fig. 4-14: Find Menu

| | NU 🕅 | | SERVO | | | P 2 |
|---|------------|-------------------|---------------|-------------|---|--------|
| × | ↑ To Start | \downarrow To End | ← To Previous | الله Go To: | 1 | 🖳 Find |

The following operations can be performed from this menu:

4.5.2.1 To Start

| Toolbar button | Name | Description |
|-----------------------|----------|--------------------------------------|
| $\overline{\uparrow}$ | To Start | Return to the first line of the job. |

4.5.2.2 To End

| Toolbar button | Name | Description |
|----------------|--------|-----------------------------------|
| \downarrow | To End | Navigate to last line of the job. |

4.5.2.3 To Previous

| Toolbar button | Name | Description |
|---------------------------|-------------|---|
| $\left \leftarrow\right.$ | To Previous | Return to the previously selected line. |

4.5.2.4 Go To

| Toolbar button | Name | Description |
|----------------|-------|---|
| <u>↓</u> | Go To | Go to the line entered into the provided numerical input. |

4-37

HW1485509

- 4 Teaching
- 4.5 Editing Job

4.5.3 Display Menu

Press the {Display} to bring up the Display Menu. This menu can be used to change various settings that relate to the Job Contents view.

Fig. 4-15: Display Menu



The following settings can be changed:

4.5.3.1 Display Classic View

When the {Classic} option is turned on, the original short-form INFORM language will be displayed on the Job Contents view. Classic INFORM is the language used in the YRC1000 Programming Pendant. For more information on the difference between Detail INFORM and Classic INFORM, refer to "YRC1000/YRC1000micro SUPPLEMENTAL INSTRUCTIONS FOR Smart Pendant (HW1485511)". Display Classic View can be turned ON / OFF during both MANUAL (TEACH) and AUTOMATIC (PLAY) mode.

Fig. 4-16: Detail INFORM (with Classic View OFF)

```
3 JointMove Speed=75.00(%) Acceleration=50(%) Deceleration=20(%)
4 Timer Time=1.00(seconds)
5 DigitalOut Output#(5) ON
```

Fig. 4-17: Classic INFORM (with Classic View ON)

```
3 MOVJ VJ=75.00 ACC=50 DEC=20
4 TIMER T=1.00
5 DOUT OT#(5) ON
```

4.5.3.2 Display Tool Number

When {Tool #} option is turned on, the tool number will be displayed on the Job Contents view. It displays next to the line number in []. {Tool #} can be turned ON / OFF during both MANUAL (TEACH) and AUTOMATIC (PLAY) mode.

Fig. 4-18: Display Tool Number (when Display Tool # is ON)

3 [1] JointMove Speed=10.00(%) Acceleration=20(%)
4 [5] JointMove Speed=10.00(%) Deceleration=50(%)

4-38

- 4 Teaching
- 4.5 Editing Job

4.5.3.3 Display Variable Names

When {Var. Name} option is turned on, the variable number is replaced with variable names. The variable should be named beforehand, using the instruction in *chapter 4.6 "User Variables"*.

{Var. Name} can be turned ON / OFF during both MANUAL (TEACH) and AUTOMATIC (PLAY) mode.

Fig. 4-19: Display Variables Numbers (with Display Variable Names OFF)

3 JointMove Speed=B005(%)
4 JointMove P000 Speed=B010(%)

Fig. 4-20: Display Variables Names (with Display Variable Names ON)

3 JointMove Speed=data1(%)

4 JointMove TEST Speed=data2(%)

4.5.3.4 Display I/O Names

When {IO Name} is turned on, the I/O number is replaced with I/O names. The I/O should be named beforehand, using the instruction in *chapter 4.6*.

{IO Name} can be turned ON / OFF during both MANUAL (TEACH) and AUTOMATIC (PLAY) mode.

Fig. 4-21: Display I/O Numbers (with Display IO Names OFF)

```
5 DigitalOut Output#(2) OFF
6 DigitalOut Output#(1) ON
```

Fig. 4-22: Display I/O Names (with Display IO Names ON)

5 DigitalOut Output#(BLOW OFF) OFF

6 DigitalOut Output#(SUCTION) ON

HW1485509

4-39

137 of 493

- 4 Teaching
- 4.5 Editing Job

4.5.3.5 Display Favorites bar

When the {Favorites} option is turned on, the bottom left of the Job Contents View will contain shortcuts to Favorite Commands. If a user wants to see more of the Job Contents View instead, this option can be turned off.

{Favorites} can be turned ON / OFF during both MANUAL (TEACH) and AUTOMATIC (PLAY) mode.

Fig. 4-23: Job Contents View (with Favorites turned ON)

| 9 Timer Time | =2.50(second | ls) | () TEA | ACH JOINT MOVE |
|---------------|-----------------|-----------|--------|----------------|
| 10 DigitalOut | Output#(1) | ON | | JOINT MOVE |
| ⊖ DigitalOut | နိဂ္ဂ်ိန် Timer | දිබූ Wait | | ~ |

Fig. 4-24: Job Contents View (with Favorites turned OFF)

| 9 Timer Time=2.50(seconds) | |
|-----------------------------|------------------|
| 10 DigitalOut Output#(1) ON | TEACH JOINT MOVE |
| 11 End Job | ~ |

4.5.3.6 Display Job Stack

When {Job Stack} is selected, a panel will display on the Job Contents View that will show the current Job Stack. As a job is executing, the "Call" instruction can be used to change to a new job. The Job Stack will show a list of jobs that have been called this way. For more information about Job Stack, refer to *chapter 5.4 "Job Stack*".

This panel can also be re-positioned inside the Job Contents View by pressing and dragging on the title bar.

Fig. 4-25: Job Stack Display



4 Teaching

4.5 Editing Job

4.5.4 Direct Open

The Direct Open function provides an easy way to debug and navigate programs. The basic usage is to Press and Hold on a User Variable, Position Variable, I/O Number, or Job Name from the Job Contents view to provide quick access to information related to these items. The following sections will describe the usage of each of these.

4.5.4.1 User Variable

A User Variable (B, I, D, R, S) can be pressed to quickly access the name and value of the variable. For example, be Pressing and Holding on the D(ouble) Variable in the program below, the Variable Panel will automatically open in the bottom half of the screen with this variable highlighted.

Fig. 4-26: Direct Open User Variable

4-41

| | ¶3 L⊿ | j <u>r</u> | ERVO | | P 2 |
|----------------------|----------|------------|------|----------|----------------|
| င္လိုန္နဲ့ ROBOT JOE | 3-SAMPLE | | | 0 | 。 。 。 |
| 1 Start Jo | b | | | | |
| 2 Incremer | nt D007 | | | | ŝ |
| 3 End Job | | | | | |
| Byte | Integer | Double | Real | String | Position |
| No. | Value | Name | | Display | only named Q |
| D000 | -2801 | partno | | | |
| D001 | 0 | index | | | |
| D002 | 0 | | | | |
| D003 | 0 | | | | |
| D004 | 0 | | | | |
| D005 | 4201 | | | | |
| D006 | 0 | | | | |
| D007 | 54 | count | | | |
| D008 | 0 | | | | |
| D009 | 0 | | | | |
| D010 | 0 | | ~ | | |
| Ĵ DIGITAL I/O | | ABLES JO | | COMMANDS | TEST/RUN JOB |

HW1485509

- 4 Teaching
- 4.5 Editing Job

4.5.4.2 Position Variable

Pressing and holding the (P)osition Variable, the Position Panel automatically opens in the bottom half of the screen with the selected position information. From this panel, the position can be modified or re-taught.

Fig. 4-27: Direct Open Position Variable


| ද්ලි} ROBOT JOB - SA | MPLE | | | 0 | |
|-------------------------------|-------------------|-----------|----------------------|--------------------|----------|
| 1 Start Job | | | | | |
| 2 JointMove | P010 Speed= | 5.00 (%) | | | • |
| 3 End Job | 2mg | | | | |
| | | V | | г | |
| Byte | Integer | Double | Real | String | Position |
| | | | | | - |
| ← Position Va | ariable P010: Pic | kPosition | | | |
| Reference Type World Frame | | | Name PickPosition | | |
| wond Frame | | | | | |
| × | 432.419 == | | Tool #3: | | ~ |
| Y | -126.285 == | | | | |
| z | 252.284 == | | (∲ s | ET CURRENT POSITI | DN |
| | 102.2485 | | 0 | 0 TO SAVED POSITIO | |
| Rx | | | V a | | |
| Rx | -70.5967 | | | | |
| | -70.5967 · | | Sh | ow Closure Set | tings |

- 4 Teaching
- 4.5 Editing Job

4.5.4.3 Input/Output Number Direct Open

Pressing and holding the Input/Output Number in the Job Contents View, the I/O Panel opens in the bottom half of the screen with the correct I/O Group and Number selected.





4.5.4.4 Job Name Direct Open

The functionality of Direct Open for the Job Name parameter in the Call instruction is slightly different. In this case, by Pressing and Holding the Job Name, the reference Job opens.

4-43



When a job opens this way, a special button appears on the Job Header that gives a quick navigation back to the parent job ("SAMPLE" in this example).

- 4 Teaching
- 4.6 User Variables

4.6 User Variables

Variables are used to store counters, calculation results, or input signals in the job. The variables can be freely defined in the job. User variables have a global scope, which means that the same variable can be used in multiple jobs and its data value is common to all the jobs. A variable's value is maintained even when the power is turned OFF.

Variables have the following applications:

- · Counting the amount of workpieces
- Managing the repeating count of jobs
- · Sending/receiving of information between jobs

The data formats for variables are described in the following table.

Default number of available variables is shown in the table. Users can change the amount of variable allocation using the Software Pendant (refer to *chapter 12 "Software Pendant"*).



Consider the data size of each variable and the amount of memory available in the YRC Controller when changing the amount of variable allocation.

| Data Format | Variable No. (pcs.) | Functions |
|------------------------------------|-----------------------------|---|
| Byte type (unsigned 8-bit) | B000 to B099 (100 count) | Range of storable values is from 0 to 255. Can store I/O status. Can perform logical operations (AND, OR, etc.) |
| Integer type (16-bit) | 1000 to 1099 (100 count) | Range of storable values is from -32768 to 32767. |
| Double integer type (32-bit) | D000 to D099 (100 count) | Range of storable values is from -2147483648 to 2147483647. |
| Real type (32-bit float) | R000 to R099 (100 count) | Range of storable values is from -3.4E+38 to 3.4E38. |
| String type (character) | S000 to S099 (100 count) | Maximum storable number of characters is 32. |
| Position type | P000 to P127 (128 pcs.) | Can store position data in angle form or in XYZ form. XYZ type variables can be used as target position data for motion instructions, and as incremental values for parallel shift instructions. Teaching line coordinates cannot be used. |

- 4 Teaching
- 4.6 User Variables

Below are some examples of using variables to specify motion speed and timer values:

- Play LinearMove Speed:

LinearMove Speed = D000 The variable D000 is used for speed with this motion instruction. <u>The unit for speed is 0.1mm per second.</u>

For example, if D000 were set as 1000, the following would be true: $D000 = 1000 \rightarrow$ unit for speed is 0.1mm/s \rightarrow speed = 100.0mm/s Note that, depending on the unit being used, the value of the variable and the value of the actual speed on occasion might not match.

– Play JointMove Speed:

JointMove Speed = D000 <u>The unit for speed is 0.01%</u>. For example, if D000 were set as 1000, the following would be true: $D000 = 1000 \rightarrow$ unit for speed is 0.01% \rightarrow speed = 10.00%.

– Timer Time:

Timer Time = D000 For YRC1000, the unit for Time is 0.01 seconds. (For YRC1000micro, the unit for Time is 0.001 seconds.) For example, if D000 were set as 1000, the following would be true: D000 = 1000 \rightarrow unit for Time is 0.01 seconds \rightarrow Time = 10.00 seconds.

Array Variable

An array variable can be used to dynamically change the variable number that is used in the program. The example below shows the relationship between the array variable and the variable number

Example:

- B[0] is same as B000.
- If B001 = 2, then D[B001] is same as D002.



This is especially useful when used inside of FOR loops where the loop index can be used to change the variable. For example, the FOR loop shown below would shift by the value of P001 in the first loop, P002 in the second loop, P003 in the third loop, etc....

– FOR I002 = 1 to 10 ShiftOn P[I002]

> ShiftOff Next I002

> > 4-45

HW1485509

- 4 Teaching
- 4.6 User Variables

4.6.1 Setting Byte, Integer, Double, and Real Type Variables

- 1. Select {Program/Operate} under {MENU}.
- 2. Select {Variables}.
 - {Byte}, {Integer}, {Double}, {Real}, {String} and {Position} tabs will appear.

| | | L (| SERVO | Ē | A 2 |
|-----------|---------|--------------|-------|--------|----------------|
| ← Variabl | es | | | | (1) |
| Byte | Integer | Double | Real | String | Position |
| No. 🔺 | Value | Binary Value | Name | Displa | y only named Q |
| B000 | 0 | 0000 0000 | | | |
| B001 | 0 | 0000 0000 | | | |
| B002 | 0 | 0000 0000 | | | |

- 3. Select the desired variable type from {Byte}, {Integer}, {Double}, or {Real}.
 - The selected variable screen appears. (Following case is when {Byte} is selected.)
- 4. Tap the desired variable number.
 - If the desired variable number is not displayed on screen, swipe the screen downwards.
 - If the variable has been named, it can be searched by using the search function.

| ← Variab | les | | | | (Ì |
|----------|---------|---------------------|------|-------------|----------|
| Byte | Integer | Double | Real | String | Position |
| No. 🔺 | Value | Binary Value | Name | Search by n | ame Q |

- 5. Tap the {Value} of the selected variable.
- 6. Insert the value to the variable using the numeric keypad.
- 7. Press {Enter}.
 - The input value is now set to the variable.
- 8. Insert the name for the variable as an option.

- 4 Teaching
- 4.6 User Variables

4.6.2 Setting String (Character) Type Variable

- 1. Select {Program/Operate} under {MENU}.
- 2. Select {Variables}.
- 3. Select {String} from the tab.
 - The string variable screen will appear.
- 4. Tap the desired variable number.
 - When the desired variable number is not displayed on the screen, swipe the screen downwards.
 - If the variable is named, the variable can be searched by using the search function.

| Byte | Integer | Double | Real | String | Position |
|------|---------|--------|------|-------------|----------|
| No. | Value | | Name | Search by n | ame (|

- 5. Tap the {Value} of the selected variable.
- 6. Insert the value to the variable using the alphanumeric keypad.
- 7. Press {Enter}.
 - The input value is now set to the variable.
- 8. Insert the name for the variable as an option.

4-47

4 Teaching

4.6 User Variables

4.6.3 Setting Position Variable with Variable Screen

4.6.3.1 Setting Position Variable by Moving the Manipulator

The following shows the position variables and setting methods.



- The setting of position variables is performed in MANUAL (TEACH) mode.
- Turn the servo power ON when setting the variables using the [Jog Keys].

Position Variables and Setting Method


| Туре | Pxxx (Robot) | |
|-------------------|------------------------------------|------------------------------------|
| | Angle type | XYZ type (world, tool, user, etc.) |
| Setting Method | Using jog keys (Robot Jog panel, M | embrane) |

| ← Variables | | | | | (i) |
|-------------------------------|------------|--------|----------------------|---------------------|----------|
| Byte | Integer | Double | Real | String | Position |
| Position Variable | P000: | | | | |
| Reference Type Robot Frame | | ~ | Name Enter Name I | nere | |
| х | 100.230 mm | | Tool #3: | | ~ |
| Y | -75.170 mm | | | | |
| Z | 257.010 mm | | 🗘 🗘 si | ET CURRENT POSITION | |
| Rx | 180.0300 ° | | () G | O TO SAVED POSITION | |
| Ry | -87.1300 ° | | | | |
| Rz | 14.2300 ° | | 錼 Sh | ow Closure Setti | ngs |

- 4 Teaching
- 4.6 User Variables
- 4.6.3.2 Setting Position Variable Using the Numeric Keypad
 - 1. Select {Position} under {Variables}.
 - 2. Select desired position variable type (ex. P000).
 - The data of the desired variable is shown below.
 - 3. Select the {Reference Type}.
 - The selection panel on Reference Type will appear.

| Position Variable R | Reference Type | × |
|---------------------|---|---|
| Select Reference 1 | Гуре | |
| JOINT ANGLE | Specify the position with Joint Angles | |
| WORLD FRAME | Specify the tool position with respect to the World Frame | |
| ROBOT FRAME | Specify the tool position with respect to the Robot Frame | |
| TOOL FRAME | Specify the tool position with respect to the Tool Frame | |
| USER FRAME | Specify the tool position with respect to the User Frame | |

If the position variable has already been set, a confirmation pop-up window will appear. Select {PROCEED} to clear the data.



- 4. Select the reference type.
- 5. Tap the cursor to the desired data to be input.
- 6. Input the value for the position.
- 7. Press {ENTER}.
 - The value is set in the cursor position.
- 8. Tap {Save} to save the position variable.
- 9. Insert the variable name as an option.

HW1485509

4 Teaching

4.6 User Variables

4.6.3.3 Closure Setting

When the position data for the job is described using the XYZ format, several postures may be adopted depending on the manipulator's structure when moving it to the described position.

Although these postures have the same coordinates for TCP, they vary in angle for each axis.

For this reason, the manipulator's posture cannot be uniquely defined by the coordinate value alone. It is necessary to specify data other than the coordinate value to define the manipulator's posture.

| ← Variables | | | | | (1) |
|-------------------------------|------------|--------|----------------------|--------------------|----------|
| Byte | Integer | Double | Real | String | Position |
| Position Variable | P000: | | | | |
| Reference Type Robot Frame | | ~ | Name Enter Name h | ere | |
| x | 100.230 mm | | Tool #3: | | ~ |
| Y | -75.170 mm | | - | | |
| z | 257.010 mm | | 🗘 SE | T CURRENT POSITION | |
| Rx | 180.0300 ° | | () G | TO SAVED POSITION | |
| Ry | -87.1300 ° | | | | |
| Rz | 14.2300 ° | | Sh | ow Closure Settin | gs |

In Position Variable Details, press {Show Closure Settings}.


The Closure Settings panel will appear.

| ← Position Variable P000 | : | |
|--------------------------|----------|------------------|
| Closure Settings | | |
| I THE REAL | | |
| Front O Rear | Up ODown | Flip No Flip |
| S < 180 | R < 180 | T < 180 |


- 4 Teaching
- 4.6 User Variables

Front / Rear

This specifies where in the S-axis rotation center the B-axis rotation center is located when viewing the L-axis and U-axis from the right-hand side. Noted that when viewed from the right-hand side, the right of the S-axis rotation center is called the front, and the left is called the back.



The diagram below shows the S-axis at 0° and at 180° . This is the configuration when the L-axis and the U-axis are viewed from the righthand side.




4-51


HW1485509

- 4 Teaching
- 4.6 User Variables

Up / Down


This specifies a type comprised of L-axis and U-axis when the L-axis and U-axis are viewed from the right-hand side.






Flip / No Flip

When the angle of the B-axis is within (+) range ($\theta B \ge 0^\circ$), it is called "Flip", and when within (-) range ($\theta B < 0^\circ$), "No Flip".






- 4 Teaching
- 4.6 User Variables

S-Axis Angle

This designation is required for manipulators that have working envelopes greater than $\pm 180^{\circ}$.


This specifies whether the S-axis angle is less than $\pm 180^{\circ}$ or greater than $\pm 180^{\circ}$.



Note that θS is the angle when the S-axis home position is 0° .

R-Axis Angle

This specifies whether the R-axis angle is less than $\pm 180^{\circ}$ or greater than $\pm 180^{\circ}$.



Note that θR is the angle when the R-axis home position is 0° .


4-53

- 4 Teaching
- 4.6 User Variables

T-Axis Angle

This specifies positions of the R-, B- and T-axis.

For manipulators with wrist axes (three axes), this specifies whether the T-axis angle is less than $\pm 180^{\circ}$ or greater than $\pm 180^{\circ}$.



Note that θT is the angle when the T-axis home position is 0° .

- 4 Teaching
- 4.6 User Variables

4.6.4 Specifying Motion Commands using Position Variables

When the position variable is used for specifying its position during the movement, a Motion command can be used. Using this command allows operators to specify positions, using specific numerical values. Position values can easily be modified too. Position variables can also be used as target position data for motion instructions, and as incremental values for parallel shift instructions.

- 1. Open the job.
- 2. Go to {COMMANDS} from the Navigation Bar.



- 3. Select the {Motion} tab.
- 4. Insert check to the {Show advanced commands} checkbox.
- 5. Select the desired motion command. The options are:
 - JointMove
 - LinearMove
 - CircleMove
 - SplineMove

(JointMove is selected as an example step.)

- The motion command is added to the job.

| Favorites | General | Motion | I/O | Math | Control | | JILDER |
|-----------|--------------|--------|-----|------|------------------------------------|---|------------|
| Show | advanced cor | nmands | | | | | <i>(i)</i> |
| jê Joi | intMove | | | | iable by joint in current robot | nterpolation. **This position** | ☆ |
| 🚔 Line | earMove | | | | iable by linear | interpolation. t robot position** | ☆ |
| Ê Circ | cleMove | | | | | ar interpolation. t robot position** | ☆ |
| 🚔 Spli | ineMove | | | | iable by spline NOT the curren | interpolation. t robot position** | ☆ |

- 6. Press the detail edit button on the job line to the right.
 - The Detail Edit panel will appear.

- 4 Teaching
- 4.6 User Variables
- 7. In the Position under Variable tab, insert the desired position variable number or select from the variable list using Browse Variables.

Fig. 4-29: Inserting Position Variable Number

| Position Data | User Variable | Loc Varia | | _ | Position Data | User Variable | Local Variable |
|---------------|------------------|--------------|-------------|---|---------------|------------------|---------------------|
| Browse | Variables | Array VAF | 2: Unused 💌 | | Brow | vse Variables | Array VAR: Unused V |
| | (P)osition | Variable | | | | (P)osition \ | Variable |
| 1 | 2 | 3 | × | | | Search | by Name Q |
| | | | | | No.▼ | Name | |
| 4 | 5 | 6 | 120 | | 0 | Approach | |
| | | | | | 1 | | |
| 7 | 8 | 9 | Enter | | 2 | PlacePos | |
| C |) | | Enter | | 3 | Conveyor | |
| | | | | | 4 | PickPos | |

8. Change the tab from Variable to Position Data.




9. Move the manipulator to the desired position.

Fig. 4-30: Browsing Position Variable Number

- 4 Teaching
- 4.6 User Variables

10. Press {RE-TEACH}

- The current manipulator position will be registered.



4.6.5 Deleting Variable

Variables can be overwritten.

- For Byte, Integer, Double and Real Variable, insert "0" to the value and delete the name. Press {save}.
- For String Variable, clear the value and delete the name. Press {save}.
- For Position Variable, insert all "0" and press {save}

4-57

HW1485509

- 4 Teaching
- 4.7 Monitoring Variables

4.7 Monitoring Variables

4.7.1 Monitoring Variables using Watch Window

User variables can be monitored using the Watch Window, placed under {Program/Operate} in {MENU}. The following variables can be monitored.

Register Items on the Watch Window for Variables:

- Byte type variable (B-variable)
- Integer type variable (I-variable)
- Double integer type variable (D-variable)
- Real type variable (R-variable)
- String type variable (S-variable)
- Position type variable (P-variable)



For using the Watch Window to monitor I/O signal, refer to *chapter 7.4.1 "Monitoring I/O Signals by I/O Monitor"*.

To maximize each panel, press the expand icon on the right-hand side of the title of variable, position and I/O. Press it again to change the panel back to its original size.

| < v | Vatch Windo | w | | | | ∎≢ C | LEAR ALL |
|----------|-------------|----------|------------|----------|----------|------------|----------|
| Variable | 57 29 | Q BROWSE | ARIABLES | Position | 57 29 | Q BROWSE P | OSITIONS |
| No. | Contents | Name | B F | No. | Name | Tool | Ī |

The values shown in the Watch Windows are updated every second.

- 4
- Teaching Monitoring Variables 4.7

Fig. 4-31: Watch Window

| sputs/Outputs (I/O) 53 | ÷ | Watch Windo | | | | | | | |
|--|---------|---------------|------------|----------|----------|--------|------|----------|-----------|
| sputs/Outputs (I/O) | ariable | es KN | Q BROWSE | ARIABLES | Position | | Q | BROWSE P | OSITIONS |
| | lo. | Contents | Name | Ē | No. | Name | | Tool | Ĩ |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| put Status Name 📑 Output Status Name 📑 | | | | | | | | | |
| | puts/ | Outputs (I/O) | 5.7 2.3 | | | | | Q BF | ROWSE I/C |
| | | | | Ĩ | Output | Status | Name | Q BF | |
| | | | | Î, | Output | Status | Name | Q BF | |
| | | | | i: | Output | Status | Name | Q BF | |
| | | | | Ū: | Output | Status | Name | Q BF | |
| | | | | Ţ. | Output | Status | Name | Q BF | |
| | | | | Ĩ | Output | Status | Name | Q BF | |
| | | | | Ţ, | Output | Status | Name | Q BF | |
| | nputs/ | | | ₿? | Output | Status | Name | Q BF | |

HW1485509

- 4 Teaching
- 4.7 Monitoring Variables

4.7.1.1 Variables (Byte / Integer / Double / Real / String)

1. Press {BROWSE VARIABLES} in Variables section under {Watch Window}.

| ÷ | Watch Windo | w | | | E CI | EAR ALL |
|--------|-------------|----------|-----------|-------|-------------|---------|
| Variab | les Ka | Q BROWSE | VARIABLES | tions | Q BROWSE PC | SITIONS |
| No. | Contents | Name | Te No. | Name | Tool | |

2. Select the type of variables from the tab. (Byte type is chosen in the example.)

| ables | | | Display only named | Search by name | Q |
|-------|-------------|------------------------|--|---|--|
| | Integer | Double | Real | String | |
| No. | | Value Name | | | |
| B000 | | 0 | | | |
| B001 | | 0 | | | |
| | No. B000 | Integer No. B000 | Integer Double No. Value Name B000 0 | Integer Double Real No. Value Name B000 0 | Integer Double Real String No. Value Name B000 0 |

- 3. Add a check in the checkbox beside a variable to view its value.
- 4. Press {UPDATE VARIABLES}.



5. Selected Variables are now available to watch on the Watch Window.

| ← Watch Window | | | | LEAR ALL | | | |
|----------------|----------|--------------|--------|----------|--------|------|---------|
| Variabl | es KN | Q BROWSE VAR | IABLES | Positio | ons Ka | | SITIONS |
| No. | Contents | Name | Ĩ. | No. | Name | Tool | Ĩ: |
| B000 | 48 | | | | | | |

- 4 Teaching
- 4.7 Monitoring Variables

4.7.1.2 Positions

1. Press {BROWSE POSITIONS} in the Positions section under {Watch Window}.



- 2. Add a check in the checkbox for the Position to view its value.
- 3. Press {UPDATE POSITIONS}.



4. Selected Positions are now available to view in the Watch Window.

| 4 | Watch Windo | w | | | | ∎ , c | LEAR ALL |
|--------|-------------|----------|----------|---------|--------|------------------|------------|
| Variab | les KN | Q BROWSE | ARIABLES | Positio | ons KA | Q BROWSE PO | SITIONS |
| No. | Contents | Name | ÎF | No. | Name | Tool | T F |
| | | | | P000 | | Tool 03 | |

5. Tap the Position to view its values.

4-61

 The left figure shows for the joint angle type, and right figure shows for the remaining reference types.

| ÷ | P000 | Tool #00 | ÷ | P000 | Tool #00 |
|---|--------------|----------|-------|----------|-------------------|
| | Axis Positio | ons | TCP P | osition | Frame & Closure |
| | (S)wing | 0.00° | x | 0.00 mm | Type: Robot Frame |
| | (L)ower | 0.00° | Y | 0.00 mm | Front, Up, Flip |
| | (U)pper | 0.00° | z | 0.00 mm | S < 180 |
| | (R)otate | 0.00° | Rx | 0.00 deg | R < 180 |
| | (B)end | 0.00° | Ry | 0.00 deg | T < 180 |
| | (T)wist | 0.00° | Rz | 0.00 deg | |
| | | | | | |

- 4 Teaching
- 4.7 Monitoring Variables

4.7.2 Monitoring Variables using Variable Setting Screen

The Variables screen can be used to observe or monitor the current value of the variables.

- 1. Select {Program/Operate} under {MENU}.
- 2. Select the Variable Type to view Setting Byte, Integer, Double, Real, or Position by touching the Variable Type Name.

- The value updates every second when the program is running.

| | | l 📃 | SERVO | | F 2 |
|-----------|---------|--------------|-------|---------|--------------|
| - Variabl | es | | | | () |
| Byte | Integer | Double | Real | String | Position |
| No. 🔺 | Value | Binary Value | Name | Display | only named Q |
| B000 | 0 | 0000 0000 | | | |
| B001 | 10 | 0000 1010 | COUNT | | |
| B002 | 100 | 0110 0100 | | | |


The user can also select to see only the variables that are named.

- 4 Teaching
- 4.8 Local Variables

4.8 Local Variables

.

Local Variables are variables that are used only within its particular job. These are useful for temporary operations as they cannot be read or changed from other jobs, whereas User Variables can be read or changed. Some of its usage are for: loop counters, temporary calculations, and input signals storage. This section describes additional settings that are available relating to Local Variables



User Variables

| Job 1 | Job 2 | Job 3 |
|----------------|----------------|----------------|
| Local Variable | Local Variable | Local Variable |
| LB001 | LB001 | LB001 |
| | | |

Local Variables

4 Teaching

4.8 Local Variables

4.8.1 Local Variable

4.8.1.1 Allocation

Local Variables need to be configured at first to be used.

- 1. Select {Job List} under {MENU}.
- 2. Select the particular job from the list of job.
- 3. Press the {Additional Settings} expansion icon at the bottom of the Job Details panel.
 - This will pull up a new panel for Additional Settings.

| Job Details: SAMPLE | | \sim |
|---------------------------------------|------------------------|--|
| Date 2017-07-19 10:01 AM | Lines 3 | (j) |
| Job Name SAMPLE | Type Robot Job | ~ |
| Tag e.g. job tag or keyword | Controlling Robot 1 | ~ |
| Comment e.g. comment about the job | 0 | ; job the Default Job ob to disable editing |
| Additional Settings | | |

- 4. Under the {Local Variable Allocation}, enter a number between 0 and 255 for the amount of variable to allocate, next to the desired variable type.
 - Example: the figure shows allocating 10 Local Byte (LB) variables.
 Thus, LB000 to LB009 will be usable inside the job.

| Additional Setti | dditional Settings | | | | | \sim |
|------------------|--------------------|---|--------|-----------|--------|----------|
| Local Variable A | Allocation | | Job Ar | gument Na | mes | |
| Byte (LB) | 10 | | + NE | W ARGUME | NT | <u> </u> |
| Integer (LI) | 0 | | | | | |
| Double (LD) | 0 | | | | | |
| Real (LR) | 0 | | | | | |
| String (LS) | 0 | | | | | |
| | | | RIGHT | • • | CLEAR | |
| | | | | | | |
| | | 1 | 2 | 3 | × | |
| | | | - | (| | |
| | | 4 | 5 | 6 | - | |
| | | 7 | 8 | 9 | | |
| | | | | | Enter | |
| | | (|) | | (Save) | |
| | | | | | (Save) | |
| | | | | | | |

4-64

- 4 Teaching
- 4.8 Local Variables

4.8.1.2 Entering Local Variables

After Local Variables have been allocated for a particular job, they can be used by changing variable type to Local Variable in the Detail Edit panel. Only available Local Variables types will be shown (i.e. types that have been allocated for a particular job).

Example: the Position Level parameter can be set as B, I, or D User Variable type. However, only LB and LI Local Variables types are shown because no LD variables have been allocated for this job.

| Detail Edit: JointMove | e Job Line #: 5 Job | Step #: 1 | × CANCE | L) 🤇 | SAVE ALL |
|------------------------|---------------------|--|------------------|--------------|-----------------|
| | | Constant | User Variable | Loo Varia | |
| Motion Type | JointMove | Specifies the app the taught positi | | | nipulator passe |
| Position | P000 | | | Array VA | R: Unused |
| Speed | 0.01 | (LB)yt | e | 0.1 | Integer |
| Position Level | LB000 🙁 | | | (1) | integer |
| Acceleration | Unused | 1 | 2 | 3 | × |
| Deceleration | Unused | | | | |
| Comment | Unused | 4 | 5 | 6 | |
| | | 7 | 8 | 9 | |
| | | 0 | | | Enter |

4-65

- 4 Teaching
- 4.8 Local Variables

If no Local Variables that can be used with particular parameters are allocated, the following message will be displayed.

| | | | | × |
|--------|------------|-------------------------------------|-------------------|---|
| | Constant | User Variable | Local Variable | |
| | | | | |
| \leq | | | | |
| | | | | |
| | | | | |
| | Variable | | used for this | |
| | | er. Press Cur below to cor s. | | |
| | _ | | | |
| | <u>+++</u> | CURRENT JO | B SETTINGS | |
| | | | | |
| | | | | |

Press the {CURRENT JOB SETTINGS} to show a subpanel where the Local Variables can be allocated.

| Job Settings - S | AMPLE | | | × |
|------------------|------------|-----------------|----------|--------------|
| Local Variable A | Allocation | Job Argument Na | mes | (i) |
| Byte (LB) | 0 | + NEW ARGUME | NT | |
| Integer (LI) | 0 | | | |
| Double (LD) | 0 | | | |
| Real (LR) | 0 | | | |
| String (LS) | 0 | | | |
| Position (LP) | 0 | | | |
| | | | | |
| t _t | B= | | COMMANDS | |
| DIGITAL I/O | VARIABLES | JOGGING | COMMANDS | TEST/RUN JOB |

- 4 Teaching
- 4.8 Local Variables

Because Local Variables only exist in its job they must be defined before being used. For example, to set the Position Level as an LB variable, this could first be initialized using the Set command:



4.8.1.3 Usage of Local Variable

Some useful way to use Local Variable is shown below.

- ① User can guarantee to not accidentally modify a value that is used in a different job by using Local Variables.
 - Example: Using a Local Variable for a For loop index If I004 was used instead of LI004, the job would change the value of a Global Variable which could be used in another job.



2 Use for temporary mathematic operations.

 Example: Set the JointMove speed to "B010*2" without overwriting any Global Variables.

| Set LB001 0 |
|--|
| Add LB001 B010 |
| Multiply LB001 2 |
| <pre>JointMove P000 Speed=LB001(%)</pre> |



- 4 Teaching
- 4.8 Local Variables

4.8.2 Job Arguments

Job Arguments are a way to pass variables and data from one job to another with a use of Call and GetArgument command. For example, a user may want to pass the position of a part to a subroutine (child job) that executes the picking motions. To use Job Arguments, the basic procedure is:

- 1. Configure the child job using the Additional Settings panel
- 2. Add the Call command with arguments in the parent job
- 3. Add the GetArgument command in the child job to get values
- 4. Store values in local variables

4.8.2.1 Configuration

- 1. Select {Job List} under {MENU}
- 2. Select the particular job from the list of job.
- 3. Press the {Additional Settings} expansion icon at the bottom of the Job Details panel.
 - Under the {Job Argument Configuration}, there will be no named Job Arguments by default.

| Additional Setti | ngs | | \checkmark |
|------------------|------------|--------------------|--------------|
| Local Variable A | Allocation | Job Argument Names | <i>(i)</i> |
| Byte (LB) | 10 | + NEW ARGUMENT | |
| Integer (LI) | 0 | | |
| Double (LD) | 0 | | |
| Real (LR) | 0 | | |
| String (LS) | 0 | | |
| Position (LP) | 0 | | |

- 4. Press the {+ NEW ARGUMENT} to name a new argument.
 - A default argument named "Arg#" (e.g. Arg1, Arg2, Arg3) is created.
 - A job can have up to 8 Job Arguments

| Job | Argument Names | |
|-----|----------------|--|
| 1: | Arg1 | |
| 5 | + NEW ARGUMENT | |

- 4 Teaching
- 4.8 Local Variables
- 5. Select the "Arg#" to name the Job Argument.
 - Entering a name is optional
 - 0 to 16 characters can be used for a name

| Additio | onal Setti | ngs | | | | | | | | < | |
|---------|------------|-----------|------------------------|------|----------|----------|----|---|---|------------|--|
| Local | /ariable A | llocation | | Jo | b Argume | ent Name | es | | | <i>(i)</i> | |
| By | te (LB) | 10 | | 1: | MyArg | ument | | | | | |
| Integ | ger (LI) | 0 | | | + NEW AF | GUMENT | | | | | |
| Doub | le (LD) | 0 | | | | | | | | | |
| Re | al (LR) | 0 | | | | | | | | | |
| Strin | ng (LS) | 0 | | | | | | | | | |
| SYMBO | DL | | LE | FT F | RIGHT 🕨 | CLE | AR | | | - | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | # | |
| q | w | е | r | t | у | u | i | 0 | р | × | |
| a | s | C | I f | g | , h | j | k | : | E | Inter | |
| ¢ | z | x | С | v | b | n | m | - | • | ¢ | |
| | space | | | | | | | | | | |



Argument name will be visible from the Job Contents view, so it is useful to give a descriptive and unique name.

- 4 Teaching
- 4.8 Local Variables

4.8.2.2 Using Job Arguments

The following steps describes the basic procedure for using Job Arguments with an example. This involves a parent job (named as "PARENT_JOB1") that will call into a child job (named as "CHILD_JOB1") with arguments. The child job uses three arguments:

- 1 Double (D) value to be used as a Speed parameter
- 1 Integer (I) value to be used in a Timer
- 1 Position (P) value to be used as a Shift value
- 1. Configure the Local Variables allocation for the child job.
 - For using these parameters in the child job, at least one LD, LI, and LP variable will need to be allocated, as shown in the figure.
 - For more information on configurating the Local Variable, refer to *chapter 4.8.1.1 "Allocation"*.

| Additional Sett | ings | | \sim |
|-----------------|------------|--------------------|--------|
| Local Variable | Allocation | Job Argument Names | |
| Byte (LB) | 0 | + NEW ARGUMENT | |
| Integer (LI) | 1 | | |
| Double (LD) | 1 | | |
| Real (LR) | 0 | | |
| String (LS) | 0 | | |
| Position (LP) | 1 | | |

- 2. Configure the Job Arguments Names for the child job.
 - Three arguments are named.
 - For more information on configurating the Job Arguments, refer to chapter 4.8.2.1 "Configuration".

| Additional Settir | ngs | | \checkmark |
|-------------------|-----------|--------------------|--------------|
| Local Variable A | llocation | Job Argument Names | <i>(i)</i> |
| Byte (LB) | 0 | 1: Speed | |
| Integer (LI) | 1 | 2: Delay | |
| Double (LD) | 1 | 3: ShiftVal | |
| Real (LR) | 0 | + NEW ARGUMENT | |
| String (LS) | 0 | | |
| Position (LP) | 1 | | |

- 3. Open the parent job (PARENT_JOB1) from the Job List.
- 4. Under Navigation Bar, press {COMMANDS}.

| î, | B= | 2 | <> | | |
|-------------|-----------|---------|----------|--------------|--|
| DIGITAL I/O | VARIABLES | JOGGING | COMMANDS | TEST/RUN JOB | |



- 4 Teaching
- 4.8 Local Variables
- 5. Add a Call command, which can be found under {Control} command group as an advanced command.
 - Parameter names (i.e. Speed, Delay, ShiftVal) are shown on:
 - the Detail Edit panel (if configured)
 - the Job Contents view (if configured)

| | | SERVO |] | |
|-------------------------------|-----------------|---------------|----------|--------------|
| Robot Job - PARENT_J | IOB1 | \leftarrow | × 1 i | |
| 1 Start Job | _ | | _ | |
| 2 Call Job:CHIL | D_JOB1 Speed=0 | Delay=0 Shift | Val=0 | \$ |
| 3 End Job | | | ТЕАСН | JOINT MOVE |
| Detail Edit: Call Jo | ob Line #: 2 | | | × |
| | | | | |
| Job Name | CHILD_JOB1 | | Search b | Name Q |
| Speed: | 0 | Job Name | ▲ Ta | g 🗘 |
| Delay: | 0 | CHILD_JOB | 1 | |
| ShiftVal: | 0 | PARENT_JC |)B1 | |
| Argument4: | Unused | | | |
| Argument5: | Unused | | | |
| Argument6: | Unused | | | |
| Argument7: | Unused | | | |
| Argument8: | Unused | | | |
| | | | | |
| T _↓ DIGITAL I/O | B= variables | | COMMANDS | TEST/RUN JOB |

6. Select the Job Name from the list on the right.

4-71

- 4 Teaching
- 4.8 Local Variables
- 7. Insert values into arguments.

- These values will be passed to the Child job's argument list.

| Detail Edit: Call Jo | ob Line #: 2 | | | | | × |
|----------------------|-----------------|--------|-----------------------|------------------|--------------|--------------|
| | | С | onstant | User Variable | Loo Varia | |
| Job Name | CHILD_JOB1 | | | | | |
| Speed: | 5000 😵 |] < Se | | of constan | t value to | enter: |
| Delay: | 1050 | |) Integer) String | | | |
| ShiftVal: | P001 | | | | | |
| Argument4: | Unused | | 1 | 2 | 3 | × |
| Argument5: | Unused | | | | | |
| Argument6: | Unused |] | 4 | 5 | 6 | |
| Argument7: | Unused |] | 7 | 8 | 9 | Enter |
| Argument8: | Unused |] | | 0 | | Enter |
| ↑ DIGITAL I/O | B= variables | | | COMMANDS | į. | FEST/RUN JOB |

- 8. Open the child job (CHILD_JOB1) from the Job List.
- 9. Under Navigation Bar, press {COMMANDS}.

| | B= | 2 | <> | • |
|-------------|-----------|---------|----------|--------------|
| DIGITAL I/O | VARIABLES | JOGGING | COMMANDS | TEST/RUN JOB |


- 10. Add a GetArgument, which can be found under {Control} command group as an advanced command.
 - GetArgument has two parameters:
 - "Result" parameter: stores the passed argument value. This value must be a Local Variable.
 - "Argument #" parameter: refers to which Argument to get. If this is entered as a constant (i.e. 1-8), the argument name will be displayed at the end of the line in the Job Contents view (shown as "Speed" below).

2 GetArgument LD000 InputArgument#(1) //Speed

If the argument # parameter is entered as a variable, the argument name will not be shown in the Job Contents view.

2 GetArgument LD000 InputArgument#(B000)

4-72




- 4 Teaching
- 4.8 Local Variables
- 11. The Job Contents for both the Parent and Child Job is shown below. The result of these operations would be:
 - LD000 = 5000
 - LI000 = Value of I050
 - LP000 = Value of P001


| Parent Job | |
|--|--|
| 1 Start Job | |
| 2 Call Job:EX_CHILD Speed=5000 Delay=I050 Shift | Val=P001 |
| 3 End Job | |
| Child Job | |
| 1 Start Job | LD000=5000 |
| <pre>2 GetArgument LD000 InputArgument#(1) //Speed</pre> | LI000=Value of I050 LP000=Value of P001 |
| <pre>3 GetArgument LI000 InputArgument#(2) //Delay</pre> | |
| 4 GetArgument LP000 InputArgument#(3) //ShiftVal | |
| 5 ShiftOn LP000 | |
| <pre>6 JointMove Speed=LD000(%)</pre> | |
| 7 Timer Time=LI000(seconds) | |
| 8 End Job | |

4.8.2.3 Job Argument Type Conversion

The safest way to use the Call and GetArgument instructions is to always make sure that the types match between the two instructions. For example, if Argument 1 in the Call instruction is a B variable, then the GetArgument should copy this value into an LB variable. Similarly, if Argument 2 in the Call Instruction is a P variable, then GetArgument should copy this value into an LP variable.



In the case where incompatible types are used (e.g. Argument 1 in the Call Instruction is a P variable and GetArgument tries to set this into an LI variable), the alarm below will be shown during job execution.







171 of 493

4 Teaching

4.8 Local Variables



However, there are some cases where conversion of parameter types is allowed. For example, if a B Variable is passed in Call Instruction, it can always be copied into a LD Variable in GetArgument as the allowable range of the LD Variable is larger than the B Variable. If a D Variable is passed in Call Instruction, it can be copied into a LB Variable in GetArgument as long as the value of the D variable is between 0-255 which is the allowable range of a LB Variable. Otherwise, the same alarm shown above will be generated.



The following table shows the available type conversions.

| Argument Type passed from Call Instruction | | | | | | | | | |
|--|----|-----------------|------------------|------|------|------|------|------|------|
| | | Const String | Const Integer | B/LB | I/LI | D/LD | R/LR | S/LS | P/LP |
| t | LB | NO | YES* | YES | YES* | YES* | NO | NO | NO |
| Type gument ction | LI | NO | YES* | YES | YES | YES* | NO | NO | NO |
| ult Type tArgume truction | LD | NO | YES | YES | YES | YES | NO | NO | NO |
| Result GetArç Instruc | LR | NO | YES | YES | YES | YES | YES | NO | NO |
| | LS | YES | NO | NO | NO | NO | NO | YES | NO |
| . <u></u> | LP | NO | NO | NO | NO | NO | NO | NO | YES |

*Value of variable passed in Call Instruction must be within the range of the variable assigned in GetArgument.

- 4 Teaching
- 4.9 Teaching Coordinate

4.9 Teaching Coordinate



Teaching Coordinate (also known as Relative Job on the YRC Pendant) is a purchased option that may or may not be included with the system.

The Teaching Coordinate of a Job defines the coordinate system that is used for teaching positions. By default, the Teaching Coordinate is set to Joint; however, a user can change to the following values:

- Joint
- Robot
- World
- User

Changing the Teaching Coordinate converts all taught positions inside the job to a new type. For example, if changing the Teaching Coordinate from Joint to Robot, all current positions are converted to X/Y/Z/Rx/Ry/Rz data and any new positions are taught with X/Y/Z/Rx/Ry/Rz data.

The most common use case for changing Teaching Coordinate is to use User Frame Coordinates to define re-usable jobs relative to workspace objects such as pallets. An application example of this is shown in *chapter 4.9.2 "Application Example"*.

World and Robot coordinates are often useful as X/Y/Z/Rx/Ry/Rz data is easier to read and interpret than Joint positions. These coordinates are also used for offline teaching. For more details about offline teaching, please refer to "YRC1000 OPTIONS INSTRUCTIONS FOR RELATIVE JOB FUNCTION (HW1483390) chapter 4 or YRC1000micro OPTIONS INSTRUCTIONS FOR RELATIVE JOB FUNCTION (HW14884476) chapter 4. Interface with an Easy Offline Teaching System"



4-75

Changing Teaching Coordinate will only affect motion instructions taught using {TEACH} and not motion instructions inserted from Commands panel.

- 4 Teaching
- 4.9 Teaching Coordinate

4.9.1 Changing Teaching Coordinate

Use the following steps to change Teaching Coordinate:

- 1. Select {Job List} under {MENU}
- 2. Select the particular job from the list of jobs.
- 3. Press the {Additional Settings} expansion icon at the bottom of the Job Details panel.

Fig. 4-32: Additional Settings

| Job Details: SAMPLE | | \sim |
|----------------------------|-----------------------------------|--------|
| Date | Lines | |
| 2019-06-11 05:23 AM | 4 | |
| Job Name | Туре | |
| SAMPLE | Robot Job | ~ |
| Tag | Controlling | |
| e.g. job tag or keyword | Robot 1 | \sim |
| Comment | 🔲 🕝 Make this job the Default Job | |
| e.g. comment about the job | Lock the job to disable editing | |
| Additional Settings | | ^ |

- This pulls up a new panel for Additional Settings

Fig. 4-33: Additional Settings Panel

4-76

| Additional Settin | ngs | | \sim |
|---------------------------|-----|--------------------|--------|
| Local Variable Allocation | | Job Argument Names | () |
| Byte (LB) | 5 | | |
| Integer (LI) | 10 | | |
| Double (LD) | 0 | | |
| Real (LR) | 0 | | |
| String (LS) | 0 | | |
| Position (LP) | 0 | | |
| | 0 | | |
| | | | |
| Robot | | | |
| | | | |



If Teaching Coordinate is not available on the system, this control is grayed out and a notification explains why it is unavailable when pressed

- 4 Teaching
- 4.9 Teaching Coordinate

When converting from World/Robot/User back to Joint, the YRC Controller will calculate the resulting joint positions by executing the motions internally starting from the current Robot position. Thus, when doing this conversion, the Robot should be moved to the expected starting position of job. If the Robot is not in the expected starting position, this operation may convert to the wrong path. Confirm the motion path before playing the job.



For more information, refer to the "YRC1000 OPTIONS INSTRUCTIONS FOR RELATIVE JOB FUNCTION (HW1483390)" or "YRC1000micro OPTIONS INSTRUCTIONS FOR RELATIVE JOB FUNCTION (HW1484476)".

4. The popup menu opens with three buttons:

4-77

- {Cancel} do not change Teaching Coordinate
- {Create New} Create a new job with changed Teaching Coordinate. This new job will have "-CONV#" appended to the end (e.g. "SAMPLE" becomes "SAMPLE-CONV1"). This is the recommended action as some position information can be lost in the conversion between different coordinate types.
- {Convert Current} This will convert the current job without making a new job. Only perform this action if converting a new job or if the information in the job is no longer needed.



When converting to a User Frame, there will be a Drop-down list to select the desired User Frame #. In *fig.* 4-34, User Frame #10 is selected.

4 Teaching

4.9 Teaching Coordinate

Fig. 4-34: Selecting User Frame

| Teaching Coo | ordinate Conversion | × |
|-----------------|---|-------|
| positions in th | nching Coordinate will modify all taught ne job. For existing jobs, it is recommende job rather than modifying the current job. | ed to |
| | erting from Joint to World/Robot/User ba ulting Joint positions may be different from ons. | |
| User Frame: | 10: Pallet ~ | |
| × CANCEL | (Recommended) | |



Converting from Joint to World/Robot/User and back to Joint may not result in the original Joint Positions being recovered. Because of this, it is recommended to make a copy of a job when converting Teaching Coordinate.

- 5. Teaching Coordinate is now changed. To verify, open the new job and check:
 - The new Teaching Coordinate displays on the Inform Header after the Job Name. In this example, the Teaching Coordinate is "User #10".
 - The new Teaching Coordinate displays at the top of the Position Data panel.

4-78

 When viewing the position data, the data should display in the correct format. In this example, the data is listed in X/Y/Z/Rx/Ry/Rz relative to User Frame #10.



Changing Teaching Coordinate will not change the data in global Position Variables. Thus, motion instructions using Position Variables (e.g. "JointMove P001 Speed=50.00") will not be modified.

- 4 Teaching
- 4.9 Teaching Coordinate

Fig. 4-35: Verifying Teaching Coordinates



4 Teaching


4.9 Teaching Coordinate

4.9.2 Application Example

The most common Teaching Coordinate to use is "User". This can be used in combination with User Frames and the "Call" instruction to re-use code to perform complex operations.

For example, consider the application in *fig. 4-36* where a Robot needs to perform the same actions for workpieces in three different locations.

Fig. 4-36: Robot with Three Workstations




The basic procedure for using Teaching Coordinate to accomplish this is as follows:

- 1. Create a job for a single Workpiece (e.g. "WORKPIECE")
- 2. Teach a User Frame (e.g. UF#1) for the workpiece in that location.
- 3. Change the Teaching Coordinate of the job created in *step 1* to the User Frame taught in *step 2*.
- 4. Move to another workpiece location and teach a new User Frame (e.g. UF#2).
- 5. Repeat step 4 for all workpiece locations.

4-80

6. Specify the User Frame when calling the "WORKPIECE" job from the controlling job as shown in *fig. 4-37*. As long as the Teaching Coordinate of the called job is "User", this will override the internal User Frame # and use the User Frame # in the parameter instead.

Fig. 4-37: Sample Code



- 4 Teaching
- 4.9 Teaching Coordinate



- To execute the JOB using the UserFrame parameter in Call Instruction, the Teaching Coordinate of the called JOB should be also User Frame. If Teaching Coordinate is not User Frame, the JOB will work on its own coordinate.
- Calling the JOB with UserFrame parameter also applies to Position Variables where the Ref.Coord is set to User coordinate.

HW1485509

HW1485509

- 5 Playback
- 5.1 Preparation for Playback

5 Playback

5.1 Preparation for Playback

5.1.1 Selecting a Job


Playback is the act of executing a job. Begin by opening the job to be executed.

5.1.1.1 Open a Job

- 1. Change the mode switch from MANUAL (TEACH) mode to AUTOMATIC (PLAY) mode.
 - The mode icon on the Status Bar will change to the AUTOMATIC (PLAY) mode icon.



2. Select {JOBS} on the Home Screen.



- 5 Playback
- 5.1 Preparation for Playback
- 3. Select the desired job from the list and press {RUN}.

| - Job L | ict | | | (+) NEW JOB | | | Search | n by name | Q |
|-------------|---|---------|------|-------------|--|------------|-------------|--------------------------|---|
| 5001 | .151 | | | () HEN SOD | | | Jearci | i by name | ~ |
| Job Name 🖌 | • | Т | ag 🕯 | • | Edited | \$ | | Attributes | G |
| ONGJOB | | | | | 2017-0 | 7-19 0 | 8:54 AM | \$ | |
| SAMPLE | | | | | 2017-0 | 7-19 1(| 0:01 AM | DOUT MOWE BND | |
| FTHEN | | | | | 2017-0 | 7-19 08 | 8:56 AM | | |
| ONGJOB | | | | | 2017-0 | 7-19 0 | 8:54 AM | 52 | |
| SAMPLE | | | | | 2017-0 | 7-19 1(| 0:01 AM | DOUT NOVE | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| Job Details | : SAMPLE | | | | | | | | ~ |
| Job Details | | | | | Lines | | | | ~ |
| Job Details | Date | -01 AM | | | Lines | | | | ~ |
| Job Details | | :01 AM | | | Lines 3 | | | | ~ |
| Job Details | Date 2017-07-19 10: | :01 AM | | | 3 | | | | ~ |
| Job Details | Date 2017-07-19 10: Job Name | :01 AM | | | 3 Туре | | | | ~ |
| Job Details | Date 2017-07-19 10: | :01 AM | | | 3 | b | | ~ | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE | :01 AM | | | 3 Type Robot Jo | | | ~ | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE | | | | 3 Type Robot Jo Controllir | | | ~ | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE | | | | 3 Type Robot Jo | | | ~ | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE Tag e.g. job tag or k | | | | 3 Type Robot Jo Controllir Robot 1 | ıg | | ~ | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE Tag e.g. job tag or k Comment | xeyword | | | 3 Type Robot Jo Controllir Robot 1 | ıg | this job ti | ~ ~ he Default Job | ~ |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE Tag e.g. job tag or k | xeyword | | | 3 Type Robot Jo Controllir Robot 1 | ng Make | | | ~ |
| | Date 2017-07-19 10: Job Name SAMPLE Tag e.g. job tag or k Comment e.g. comment a | xeyword | | | 3 Type Robot Jo Controllir Robot 1 | ng Make | | | |
| Job Details | Date 2017-07-19 10: Job Name SAMPLE Tag e.g. job tag or k Comment e.g. comment a | xeyword | | | 3 Type Robot Jo Controllir Robot 1 | ng Make | | | ~ |


HW1485509

- 5 Playback
- 5.1 Preparation for Playback


5.1.2 Test/Run Job Panel

When the mode switch on the Smart Pendant is switched to "AUTOMATIC (PLAY)" while displaying the Job Contents view, the Test/Run Job panel appears.

Fig. 5-1: Test/Run Job Panel



5.1.2.1 Operation Buttons





- 5 Playback
- 5.1 Preparation for Playback

5.1.2.2 Operation Cycle

There are three types of manipulator operation cycles:

| CONTINUOUS 揻 | Executes job continuously. Job will automatically restart when the end is reached. |
|---------------|---|
| ONE CYCLE | Executes job from current line to the "End Job" line. If {RUN} is pressed again, the job will start from the beginning. |
| STEP I | Executes job one line of the program each time {RUN} is pressed. |


To change the operation cycle:

- 1. Tap {Mode} under Playback Controls.
- 2. Select the desired operation cycle.
 - The operation cycle is now changed.

| One Cy | cle | | | × |
|----------|---------------|------------|--|---|
| Select I | Playback Mode | | | |
| | CONTINUOUS | i œ | Execute job continuously. Job will automatically restart when the end of program is reached. | |
| | ONE CYCLE | ţ <u>ı</u> | Execute job once. Job will stop operation at end of program is reached. | |
| | STEP | ĬN | Execute job one instruction at a time. | |
| | | | | |

5.1.2.3 Playback Speed

Use this slider to modify the Playback Speed from 10-100%. This will scale all programmed speeds by the specified amount. For example, if Playback Speed is set to "50%", a linear motion of 1000 mm/sec would execute at 500 mm/sec and a joint motion of 60% would execute at 30%. User can use this to verify Robot motion at a slower speed before full speed execution. This can only be done in AUTOMATIC (PLAY) mode and will revert to 100% if mode is switched back to MANUAL (TEACH) mode.



- 5 Playback
- 5.1 Preparation for Playback

5.1.2.4 Time Indicators

While the job is executing, these indicators will update with the values shown in this table.

Table 5-1: Time Indicators

| Items | Description |
|-------------------------|---|
| Moving Time (seconds) | Total time that the manipulator has moved since job execution began. |
| Playback Time (seconds) | Total time that has elapsed since job execution began (including Manipulator Idle time) |
| Servo On Time (seconds) | Cumulative time the manipulator servo power has been in the ON state since the YRC Controller was first used. |
| Power On Time (seconds) | Cumulative time the YRC Controller power has been in the ON state since the YRC Controller was first used. |

- 5 Playback
- 5.2 Playback

5.2 Playback

5.2.1 Playback Operation

Playback is the operation by which the taught job is played back.



After checking to ensure that there is no one in the Robot's workspace, or user is using a human collaborative Robot with Power and Force Limiting (PFL) function active, start playback operation using the Smart Pendant by following the instructions below.

5.2.1.1 Selecting the Start Mode

Set the Mode Switch on the Smart Pendant to AUTOMATIC (PLAY) mode. The AUTOMATIC (PLAY) mode is enabled.

5.2.1.2 Servo ON

Press [SERVO].

 The YRC Controller servo power turns ON and the {SERVO} ON button will turn green.

5.2.1.3 Run Operation

Press {RUN}.

 The manipulator starts operation. The job will start from the selected line that the cursor is positioned. The selected line can be changed in MANUAL (TEACH) mode.

The job can be stopped or paused when the job is running by pressing {STOP} or {PAUSE}. The servo power will not turn OFF when {PAUSE} is pressed, but will turn OFF when the {STOP} is pressed. To cancel {Continuous}, switch to {One Cycle} while job is playing.

Fig. 5-2: Run Operation

| | Test 🂽 Run | (j) |
|---------------------|---------------|----------|
| Mode One Cycle 1 | Playback Spee | d |
| STOP | ► RUN | II PAUSE |

HW1485509

- 5 Playback
- 5.3 Stop and Restart

5.3 Stop and Restart

The following situations stops or automatically stops the running job or manipulator:

- Pause
- Emergency Stop
- Alarm
- Stop due to other causes

5.3.1 Pause

By the hold operation, the Job stops temporarily. "Pause" is also called "hold".

5.3.1.1 Using the Smart Pendant

Pause

Press {PAUSE} on the screen Press [PAUSE] on the membrane key

Release

Tap {RUN} on the screen to restart the operation Press [RUN] on the membrane key to restart the operation Tap {STOP} on the screen

5.3.1.2 Using an External Input Signal (System Input)

Pause

Turn ON the HOLD signal from an external input (system input)

 Release Turn OFF the HOLD signal from an external input (system input)

5.3.2 Emergency Stop

During an Emergency Stop, the servo power supply that drives the manipulator is turned OFF and the manipulator stops immediately. An Emergency Stop can be performed using the following tools:

- Emergency Stop button on the front door of the YRC Controller (some models do not have this button)
- Emergency Stop button on the Smart Pendant
- External input signal (system input)

HW1485509

- 5 Playback
- 5.3 Stop and Restart

5.3.2.1 Emergency Stop

Press the Emergency Stop button.

The servo power turns off and the manipulator stops immediately.

- Emergency Stop button on the YRC Controller (some models do not have this button)
- Emergency Stop button on the Smart Pendant

The Emergency Stop icon will appear on the Status Bar.

Fig. 5-3: Emergency Stop Icon




5.3.2.2 Release

5.3.3 Stop by Alarm

Turn the Emergency Stop button in the direction of the arrows. Emergency Stop button should lift up and indicator on Status Bar should disappear. To turn the servo power supply ON again, press [SERVO] ON. If the system is in MANUAL (TEACH) mode, make sure to also grip the Enable switch.

5.3.2.3 Restart After an Emergency Stop



To display the ALARM pop-up window again during alarm occurrence, press the Alarm icon on the status bar. To view previous alarms that are currently inactive, select {ALARM HISTORY} under {MENU}.

For more information, go to chapter 15 "Alarm".



- 5 Playback
- 5.3 Stop and Restart

5.3.4 Others

5.3.4.1 Temporary Stop by Mode Change

When the AUTOMATIC (PLAY) mode is switched to the MANUAL (TEACH) mode during playback, the manipulator stops immediately. To restart operation, return to the play mode and perform a start operation.

5.3.4.2 Temporary Stop by the PAUSE Instruction


When the PAUSE instruction is executed, the manipulator stops operating. To restart operation, perform a start operation. The manipulator restarts from the next instruction.

- 5 Playback
- 5.4 Job Stack

5.4 Job Stack

A job stack is saved as the Robot performs a series of jobs, provided the Call command is used. Job calls can be stacked up to 12 levels. For more information on the Job Call, refer to *chapter 4.8.2 "Job Arguments"*. To display the stacked job, refer to *chapter 4.5.3.6 "Display Job Stack*".





- 6 Robot Settings
- 6.1 Tool Settings

6 Robot Settings



 Data related to the system's basic functions can be modified; however, inappropriate modification may cause fatal incident or failure for the manipulator or the whole system.

Before performing Robot setting, carefully read and understand the instructions, and make sure to observe the precautions.

• Robot setting must be performed under the supervision of the administrator.

NOTICE

- Make sure to perform data storage and manage them whenever creating or modifying data.
- YASKAWA is not responsible for any incident or failure caused by inappropriate setting of data.

6.1 Tool Settings



Failure to observe this instruction will affect the performance of the Robot, particularly those with power and force limiting functions for human collaborative operation, which may result in personal injury.

Tool information is saved in tool files.

Each tool setting is broken down into three categories:

- Tool Mass Properties
- Tool Frame
- Tool I/O

- 6 Robot Settings
- 6.1 Tool Settings

6.1.1 Tool Files


Tool files store definitions for its mass, orientation, and I/O. There are 64 tool files available, numbered from 0 to 63. The active tool file must be switched if the Robot's load changes.

To set the tool information, open the tool file.

- 1. Go to {Robot Settings} under {MENU}.
- 2. Select Tools.
 - The Tools screen will appear.

| ← Tools | | Disp | olay only named | Search by name | ٩ |
|------------|------------------|--------|-----------------|----------------|-----|
| Tool No. 🔺 | Tool Name | Weight | Block I/O Na | me | |
| 0 | Parallel Gripper | 1.000 | Gripper ON | /OFF 🛞 CLEAR | I/O |
| 1 | Gripper + Load | 3.000 | Gripper ON | /OFF | |
| 2 | | 0.000 | | | |

- 3. Select tool from the list by selecting the row associated with the desired tool number.
 - Tool Detail panel of the selected tool number will appear.



- 6 Robot Settings
- 6.1 Tool Settings

6.1.2 Tool Name

A tool name can be from 0 to 16 alphanumeric characters in length, including the minus (-) symbol. The Name must start with letters. The same tool name can be used multiple times.

Fig. 6-1: Tool Name

| Tool #0: Parallel Gripper | | | |
|---------------------------|-------------|---|---|
| Name | Block I/O | | |
| Parallel Gripper | Grip ON/OFF | ~ | 0 |

6.1.3 Tool Mass Properties

Setting the correct Tool Mass Properties is critical to maintain system performance. For the manipulators that have Power and Force Limiting functions (e.g. MOTOMAN-HC10), the Tool Mass Properties weight, center of gravity, and moment of inertia are used to calculate external force. Therefore, these values must be entered precisely and tool setting must be updated in any case where a tool and/or workpiece is changed. For manipulators without Power and Force Limiting functions, the Tool Mass Properties are used to optimize the manipulator's motion performance. Failure to set these properties may result in non-optimal motion times.

If the active tool number is changed to a tool setting with one or multiple Tool Mass Properties containing zero values, a notification will appear directing the user to the {Tools} screen.

Fig. 6-2: Confirm Physical Settings for Active Tool




On the {Tools} screen, warning icons will appear near any setting(s) that may affect the performance of the manipulator. These values should be properly entered before finalizing the details of a job.


Fig. 6-3: Warnings for Critical Tool Settings Containing Zero Values

| Weig | ht 🚺 ——— |
|----------------|-----------------|
| W | 0.000 kg |
| Cent | er of Gravity 🚺 |
| X_{G} | 0.000 mm |
| Y _G | 0.000 mm |
| Z _G | 0.000 mm |
| | |

- 6 Robot Settings
- 6.1 Tool Settings

Tool Mass Properties include the weight, a center of gravity position, and moment of inertia at the center of gravity of the tool installed at the flange. A visual representation of each is provided in *fig. 6-4*.






6.1.3.1 Weight

The total weight of the installed tool is set in kg. For a standard industrial Robot, it is recommended to set a value slightly greater than the actual load. Round up the value between 0.5 to 1.0 kg for small and medium size Manipulator. For a Collaborative Robot, use the weight of the tool assembly-as measured on an accurate scale.

If the weight changes during an application, multiple tools may need to be created. For example, if the "gripper (tool)" grasps and lifts a "box (work)" off a table, tool weight is "gripper only" until the "box" is grasped. Tool weight becomes "gripper + box" after box is lifted. To reflect this accurately, two tools must be created. The first tool represents the "gripper (tool)" only and the second tool represents the "gripper + box" combined.



| W | 4.500 kg | | |
|----------------|---------------|------|-------------------------|
| Cente | er of Gravity | Mome | nt of Inertia |
| X _G | -22.000 mm | Ix | 0.000 kg-m ² |
| Y _G | 19.000 mm | ly | 0.000 kg-m ² |
| ZG | 119.000 mm | Iz | 0.019 kg-m ² |

- 6 Robot Settings
- 6.1 Tool Settings

6.1.3.2 Center of Gravity

The tool's center of gravity is defined in mm. Measurements are taken from the flange center point (FCP) in X, Y, Z direction. Enter this data as provided by the tool manufacturer or from an accurate CAD model. In the absence of this information, the center of gravity can be approximated using the Tool Load Estimation feature described in *chapter 6.1.3.4 "Automatic Estimation of Tool Mass Properties"*.

Fig. 6-6: Tool Center of Gravity

| Weigh | nt | | {္ပ်ို ESTIM |
|----------------|---------------|------|-------------------------|
| W | 4.500 kg | | |
| Cente | er of Gravity | Mome | nt of Inertia |
| X _G | -22.000 mm | Ix | 0.000 kg-m ² |
| Y _G | 19.000 mm | ly | 0.000 kg-m ² |
| ZG | 119.000 mm | Iz | 0.019 kg-m ² |

6.1.3.3 Moment of Inertia

The moment of inertia is calculated about the tool's center of gravity shown in *fig. 6-4*. The tool's moment of inertia is inserted in kg•m². Enter this data as provided by the tool manufacturer or from an accurate CAD model. In the absence of this information, the moment of inertia can be approximated using the Tool Load Estimation feature described in Section 6.1.3.4.

Fig. 6-7: Tool Moment of Inertia



- 6 Robot Settings
- 6.1 Tool Settings

6.1.3.4 Automatic Estimation of Tool Mass Properties


To ensure a Robot can achieve the speeds and force levels intended, accurate mass properties for the installed tool (and workpiece if present) must be registered. In the absence of known mass properties, Tool Load Estimation is an operation approximates this data through Robot motion. After a series of motions are completed, the selected mass properties will be updated and can be sent to the {Tools} screen for the user to review and save.



This function can only be used with floor-mounted Manipulator configurations. Also, this feature will not account for any loads applied to the upper arm (ARM Control on Software Pendant).

To estimate the mass properties of a tool load, move the manipulator to its home position (U-, B- and R-axes: horizontal to the ground) and operate the U-, B- and T-axes.

Fig. 6-8: Estimating Mass Properties of a Tool Load





To correctly estimate tool weight, center of gravity, and/or inertia, remove any cables or wires connected to the tool to prevent unnecessary loads from being applied.

On Smart Pendant, the Tool Load Estimation screen can be accessed as follows:

- 1. Go to {MENU} \rightarrow {Robot Settings} \rightarrow {Tools}
- 2. Select the desired Tool from the list at the top.

6-6

HW1485509

- 6 Robot Settings
- 6.1 Tool Settings
- 3. Press {ESTIMATE} on the mass property section of the tool's detail panel at the bottom.

Fig. 6-9: {ESTIMATE} on Tool's Detail Panel

| Weigh | t 🚺 ——— | | င့်နဲ့ ESTIMA |
|----------------|--------------|----------------|-------------------------|
| w | 0.000 kg | | |
| Center | of Gravity 🚺 | Mome | nt of Inertia |
| X _G | 0.000 mm | I _X | 0.000 kg-m ² |
| Y _G | 0.000 mm | Iy | 0.000 kg-m ² |
| ZG | 0.000 mm | Iz | 0.000 kg-m ² |

Fig. 6-10: Tool Load Estimation Screen

| | perties to Estir t + Center of G | nate Gravity + Inertia 🗸 🗸 | |
|---------|-------------------------------------|-------------------------------|---------|
| 2. Esti | mate Tool Loa | d with Robot Motion | |
| Weight | kg 🔿 | | |
| Xg | mm 🔵 | lx kg-m ² | YASKAWA |
| Yg | mm 🔵 | ly kg-m ² | |
| Zg | mm 🔿 | lz kg-m ² | |

A dialog appears if the Active Tool does not match the Tool selected from the list. These must match to perform the Tool Load Estimation procedure.



- 6 Robot Settings
- 6.1 Tool Settings

Tool Load Estimation Procedure

Three steps are required to successfully estimate the mass properties of the installed tool (and workpiece if present):

- 1. Selection of {Properties to Estimate}
- 2. Execute the motion sequences to estimate tool mass properties
- 3. Confirm, send, and save results on the {Tools} screen

Detailed instructions to complete these steps is provided in the following sections.

- 1. Selection of Physical Properties to Estimate
 - The user can select from one of two methods on the {Tool Load Estimation} screen:
- Fig. 6-11: Tool Load Estimation Screen

| | Weight | | | 🔅 ESTIM |
|---|----------------|---------------------------|------|-------------------------|
| 1. Properties to Estimate Weight + Center of Gravity + Inertia ~ | W Center | 0.000 kg of Gravity () | Mome | nt of Inertia |
| Weight + Center of Gravity + Inertia | X _G | 0.000 mm | Ix | 0.000 kg-m ² |
| Weight + Center of Gravity | Y _G | 0.000 mm | Iy | 0.000 kg-m ² |
| | ZG | 0.000 mm | Iz | 0.000 kg-m ² |

- Weight + Center of Gravity + Inertia: Estimates all mass properties of the installed tool
 - Weight and Center of Gravity must be accurately entered for the system to perform as intended. Inertia is particularly important for large and/or non-symmetric tools.
- Weight + Center of Gravity: Estimates weight and center of gravity only
 - This option skips the inertia estimation, saving time for small, symmetric tools
- 2. Motion Sequence for Tool Load Estimation

This procedure uses a series of Robot motions to estimate the properties selected. An image on the right side of the screen will dynamically update to indicate which axes are moving during each step of the process. Use the following components to successfully complete the estimation procedure:





- 6 Robot Settings
- 6.1 Tool Settings
 - a) Press {Hold to Estimate Tool Load} to initiate and execute the estimation procedure.
 - ① Holding button until notifications indicates.



The Estimation procedure requires an active Speed Limit settings and/or PFL settings to be temporarily disabled. A pop-up with instructions appears if these states are detected.

- ② The selected fields will update when the calculation is complete.
- ③ Each field has a status indicator that reads undefined, in progress, or completed.
- ④ A progress bar with accompanying text provides the user with a status of the overall estimation procedure.



- 6 Robot Settings
- 6.1 Tool Settings
- 3. Send New Mass Property Data to Tools Screen

Review the results for the chosen physical properties. If no errors in the estimation are present, press {Send & Review Data} to send the date to the {Tools} screen for saving. Refer to *chapter 6.1.5* for instructions to properly save the data.

| 2. Estimate Tool Load with Robot Motion | |
|--|--------------------------|
| Weight 4.542 kg | |
| Xg -22.114 mm 🖉 1x 0.000 kg-m ² | YASKAWA |
| V_{g} ly 0.000 kg-m^2 \bigcirc | |
| Zg lz 0.020 kg-m ² | |
| Send & Review Data | ⊖ Re-estimate Tool Load? |

| W | 0.000 kg | | |
|----------------|--------------|------|-------------------------|
| Center | of Gravity 🕕 | Mome | nt of Inertia |
| X _G | 0.000 mm | Ix | 0.000 kg-m ² |
| Y _G | 0.000 mm | ly | 0.000 kg-m ² |
| ZG | 0.000 mm | Iz | 0.000 kg-m ² |

4. Verification of Estimated Tool Mass Properties

If using a non-collaborative Robot, run a job that contains motions programmed with the tool that now has newly saved property data. If the job runs at the desired speed with no collision detection alarms, the estimated mass property data is sufficient.

If using a collaborative Robot, navigate to the {Utility} \rightarrow {Force/Torque Watch} to view the live torque sensor readings. Ensure the Active Tool # is set to the tool that has newly estimated mass property data. If any of the TCP values are greater than 30N while the Robot is static, the Tool Load Estimation procedure should be repeated to obtain more accurate values.


- 6 Robot Settings
- 6.1 Tool Settings


6.1.4 Tool Frame

6.1.4.1 Tool Center Point

The Tool Center Point is the offset of the Tool's Tip from the tool flange. Most simple tools will only have offsets in the XYZ direction; however, rotational offsets can also be set (see *chapter 6.1.4.2 "Orientation of Tool Tip"*). Configuring the Tool Center Point will allow Cartesian jogging of the manipulator about the correct point and will also ensure the Taught Positions have the correct offset from the Manipulator base.


Enter this data as provided by the tool manufacturer or from an accurate CAD model. In the absence of this information, the TCP coordinates can be calculated using the TCP Calibration feature described in *chapter 6.1.4.3*.





6.1.4.2 Orientation of Tool Tip

The orientation of tool tip is the rotation of the TCP from the tool flange. The rotation of the tool is input in degrees. Enter this data as provided by the tool manufacturer or from an accurate CAD model. In the absence of this information, the tool's orientation can be accurately calculated using the TCP Calibration feature described in *chapter 6.1.4.3*.



Y-axis


Fig. 6-13: Orientation of Tool Tip




- 6 Robot Settings
- 6.1 Tool Settings

6.1.4.3 Tool Center Point (TCP) Calibration


To ensure a Robot can properly perform linear and circular motions, the TCP introduced above must be fully defined. In the absence of known tool frame properties, TCP Calibration is an operation that accurately calculates this data through a series of recorded postures. This procedure can calculate the TCP's XYZ coordinates and/or orientation data in the flange coordinates.





To calibrate the TCP's XYZ coordinates, five different postures must be registered about a reference point with a fine tip (example shown in red in *fig. 6-15*). YASKAWA recommends aligning the first posture of the tool with the center of the reference point and then rotating the tool around it with significant angle to define the remaining four postures. See *fig. 6-16 "Calibration Postures"* for detail on these postures.

Fig. 6-15: Reference Point with a Fine Tip




- 6 Robot Settings
- 6.1 Tool Settings

On Smart Pendant, the TCP Calibration screen can be accessed as follows:

- 1. Go to {MENU} \rightarrow {Robot Settings} \rightarrow {Tools}.
- 2. Select the desired Tool from the list at the top.
- Press {ESTIMATE} on the tool frame section of the tool's detail panel at the bottom.



← TCP Calibration for Tool #0: Parallel Gripper



A dialog may appear if the active tool does not match the Tool selected from the list. These must match to accurately perform the TCP calibration procedure.



- 6 Robot Settings
- 6.1 Tool Settings

TCP Calibration Procedure

Three steps are required to successfully calibrate the Tool Center Point:

- 1. Selection of desired {Calibration Method}
- 2. Move to and {Set} Robot postures required to calibrate the TCP
- 3. Calculate, send, and save tool frame data on {Tools} screen

Detailed instructions to complete this procedure is provided in the following sections.

① Selection of Desired Calibration Method

The user can select from one of three methods on the {TCP Calibration} screen:

| . Select Calibration Method CP (X, Y, Z - Recommended) ~ | | Center Point (TCP) | ② Orient | ation — 💮 ESTIMAT |
|---|----------------|--------------------|----------------|-------------------|
| TCP (X, Y, Z - Recommended) | X _F | 0.000 mm | R _X | 0.0000 deg |
| Orientation (Rx, Ry, Rz) | Y _F | 0.000 mm | Ry | 0.0000 deg |
| TCP + Orientation | Z _F | 140.000 mm | Rz | 0.0000 deg |

• TCP (X, Y, Z): Calibrates TCP's XYZ coordinates only, recommended for most users

"TCP Coordinates" are calculated from five postures (1 to 5) set by the user. In this case, Tool Orientation will not be changed (previous values are maintained).

Orientation (Rx, Ry, Rz): Calibrates tool orientation only

6-14

Tool "Orientation" is calculated using a single posture (1) set by the user. In this case, TCP XYZ coordinates will not be changed (previous values are maintained).

• **TCP + Orientation:** Calibrates both the TCP's XYZ coordinates and tool orientation


"Orientation" is calculated from the first recorded posture (1) and "Coordinates" are calculated using all five recorded postures (1 to 5)

- 6 Robot Settings
- 6.1 Tool Settings


① Set and Move To Calibration Postures

YASKAWA recommends setting the five calibration postures in the following configuration for the best results. The easiest jogging mode to start with is XYZ-World while XYZ-Tool mode can be used to refine and verify the resulting TCP.

Fig. 6-16: Calibration Postures




The greater the difference between the five postures, the better. No two recorded postures can match and calibration accuracy will decrease if multiple poses are similar or rotated in a constant direction. Repeating this procedure multiple times may increase the accuracy of the resulting TCP.



- 6 Robot Settings
- 6.1 Tool Settings


Use the following procedure to {Set} and {Go To} the recommended postures above:

- 1. Select a Calibration Posture (1 to 5).
 - Check its status (Green = "Saved", Blue = "Undefined"). If undefined, jog the Robot to approximately match the "Recommended Posture" using the Jogging Panel.
- 2. Once at the desired posture, press {Set} to record its position.
- 3. Move to previously saved postures using {Go To} buttons.
 - If calibrating TCP coordinates, repeat *step 1* through *step 4* until all Calibration Postures are green in color.
- 4. Use the {Clear All} button to remove all previously recorded postures to re-initialize the calibration process.



① Calculate and Confirm New TCP on Tools Screen

Press {Calculate TCP and Send for Review} to send the calculated TCP data to the {Tools} screen for review. Refer to Chapter 6.1.5 for instructions to properly save the data.



- 6 Robot Settings
- 6.1 Tool Settings

| C Tool C | enter Point (TCP) | Orient | ation — 🎲 E | STIMATE |
|----------------|-------------------|----------------|-------------|---------|
| X _F | 0.000 mm | R _X | 0.0000 deg | |
| Y _F | 0.000 mm | R _Y | 0.0000 deg | |
| Z _F | 150.000 mm | Rz | 0.0000 deg | |
| | | 2 | | J |

① Verification of Calculated TCP

Jog the Robot in XYZ-Tool mode to rotate the installed tool about the reference point used for the calibration procedure. The TCP should rotate nicely around the fine point. If the rotation motions are offset and appear to be rotating around another point, the calibration procedure should be repeated to increase accuracy.

6.1.5 Setting Tool with FSU

A final step is required in the tool setting process when the Functional Safety Unit (FSU) and/or Power and Force Limit (PFL) function is enabled on the YRC Controller. To ensure tool setup has been performed according to safety regulations, the data must be checked to ensure that the information in the YRC Controller matches that on the FSU/PFL safety boards.


- 1. Edit the tool data
 - {READBACK} will appear, to allow the operator to read data from both the YRC Controller and the FSU/PFL safety boards.

| Tool #0: | Parallel Gripper | | | × CANCEL | READBACK |
|------------------|-----------------------------|--------------------------|--------------------------|----------------|--------------|
| Name Parallel | Gripper | | Block I/O Grip ON/OFF | ~ | |
| Tool C | Center Point (TCP) 0.000 mm | Orient R _X | ation — 🎲 ESTIMATE | E Show w | rithout tool |
| Y _F | 0.000 mm | R _Y | 0.0000 deg | | S |
| Z _F | 130.000 mm | Rz | 0.0000 deg | TCP (X,Y,Z) | Zi |

- 6 Robot Settings
- 6.1 Tool Settings
- 2. Press the {READBACK}
 - {Display} option appears. Options are provided for viewing the data.
 - Edit Value: values entered
 - READBACK VALUE (FSU): temporary values saved on the FSU board
 - READBACK VALUE (PFL): temporary values saved on the PFL board
 - COMPARISON RESULT (default): the result that are compared

| Tool #0: | Parallel Gripper | | | CANCEL SWRITE |
|------------------|-------------------|----------------|---------------------|--------------------------------|
| Name Parallel | Gripper | | _ | Display Comparison Result ~ |
| - Tool C | enter Point (TCP) | Orient | tation — 🏠 ESTIMATE | Comparison Result |
| X _F | 0.000 mm | R _x | 0.0000 deg | Edit Value |
| Y _F | 0.000 mm | Ry | 0.0000 deg | Readback Value (FSU) |
| Z _F | 140.000 mm | Rz | 0.0000 deg | Readback Value (PFL) |

- 3. Select {COMPARISON RESULT}.
- 4. Check the {READBACK} result
 - If {Comparison Result} data matches, then the setting was successful. But if the data differs, the value of the {Comparison Result} will be displayed as "***" instead of the value. At this point, the operator should check to see which data on which board was not updated.
- 5. Press {WRITE.}
 - The pop-up message appear for confirming the tool data update.
- 6. Press {YES}.
 - This will update the tool data, provided the data was updated correctly.



- 6 Robot Settings
- 6.2 I/O for Tool

6.2 I/O for Tool

A robotic tool (i.e. end-effector) typically has subcomponent(s) that are controlled by I/O. These I/O can be used to do the following example tasks:


Fig. 6-17: Block I/O Sequence for Selected Tool

| Block I/O Grip ON/OFF | ~ | (i) |
|--------------------------|---|-----|
| | | |

- Open/close a two-finger gripper.
- Trigger an auxiliary action (e.g. blow-off for a vacuum gripper) to reliably release a part.

Smart Pendant provides the following methods to use I/O for tool operation:

- Program in an INFORM job using {I/O} commands (refer to *chapter* 4.4.3" *Inserting Commands*" for more information).



 Toggle the general purpose output signal ON/OFF from the {I/O screen} (refer to *chapter 7.4.2.2 "I/O Screens*" for more information)

| Inpu | uts | Outputs | | [≟] ⊲⇒ Go To: | 1 | ② Settings |
|-------|---------|----------|---------|-----------------------------|------|-------------------|
| Group | Outputs | Status (| | GROUP: 1 | | VALUE (DEC): 8 |
| | 1.0 | 7 6 5 4 | 3 2 1 0 | OUTPUT: 1-8 TYPE: Genera | | VALUE (HEX): 0x08 |
| 1 | 1-8 | 80000 | 0001 | | | Enable toggle |
| 2 | 9-16 | 0000 | 0000 | | | |
| 3 | 17-24 | •000 | 0000 | Output Status | Name | Toggle |
| 4 | 25-32 | 0000 | 0000 | 1 O | | 0 |
| 5 | 33-40 | 0000 | 0000 | 2 O | | |
| 6 | 41-48 | •000 | 0000 | 3 🔾 | | |

- 6 Robot Settings
- 6.2 I/O for Tool
 - Configure I/O sequences for tool on the {Block I/O screen} (refer to the *chapter 7.7 "Block I/O*" for more information). {Block I/O screen} can be used to:
 - Physically open/close a gripper during teaching
 - Quickly add INFORM command sequences that open/close a gripper to the Current Job

To configure the block I/O states for a tool, refer to chapter 7.7 "Block I/O".

HW1485509


- 6 Robot Settings
- 6.3 User Frames

6.3 User Frames


User Frame is a user-defined frame. Instead of specifying positions relative to the World or Robot Frames, user can specify positions relative to an object in their workcell such as a work surface, pallet, or conveyor. The manipulator moves parallel to each axis of the user-defined frame. The user defines the X, Y, and Z axes with the desired slopes and positions available within the manipulator's motion range.

6.3.1 Example Usage of User Frames

 When two or more fixtures are used, manual operation is simplified by setting the user frames for each fixture.



 When performing arranging or stacking operations, the incremental value for the parallel shift is easily set by setting the user frame on a pallet.




- When the position of a pallet moves, all points relative to a pallet can be moved simply by re-teaching the User Frame.
- When multiple pallets have the same part pattern, user can teach points on one pallet and then switch them to another by changing the User Frame.

- 6 Robot Settings
- 6.3 User Frames

6.3.2 Methods for User Frame Setting

User coordinates are defined by three points that have been taught by the manipulator. These three defining points are ORG, XX, and XY, as shown in the diagram below. These three points are referenced from the World Frame, and are registered in a user frame file.




ORG is the origin position. XX is a point on the X-axis. XY is a point on the Y-axis side of the taught user coordinates. The directions of the Y- and Z-axes are determined by point XY.



6.3.3 User Frame Number

63 user frames can be created, numbered from 1 to 63.



- 6 Robot Settings
- 6.3 User Frames

6.3.4 User Frame Setting

- 1. Select {Robot Settings} under {MENU}.
- 2. Select {User Frame}
 - The User Frame (UF) Configuration screen will appear.

| ÷ | User Frames (| (+) N | EW U | SER FRAME | Search by name | Q | |
|--------------|-------------------|-------|------------|-----------|----------------|--|------------|
| User | Frame No. | Na | me | | | | |
| 1 | | Pa | llet | | | | Î |
| | | | | | | | |
| Use | r Frame #1: Palle | et | | | | | <i>(i)</i> |
| Nam Palle | | | Tool Numbe | | ~ | To create a User Frame (U Select (1) Origin, (2) XX, ar | |
| | ORIGIN | | ХХ | | XY | to teach their positions. From these taught positio | ons the Z |
| х | 460.004 mm | Х | 470.002 mm | Х | 470.004 mm | direction will be calculated To get more accurate resu a pointer tool. | |
| Υ | -0.003 mm | Y | -0.003 mm | Y | 9.811 mm | Z-axis | |
| Z | 385.002 mm | Ζ | 385.005 mm | Z | 385.004 mm | ORIGIN | |
| (♥ | SETORIGIN | (₹ | SET XX | \$ |) SET XY | X-axis | Y-axis |
| 0 | GO TO ORIGIN | 0 | GO TO XX | 0 |) до то ху | XY | - |
| Rob | ot Jog Panel | | | | | | ^ |

3. Tap {+ NEW USER FRAME} on the top.

| ← User Frames (UF) | | Search by name | ۹ |
|--------------------|--------|----------------|---|
| User Frame No. | Name | | |
| 1 | Pallet | | Ĉ |

- 4. Enter the name of the user frame.
 - Name is up to a maximum of 16 alphanumeric characters and symbols.

| User Frame #1: Pallet | | | (i) |
|-----------------------|-------------------|---|--------------------------------------|
| Name | Tool Number | ~ | To create a User Frame (UF), |
| Pallet | #7: Vacuum | | Select (1) Origin (2) XX, and (3) XY |

- 5. Press {Tool Number}.
 - The list of Tools will appear.
 - By default, the new User Frame will use the current (active) Tool number.

| User Frame #1: Pa | (i) | | |
|-------------------|-------------|---|--|
| Name | Tool Number | | |
| Pallet | #7: Vacuum | ~ | To create a User Frame (UF), Select (1) Origin (2) XX, and (3) XX |



- 6 Robot Settings
- 6.3 User Frames

6. Select the desired Tool from the Tool List.

| | ': Vacuum | | | | × |
|--------|--------------|-----------|--------------------|----------------|---|
| Select | User Frame 1 | īool | Display only named | Search by Name | ۹ |
| | Tool No. | Tool Name | Weight | Block I/O Name | |
| | 5 | | 5.000 | | |
| | 6 | - | 0.500 | 2 | |
| | 7 | Vacuum | 3.000 | - | |
| | 8 | | 0.100 | | |
| | | | SELECT | | |
| | | | SELECT | | |

- 7. Press {SELECT}.
 - Tool List will close and go back to the User Frame Configuration screen.
- 8. Select {ORIGIN}.
 - Move the manipulator to the desired position using any of the Jog Modes/methods or type in the desired position in X, Y, Z format.

| Use | r Frame #1: Palle | et | | | | (i) |
|-------------|-------------------|----|------------|-----|------------|---|
| Nam Pall | | | Tool Numbe | | ~ | To create a User Frame (UF), Select (1) Origin, (2) XX, and (3) XY |
| | ORIGIN | | XX | | ХҮ | to teach their positions. From these taught positions the Z |
| х | 460.004 mm | х | 470.002 mm | x | 470.004 mm | direction will be calculated. To get more accurate results, use |
| Υ | -0.003 mm | Y | -0.003 mm | Y | 9.811 mm | a pointer tool. Z-axis |
| Z | 385.002 mm | Z | 385.005 mm | Z | 385.004 mm | |
| (♥ | SET ORIGIN | († | SET XX | (↔ | SET XY | X-axis XX Y-axis |
| 0 | GO TO ORIGIN | 0 | GO TO XX | 0 | GO TO XY | XY |
| Rob | ot Jog Panel | | | | | ^ |

9. Press {SET ORIGIN}.

- Taught position is registered.

10. Repeat step 8 and step 9 to teach {XX} and {XY}.

6-24

 To check the taught positions, press {GO TO ORIGIN}, {GO TO XX} or {GO TO XY}. The manipulator will move to the set position.

HW1485509

- Robot Settings
- 6.3 User Frames

6

Setting points have following constraints:

 A User Frame cannot be created if manipulator is at singular position or on the edge of workspace
 Two points cannot be the same (i.e. ORIGIN&XX, ORIGIN&XY, or XX&XY)
 The three points cannot be on the same line.
 If any of the above conditions are present, a warning notification will appear.

- 11. Select {Save}.
 - User frame is saved.

6.3.5 Deleting the User Frame

1. Select the trash can icon.

- A confirmation pop-up window will appear.

| ← User Frames | s (UF) | Search by name | Q | |
|----------------|--------|----------------|---|--|
| User Frame No. | Name | | | |
| 1 | Pallet | | Û | |

- 2. Select {YES}.
 - User frame is deleted.

- 6 Robot Settings
- 6.4 Zones

6.4 Zones

The zone setting allows user to define spatial boundaries that can be used to restrict manipulator motion or to generate notifications for application control. The YRC Controller supports the creation of a maximum of 64 zones. There are two different types of zones:

- Cubic zones
- Axis zones

When the manipulator attempts to enter a zone, it can take two kinds of action.

 Status: The status signal turns ON when the manipulator enters the zone. To determine status by application, refer to *chapter 6.4.3*" *Zone Status*".

Example use: set a zone when the manipulator is outside the metal working machine.


 Alarm: The alarm becomes active when the manipulator enters inside the zone.

Example use: set a zone not to interfere with the working table

This signal is processed in the I/O section.


6.4.1 Cubic Zone

The cubic zone is a rectangular parallelepiped (a solid body of which each face is a rectangle) parallel to the base coordinate, robot coordinate, or user frame. The YRC Controller determines whether the manipulator's TCP is inside or outside this zone, and outputs this status as a signal.



- 6 Robot Settings
- 6.4 Zones

The area inside the specified cube is defined as the zone. When the manipulator's TCP is located inside the cube, the corresponding Specific Output signal is ON.



- TCP is located inside the cube
- Inside of zone: Specified output signal = ON
- Outside of zone: Specified output signal = OFF

6.4.1.1 Cubic Zone Setting Operation


- 1. Go to {Zones} under {MENU}.
 - The Zone screen will appear.
- 2. Press {+ NEW ZONE}.

| ← Zone | S | (\pm) | Search by name | Q |
|----------|--------|---------|----------------|---|
| Zone No. | Status | Name | Туре | |
| 1 | 0 | Pallet | Cubic (World) | Û |

- 3. Press the number with new zone.
 - The Zone Detail panel will show for the selected zone.
- 4. Type the name of the zone in the {Name}.
 - Zone names can be from 0 to 32 alphanumeric characters and symbols in length.
 - Same zone name can be used.

| Zone #1: Pal | let | | | | | | |
|----------------|------|-------------|---|-------|---------------|----|----------------|
| Name Pallet | | | ٦ | | Corner 1 | | Corner 2 |
| | | Ref. Coord. | | х | 0.000 mm | Х | 400.000 mm |
| Type Cubic | ~ | World | ~ | Υ | 0.000 mm | Y | 100.000 mm |
| Action | | | | Z | 0.000 mm | Z | 400.000 mm |
| Alarm | ~ | | | (†) s | SET CORNER 1 | \$ | SET CORNER 2 |
| Corre | er1 | Corner2 | | ି ତ ଜ | 0 TO CORNER 1 | 0 | GO TO CORNER 2 |
| Robot Jog Pa | anel | | | | | | ^ |

- 6 Robot Settings
- 6.4 Zones
- 5. Select {Cubic} from the pull-down list at Type.
- 6. Select the desired Action from the pull-down list.
- 7. Select the Reference Coordinates from the pull-down list.
 - World: Currently, it is same as the Robot
 - Robot: This zone is referred to the Robot frame when it is created
 - User: This zone is referred to the user frame when it is created
- 8. Enter the minimum (Corner 1) values of X, Y, Z either 1) by moving the manipulator to the corner or 2) by manually entering the data.



To move the manipulator via the touch screen, press {Robot Jog Panel} on the bottom of the screen to display the touch buttons.

- Press {SET CORNER 1} The position of the corner can be checked visually by pressing {GO TO CORNER 1} after it is set.
- Enter the maximum (Corner 2) values of X, Y, Z by either moving the manipulator to the corner or by manually entering the data. To move the manipulator from the touch screen, press {Robot Jog Panel} on the bottom of the screen to open the touch buttons.
- 11. Press {SET CORNER 2} The position of the corner can be checked visually by pressing {GO TO CORNER 2} after it is set.
- 12. In the case of a Zone with "User" Reference Coordinate, the correct User Frame must also be set. Select {User Frame #} and select the proper User Frame from the list.

6-28

6 Robot Settings

6.4 Zones

| Zo | one #10: PalletZone | | |
|----|----------------------|-----------------|---|
| Us | er Frame #1 | | × |
| Se | lect Zone User Frame | | |
| | User Frame No. | User Frame Name | |
| | 1 | Pallet | |
| | 2 | User frame 2 | |
| | 3 | User frame 3 | |
| | A | Hear france A | |
| | | SELECT | |
| Ro | bot Move Controls | | ^ |

The current status is shown in the Status column. When the manipulator is inside the specified zone, the Status color will turn green. When the manipulator is outside the specified zone, the Status will be white.


| | | | | SERVO | | | P | 2 C |
|---|--------|----------------------|------|------------|---------------|--------|-------------|------|
| ← Zone | s | | • | NEW ZONE | E . | Search | by name | ۹ |
| Zone No. | Status | Name | | | Туре | | | |
| 1 | 0 | Pallet | | | Cubic (World) | | | Û |
| 2 | 0 | Loading | Area | | Cubic (World) | | | |
| Zone #1: P | allet | | | | | | | |
| Name Pallet | | | | | Corner 1 | | Corner | 2 |
| Type Cubic | ~ | Ref. Coord. World | ~ | X Y | 0.000 mm | X Y | 400.00 | |
| Action Alarm | ~ | | | Z | 0.000 mm | Z | 400.00 | 0 mm |
| | | | | (+) | SET CORNER 1 | \$ | SET CORNER | R 2 |
| ~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~ | mer1 | Corner2 | | ⊘ G | O TO CORNER 1 | | GO TO CORNI | ER 2 |
| Robot Jog | Panel | | | | | | | ^ |

- 6 Robot Settings
- 6.4 Zones

6.4.2 Axis Zone

The axis zone is a function that determines the current position of the each axis and outputs a signal. Once the maximum and minimum values have been set at the axis to define the working range, a signal indicating whether the current position of the axis is inside or outside this range is output. (ON: inside, OFF: outside)

Fig. 6-18: Axis Zone



6.4.2.1 Axis Zone Setting Operation

- 1. Go to {Zones} under {MENU}.
 - Zone screen will appear.
- 2. Press {+NEW ZONE}.

| ← Zone | S | (i) | NEW ZONE Search by name | ٩ |
|----------|--------|--------|-------------------------|---|
| Zone No. | Status | Name | Туре | |
| 1 | 0 | Pallet | Cubic (World) | Û |

- 3. Press the number with new zone.
 - The Zone Detail panel will show for the selected zone.
- 4. Type the name of the zone in the Name.
 - Zone names can be from 0 to 32 alphanumeric characters and symbols in length.
 - Same zone name can be used.

| Zone #2: Zone | 2 | | | |
|------------------|---|---------|--------------|----------------|
| Name | | | Min | Max |
| Zone 2 Type | | | S -180.000 ° | 180.000 ° |
| Axis | ~ | | L -180.000 ° | 180.000 ° |
| Action Status | ~ | | U -5.000 ° | 355.000 ° |
| | | Max Min | R -180.000 ° | 180.000 ° |
| | | | B -180.000 ° | 180.000 ° |
| | | | T -180.000 ° | 180.000 ° |
| | | | RE | SET TO DEFAULT |





- 6 Robot Settings
- 6.4 Zones
- 5. Select {Axis} from the pull-down list at Type.
- 6. Select the desired Action from the pull-down list.
- 7. Insert the minimum angle and maximum angle for each axis.
 - Each axis has a different range of motion. Check the manipulator's range of motion in the manual that came with the manipulator. The value that exceeds the manipulator's range of motion cannot be inserted.
 - Press {Robot Jog Panel} on the bottom of the screen to display the touch buttons and move the manipulator via the touch screen.
- 8. Press {RESET TO DEFAULT} to reset the angles on all axes.
 - The default values are the minimum and maximum limits for each axis.
- 9. Zone setting is complete.

For each zone, the status indicator shown in:

- green: inside zone
- white: outside zone

For Axis Zone, even if one axis is outside the zone, the manipulator is detected as outside the zone.





- 6 Robot Settings
- 6.4 Zones

6.4.3 Zone Status

User can check the status of a zone from the pendant user interface.

For each zone, the status indicator shown in:

- green: inside zone
- white: outside zone

Fig. 6-20: Zone Status

| Zone No. | Status | Name | Туре | |
|----------|--------|--------|--------------|-----|
| 4 | 0 | Zone 4 | Cubic (Base) | i i |
| 5 | • | Zone 5 | Axis | |

For application programming and logic control, user can determine the status of a zone by monitoring the status of a given zone on a Specific Output. These zone status signals indicate the zone in which the current control or axis is positioned in the initially set area. These signals can be used to prevent interference with other manipulators or jigs.

The following table shows the Specific Output Numbers (SpecificOut#) for zone status.

| Cubic / Axis Zone Status | | | | | | | | |
|--------------------------|------|------|------|------|------|------|------|------|
| Zone # | #8 | #7 | #6 | #5 | #4 | #3 | #2 | #1 |
| SpecificOut# | #064 | #063 | #062 | #061 | #060 | #059 | #058 | #057 |
| Zone # | #16 | #15 | #14 | #13 | #12 | #11 | #10 | #9 |
| SpecificOut# | #072 | #071 | #070 | #069 | #068 | #067 | #066 | #065 |
| Zone # | #24 | #23 | #22 | #21 | #20 | #19 | #18 | #17 |
| SpecificOut# | #080 | #079 | #078 | #077 | #076 | #075 | #074 | #073 |
| Zone # | #32 | #31 | #30 | #29 | #28 | #27 | #26 | #25 |
| SpecificOut# | #088 | #087 | #086 | #085 | #084 | #083 | #082 | #081 |
| Zone # | #40 | #39 | #38 | #37 | #36 | #35 | #34 | #33 |
| SpecificOut# | #096 | #095 | #094 | #093 | #092 | #091 | #090 | #089 |
| Zone # | #48 | #47 | #46 | #45 | #44 | #43 | #42 | #41 |
| SpecificOut# | #104 | #103 | #102 | #101 | #100 | #099 | #098 | #097 |
| Zone # | #56 | #55 | #54 | #53 | #52 | #51 | #50 | #49 |
| SpecificOut# | #112 | #111 | #110 | #109 | #108 | #107 | #106 | #105 |
| Zone # | #64 | #63 | #62 | #61 | #60 | #59 | #58 | #57 |
| SpecificOut# | #120 | #119 | #118 | #117 | #116 | #115 | #114 | #113 |


6-32

Table 6-1: Cubic / Axis Zone Status

Robot Settings

6.4 Zones

6



- 6 Robot Settings
- 6.5 Shock Detection Setting

6.5 Shock Detection Setting

The shock detection function is a function to decrease damage due to collisions by stopping the manipulator without any external sensors when the tool or the manipulator collides with a peripheral device.

When the shock is detected either in MANUAL (TEACH) mode or in AUTOMATIC (PLAY) mode, the manipulator is stopped immediately.



Failure to observe this instruction may cause contact with the manipulator, which may result in personal injury and/or equipment damage.

6.5.1 Shock Detection Overview

Shock Detection Setting provides a mechanism to add extra protection to the Manipulator and surrounding equipment in the case of accidental collisions. This is done by measuring the torques encountered during an application and then setting a "Max Allowable" torque within some buffer/ offset of the measured values. If the measured value ever goes over the "Max Allowable", an alarm will be triggered and the Robot will be stopped.

By factory default setting, Shock Detection will be turned on with a large offset. However, these default settings can be changed based on the application and multiple settings for a single application can even be created. In all, there are nine total Shock Detection Settings:

- Default for AUTOMATIC (PLAY) Mode
- Default for MANUAL (TEACH) Mode
- Condition #1-7 Additional User Configurable Settings for AUTOMATIC (PLAY) Mode

The following sections will describe how to configure these settings and to change them during operation.

6.5.2 Shock Detection Setting Interface

The main Shock Detection Setting Screen is shown in *fig. 6-21 "Shock Detection Setting Screen"*. To access this page, select {MENU}, {Robot Settings}, and then {Shock Detection Setting}.

The following actions can be taken from this page:

① Shock Detection Status Switch

Use this to enable or disable the Shock Detection feature. This is a global setting which will turn on/off Shock Detection for the YRC Controller.

HW1485509

- 6 Robot Settings
- 6.5 Shock Detection Setting

② Shock Detection Setting

Use this to select Condition Number to configure.

| Automatic (Play): Default | |
|-----------------------------------|--|
| Automatic (Play): Default | |
| Manual (Teach) | |
| Automatic (Play): Condition No. 1 | |
| Automatic (Play): Condition No. 2 | |
| Automatic (Play): Condition No. 3 | |
| Automatic (Play): Condition No. 4 | |
| Automatic (Play): Condition No. 5 | |
| Automatic (Play): Condition No. 6 | |
| Automatic (Play): Condition No. 7 | |

③ Measured Max Torque

This will show the current Measured Max Torque and will update while the Robot is running. These values can be cleared by pressing {Clear Measured Max}.

④ Allowable Max Torque

This will display the Allowable Max Torque for the current Shock Detection Setting.

⑤ Clear Measured Torque

This will reset the "Measured Max Torque" values.

6 Copy Measured to Allowable


This will copy the current "Measured Max Torque" with the entered Offset added to the "Allowable Max Torque" values.

⑦ Reset Allowable to Default

This will reset the "Allowable Max Torque" values to the default values.

- 6 Robot Settings
- 6.5 Shock Detection Setting





The general procedure for configuring a Shock Detection Setting are:

- 1. Run application and observe the Measured Max Torque for several hours.
 - After this point, the Measure Max Torque values should not change much.
- Press {COPY MEASURED TO ALLOWABLE WITH OFFSET} with a small Offset value depending on desired sensitivity (lower Offsets will be more sensitive). A recommended starting point is an Offset between 10-20.

If a collision is detected during execution, the YRC Controller will report Alarm 4315, shown in *fig. 6-22 "Collision Detection Alarm"*.

6-36

6 Robot Settings

JOT

6.5 Shock Detection Setting

Fig. 6-22: Collision Detection Alarm

| COLLISION DETECT Alarm 4315 [1] |
|---|
| COLLISION DETECT A collision was detected because of the interference between the manipulator and a peripheral device. The external force applied to the robot exceeded the threshold. SOLUTION: Check the following settings. - The tool information - The selection tap of the transfer - The collision detection level - JOB - Work - The speed of JOB - The acceleration/deceleration speed of ACC and DEC - Length of the power cables |
| - Diameter of the power cables Remove the following interferences. - The interferences to the jigs of Robot. |
| Ref: GFYQK |

When Robot is stopped instantaneously while having contact with the object and the detection alarm is tried to reset on the alarm window, the situation in which the alarm cannot be reset may occur since the collision may be detected again after resetting.

In this case, set the Shock Detection Status to "INVALID", or increase the detection level in MANUAL (TEACH) mode and move the manipulator to a safety position.

For most cases, only the AUTOMATIC (PLAY): Default" setting will need to be configured. This setting will be active by default to provide protection during operation. However, in some cases, it might be desirable to change the settings throughout a single application. This is described in *chapter* 6.5.3" Using Multiple Shock Detection Settings".

| | • | Perform all the jobs to use for 5 to 6 hours. |
|------|---|--|
| | • | For the material handling application, if a work job is performed both with holding a workpiece and without holding a workpiece, measure both patterns. |
| | • | In the event of a collision while measuring the Max Torque, clear the Measured Max Torque by pressing {CLEAR MEASURED MAX}. Then try again. |
| NOTE | • | The Measured Max Torque is cleared when the power is turned ON/OFF. Therefore, DO NOT set the level based on the Measured Max Torque immediately after turning ON/OFF the power. |
| | • | When the teaching point, operation speed, operation position, etc. of a job are greatly changed due to teaching modification, etc., measure the Measured Max Torque and configure the settings again. |
| | • | When the load of tool or workpiece is greatly modified, measure the Measured Max Torque and configure the settings again. |
| | | |



- 6 Robot Settings
- 6.5 Shock Detection Setting

6.5.3 Using Multiple Shock Detection Settings

In most applications, it is sufficient to set only one Shock Detection Setting for AUTOMATIC (PLAY) Mode and it is best to use the "AUTOMATIC (PLAY): Default" setting. However, it is sometimes useful to have multiple settings active in an application and to change the active setting during operation. For example, the sensitivity might need to be lowered during the picking of a part.

There are two INFORM commands that can be used to perform these actions:

- **SetShockDetection** Changes that active Shock Detection Setting or overrides the current settings
- ResetShockDetection
 Resets the Shock Detection Setting to default (i.e. "AUTOMATIC (PLAY): Default")

An example of using these instructions is shown in *fig. 6-23 "Shock Detection INFORM Instructions"*. At the top of the program, the ResetShockDetection instruction is executed (1) to reset to the default setting. Thus, the motions executing in (2) will use the "AUTOMATIC (PLAY): Default" setting. Then, the SetShockDetection instruction is executed (3) to change to Condition #4. Thus, the motions executing in (4) would use the "AUTOMATIC (PLAY): Condition No. 4".

Fig. 6-23: Shock Detection INFORM Instructions

6-38

| 🔅 ROBOT JOB - MOTIONTEST | 0 | ŝ |
|-------------------------------------|---|---|
| 1 Start Job | | 1 |
| 2 ResetShockDetection | | |
| 3 For I000 = 1 to 5 | | |
| 4 JointMove Speed=100.00(%) | | 2 |
| 5 JointMove Speed=100.00(%) | | |
| 6 Next I000 | | |
| 7 SetShockDetection SettingNumber=4 | | 3 |
| 8 For I000 = 1 to 5 | | |
| 9 JointMove Speed=100.00(%) | | 4 |
| 10 JointMove Speed=100.00(%) | | 4 |
| 11 Next I000 | | |
| 12 End Job | | |

- 6 Robot Settings
- 6.5 Shock Detection Setting

6.5.4 Shock Detection Watch

The Shock Detection Watch screen is an overlay utility that can be used to monitor Measured and Allowable Max Torque during operation. To access this screen, press {MENU}, {Utility}, and then {Shock Detection Watch}.



When Robot operation has just started, the listed "Allowable Max Torque" may be larger than the value in the corresponding Shock Detection Setting. This is due to difference in the grease viscosity during cold start. After operating for approximately 1 hour, the value used by the system will match the Shock Detection Setting.

Fig. 6-24: Shock Detection Watch

| | | SERVO | | | Þ | N |
|------------------------------------|---------------------------------------|--|-------------------------------|--------------------------------------|---|---|
| ႏွို် ROBOT JOB - SAMP | PLE | | | 0 | | 锁 |
| 1 Start Job | | | | | | |
| 2 Timer Time=2 | .50(seconds | ;) | | | | |
| 3 For I000 = 1 | to 5 | | | | | |
| 4 JointMove | Speed=100 | .00(%) | | | | |
| 5 JointMove | Speed=100 | .00(%) | | | | |
| 6 Next I000 | | | | | | |
| 7 Timer Time=2 | .50(seconds | ;) | | | | |
| 8 DigitalOut O | utput#(1) | ON | | | | |
| 9 End Job | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| Shock Deter | ction Watch | | | | | × |
| Shock Deter | ction Watch | Shock Detection Stat | us: Active | | | × |
| ▲ Shock Deter | 2 | Shock Detection Stat | | | | × |
| | | | CLEAR N | IEASURED ORQUE | | × |
| | OPEN SHOCK TECTION SETTING | | CLEAR N | Max | | × |
| DET | OPEN SHOCK TECTION SETTINGS | Measured Max | CLEAR M MAX T Allowable | Max | | × |
| Det | OPEN SHOCK TECTION SETTINGS tis | Measured Max Torque | CLEAR M MAX T Allowable | Max e | | × |
| Det Ax S | OPEN SHOCK TECTION SETTINGS tis | Measured Max Torque 0 | CLEAR M MAX T Allowable | • Max e 0 | | × |
| DET Ax S L | OPEN SHOCK TECTION SETTING tis | Measured Max Torque 0 0 | CLEAR M MAX T Allowable | e Max le 0 0 | | × |
| DET Ax S L U | OPEN SHOCK TECTION SETTING tis | Measured Max Torque 0 0 0 | CLEAR M MAX T Allowable | Max e 0 0 0 | | × |
| Det Ax S L U R | OPEN SHOCK TECTION SETTING is | Measured Max Torque 0 0 0 0 | CLEAR M MAX T Allowable | e Max le 0 0 0 0 | | × |
| Det Ax S L U R B | OPEN SHOCK TECTION SETTING is | Measured Max Torque 0 0 0 0 0 0 | CLEAR M MAX T Allowable | e Max le 0 0 0 0 0 | | × |

- 6 Robot Settings
- 6.6 Robot Configuration Positions


6.6 Robot Configuration Positions

The {Robot} \rightarrow {Robot Configuration} screen allows the user to define and move the manipulator to positions helpful for certain tasks, such as:

- job start position (i.e. "Work Home Position")
- manipulator setup & resolving alarms (i.e. "Robot Position Confirm")
- torque sensor calibration postures for human collaborative Robots
- Fig. 6-25: Robot Configuration Screen Position Setup Tab

← Robot Position Setup

| Position Setup | Home Calibration | |
|----------------------|----------------------------------|---------------|
| Move to Reference Po | sitions Used for Robot Operation | (\tilde{l}) |
| | s 0.000 ° | AXIS REACHED |
| Edit Position | L 0.000 ° | AXIS REACHED |
| Robot Position | U 0.000 ° | AXIS REACHED |
| Work Home | R 0.000 ° [⊘∕ | AXIS REACHED |
| | в -90.000 ° | GO TO AXIS |
| | т 0.000 ° | AXIS REACHED |
| | | |
| | | |
| Mode | | |




6-40

- 6 Robot Settings
- 6.6 Robot Configuration Positions

6.6.1 Robot Position Types

Common Robot position types available to the user are described below. Axis position values will vary depending on manipulator model.

- Work Home Position (user editable)
 - A manipulator posture often used as the "start" position in the default job to ensure the manipulator will not crash into its surroundings.
 - By default, this position is connected to Zone 64 (type = cubic) for ROBOT1. Point "P" in the figure below represents the TCP of the manipulator at the work home position. The size of the cube ("a") is initially configured to be 100mm.



- Robot Position Confirm (user editable)
 - Used to verify the current posture of the Robot in the event of an alarm (e.g. 4107) when the YRC Controller is powered ON.
 - These alarms may occur if there is an error in encoder communication or the manipulator was moved after the power supply was turned off.
 - The initial value of Robot position confirm is also the manipulator's home position (all axes at pulse 0).



If an installed tool/workpiece prevents the manipulator from reaching its default confirmation position, the user can edit this to a posture more accommodating of the tool's geometry.

- Temporary Position (user editable)
 - Used to move the manipulator to a user-editable posture by specifying the target axis values.

There are additional positions for certain manipulator models.

- HC10 Torque Calibration Positions (cannot edit)
 - A set of factory defined postures used to calibrate torque sensors on the human collaborative. For more information on this position, refer to *"Calibrating Torque Sensor Offset Data"*.

- 6 Robot Settings
- 6.6 Robot Configuration Positions

6.6.2 Move to a Robot Position

The procedure to move to Robot positions is similar to that of the panel described in *chapter 2.4.8*" *Move to Position Panel*".

When approaching any position near other physical objects, reduce speed and use caution to prevent collisions. Pay close attention to the motion of the manipulator.



- In the event of "singularity" alarms, reduce speed and use individual {Move Axis} buttons to move to a target position without error.
- Failure to observe these instructions may result in personal injury or collisions with the manipulator.

6.6.3 Edit a Robot Position

Follow the steps below to edit a Robot Position:

- Press the {Edit Position} checkbox. This will enable fields and controls according to:
 - Required security level.
 - Write access level of position (editable vs non-editable)
- 2. Select a {Robot Position} from the dropdown list
 - Current axis values will update accordingly.
- 3. Edit the position using one of the methods below:
 - Enter values into enabled field(s) using the numeric keyboard
 - Use {Set To X.X} button(s) to set individual axes to the current position of the manipulator
 - Use {Set to Current Position} to set all axes to the current position of the manipulator
- Once change(s) are present, a {Save All/Cancel} control will appear. {Save All} will save changes to an edited position while Cancel will default to previously saved values.
 - The "Temporary" position is editable, but Save/Cancel does not apply. Axis values will default to zero on the YRC Controller reboot.

- 6 Robot Settings
- 6.6 Robot Configuration Positions

5. Uncheck {Edit Position} to exit "Edit" mode


| Position Setup | Home Calibr | ation | × CANCEL | SAVE ALL |
|------------------------|------------------|---------------|-----------------|----------|
| Edit Reference Positio | ons Used for Rob | oot Operation | | () |
| | S | 0.000 ° | | |
| Edit Position | L | 45.000 ° | SET TO 45.0* | |
| Robot Position | U | 0.000 ° | ◎ SET TO -0.0* | |
| Work Home | | 0.000 ° | SET TO -0.0* | |
| | В | -90.000 ° | ⊘ SET TO -46.4° | |
| | Т | 0.000 ° | ⊘ SET TO -0.0* | |
| | | CURRENT POSIT | TION | |

6.6.4 Robot Position Confirm Procedure

Encoder alarms (e.g. 4107 or 4511) may occur if the manipulator stops suddenly or collides during the operation, or if the manipulator is moved while the YRC Controller power is OFF.

In the event of an encoder alarm, a message will appear prompting the user to "check the position". The ability to run a job and move to positions other than the "Robot Position Confirm" target will be disabled when this message is active.






- 6 Robot Settings
- 6.6 Robot Configuration Positions
- 1. Navigate to {Robot} \rightarrow {Robot Configuration} \rightarrow {Position Setup Tab}
 - Ensure {Robot Position Confirm} is selected. {Confirm Position} will be visible with a blinking orange border but will be disabled if the Robot is not at the proper position.

| | S | 0.000 ° | O AXIS REACHED |
|------------------------|---|---------|----------------|
| Edit Position | L | 0.000 ° | 🔗 GO TO AXIS |
| Robot Position | U | 0.000 ° | AXIS REACHED |
| Robot Position Confirm | R | 0.000 ° | O AXIS REACHED |
| CONFIRM POSITION | В | 0.000 ° | 🔘 GO TO AXIS |
| | т | 0.000 ° | O AXIS REACHED |

- 2. Press and hold {Go To Position}.
 - Robot moves to the Confirm Position, {Confirm Position} will be enabled once reached



- 6 Robot Settings
- 6.6 Robot Configuration Positions
- 3. Press {CONFIRM POSITION}.
 - The position of the Robot is verified.
 - A confirmation message will appear.

This will re-enable the ability to run a job and move to previously taught positions.



If the manipulator's posture at its "Confirm Position" does not match the physical posture set by the user, Home Position Calibration may be required (refer to *chapter 6.7 "Home Position Calibration"*). This can occur, for example, if a motor or encoder is replaced. "Robot Position Confirm" is known as the "Second Home Position" in standard YRC Controller manuals.

- 6 Robot Settings
- 6.7 Home Position Calibration


6.7 Home Position Calibration

The Home Position of a Robot is the position where all axes are "0" degrees. Home Position Calibration is the operation where the Home Position and Absolute Encoder Position coincide. Although this operation is performed prior to shipment at the factory, it must be repeated if:

- Home Position encoder deviation (e.g. caused by a crash with the Robot's surroundings)
- Stored memory is wiped (e.g. weak battery, etc.)
- Replacement of a Manipulator motor or absolute encoder
- A change in the combination of a Manipulator and its YRC Controller

The Home Position is commonly used for a 6-axis vertically articulated Robot is shown in *fig. 6-27*.

Fig. 6-27: Home Position of a Common Industrial Robot






The Home Position differs depending on Manipulator model. Refer to the INSTRUCTIONS that corresponds to the specific Manipulator model.

- 6 Robot Settings
- 6.7 Home Position Calibration

Editing the Home Position affects the stored physical position. Using the {Home Position Calibration} screen on the Smart Pendant, the user can set one axis at a time or all axes simultaneously to the Robot's current position (unit: pulse). The user can also enter values manually using information provided by YASKAWA.

Fig. 6-28: Home Position Calibration Screen



- 6 Robot Settings
- 6.7 Home Position Calibration

6.7.1 Verification of Home Position Calibration

To verify the existing calibration of a Robot's Home Position, move all axes to their respective "0" degree positions. {Not at Home} will navigate to the {Temporary Position} with all zeros on the Move Robot screen to quickly accomplish this. Follow the instructions in *chapter 6.6.2" Move to a Robot Position*" to perform this action.



6-48


Set Origins for Robot's Encoders to Define Its Zero Posture S 100 SET ORIGIN SET ORIGIN 100 L Manual Entry? U 200 SET ORIGIN NOT AT HOME 號 MOVE ALL AXES TO 0° R 200 SET ORIGIN SET ORIGIN В 300 SET ORIGIN 300 Т SET ORIGIN FOR ALL AXES 0 TO CURRENT POSITION


6 Robot Settings

6.7 Home Position Calibration

When at "all zeros", "Not at Home" will turn green and the "Robot is at Home Position" indicator confirming the existing Home Position is ready for verification.

The user should now visually confirm whether the physical arrows on the Manipulator (i.e. one pair for each axis) are precisely aligned to validate the calibration of Home Position.





In the case of arrow misalignment for one or multiple axes, Home Position Calibration is required. The following sections discuss how to perform the calibration.



The arrow labels on some Robot models may be hard to find. Refer to the INSTRUCTIONS for the Manipulator corresponding to its model to find each label and accurately perform the calibration.

6.7.2 Home Position Calibration Methods

There are three separate methods for Home Position Calibration:

- Calibrate Individual Axis to robot's current axis position
- Calibrate All Axes to Robot's current position

6-49

Manually Calibrate one or multiple axes to known encoder values

The procedure for each of these methods is provided in the following sections.



All calibration methods change the zero-position of the desired axes. This can affect the physical position of the robot for any previously saved positions.


- 6 Robot Settings
- 6.7 Home Position Calibration

6.7.2.1 Individual Axis Calibration Procedure

Use this method if a single axis experiences a hard crash or if a single motor/encoder is replaced.

- 1. Go to $\{MENU\} \rightarrow \{Robot Settings\} \rightarrow \{Home Position Calibration\}.$
- 2. Perform the verification procedure described in *chapter 6.7.1*" *Verification of Home Position Calibration*".
- 3. For any arrow(s) that are misaligned, jog the affected axis until they are aligned.
- 4. Press {Set Axis} to insert the robot's current pulse value for that axis.
- 5. Press {Save All} (or {Readback/Write} for FSU) to update the calibration data

Fig. 6-31: Individual Axis Home Position Calibration



- 6 Robot Settings
- 6.7 Home Position Calibration

6.7.2.2 All Axes Calibration Procedure

Use this method if multiple axes are misaligned after a robot crash.

- 1. Go to {MENU} \rightarrow {Robot Settings} \rightarrow {Home Position Calibration}.
- 2. Perform the verification procedure described in *chapter 6.7.1*" *Verification of Home Position Calibration*".
- 3. Jog all axes until each pair of arrows are aligned.
- 4. Press {Calibrate All Axes} to insert the robot's current pulse values for all axes.
- 5. Press {Save All} (or {Readback/Write} for FSU) to update the calibration data.

Fig. 6-32: All Axis Home Position Calibration

6-51


| Position Setup | Home Calibration | _ | | | READBACK |
|-------------------------|-------------------------|-----------|------------------------|---|----------|
| Set Origins for Robot's | s Encoders to Define It | ts Zero P | Posture | 5 | (Ì |
| | S | 100 | SET ORIGIN | | |
| Manual Entry? | L | 100 | SET ORIGIN | | |
| ROBOT CURRENTLY | | 200 | SET ORIGIN | | |
| HOME POSITION | R | 200 | SET ORIGIN | | |
| | В | 300 | SET ORIGIN | | |
| | Т | 300 | SET ORIGIN | | |
| | | ORIGIN FO | R ALL AXES POSITION | | |

- 6 Robot Settings
- 6.7 Home Position Calibration

6.7.2.3 Manual Calibration Procedure

Use this method if the manipulator or YRC Controller is replaced with a new unit. This method is also used to re-enter the existing Home Position values that appear to be correct but are not "set".

- 1. Go to $\{MENU\} \rightarrow \{Robot \ Settings\} \rightarrow \{Home \ Position \ Calibration\}.$
- 2. Locate the "ABSOLUTE DATA" white tag on the YRC Controller containing the factory default robot encoder calibration.
- Fig. 6-33: "ABSOLUTE DATA" white tag



3. Check the {Manual Entry?} checkbox.

Fig. 6-34: Manual Axis Home Position Calibration

| Position Setup | Home Calibrati | on | (S) CA | | READBACK |
|-------------------------|-------------------|---------------|------------|---|----------|
| Set Origins for Robot's | Encoders to Defin | e Its Zero Po | osture | 5 | |
| | S | 2548 | SET ORIGIN | | |
| 3 Manual Entry? | L |) 1016 | SET ORIGIN | | |
| ROBOT CURRENTLY. | AT U | 1720 | SET ORIGIN | | |
| HOME POSITION | R | -1504 | SET ORIGIN | | |
| | В | 2170 | SET ORIGIN | | |
| | т | -19754 | SET ORIGIN | | |
| | | T ORIGIN FOR | | | |

4. Manually enter the data for each axis using the keyboard.

6 Robot Settings

NOT

- 6.7 Home Position Calibration
- 5. Press {Save All} (or {Readback/Write} for FSU) to update the calibration data.
 - Alarms may occur if large changes are made to the Home Position.
 - In the case of Alarm 4511, reset the alarm and proceed normally.
 - If large changes are made to the Home Position of a collaborative HC-series robot, Alarm 1933 may occur.
 - This major alarm will require a reboot of the YRC Controller to successfully clear the error.

- 6
- Robot Settings Home Position Calibration 6.7

HW1485509

6-54

- Concurrent I/O (Input/Output)
- 7.1 Features of Concurrent I/O

7 Concurrent I/O (Input/Output)

7

Concurrent I/O control processes control relative to the YRC Controller I/O. Concurrent I/O control is independent of the manipulator operation (in parallel with manipulator operation).

7.1 Features of Concurrent I/O

Attaching I/O signals to terminals and connects can boost efficiency.

- Terminals and connectors are provided for connecting I/O signals.
 - Although the number of connections is limited, only the necessary signals are connected at any time, ensuring efficient operations.
- Instructions relative to the I/O (Robot Language: INFORM) can be simplified for smooth manipulator operation.

Fixed procedures relative to the I/O can be registered as independent programs, enabling simplification of I/O instructions in the job (operation program) and reducing interruptions.

A reserved signal can be accepted while the manipulator is operating.

Reserved signals can be accepted during operation since the manipulator operation processing and I/O processing can be executed at the same time.

- 7 Concurrent I/O (Input/Output) Classification of I/O signals
- 7.2

7.2 **Classification of I/O signals**

| Classification | Description | Range |
|------------------------|---|---------------------------------|
| General-Purpose Input | Referenced with input instruction of the job | 00010 - 05127 (4096 signals) |
| General-Purpose Output | Referenced with output instruction of the job | 10010 - 15127 (4096 signals) |
| Specific Input | Signal to change the operating condition of the manipulator | 40010 - 42567 (2048 signals) |
| Specific Output | Signal notifying the operating condition of the manipulator | 50010 - 55127 (4096 signals) |

7-2

- 7 Concurrent I/O (Input/Output)
- 7.3 I/O Instructions

7.3 I/O Instructions

A Robot system rarely works without having to interact with other devices. Most instances, the YRC Controller must communicate with external equipment, such as fixtures and sensors. Communication is accomplished using Universal Inputs and Outputs. The INFORM language supports I/O instructions for both digital input and output.

7.3.1 DigitalOut Output#()

The DigitalOut instruction with the Output#() tag can only operate an individual Universal Output. It is used any time a device, such as a gripper, is to be turned ON or OFF.

The following is an example of the DigitalOut instruction used with a single Universal Output (Output#):

DigitalOut Output#(1) ON

JointMove Speed = 25%

DigitalOut Output#(1) OFF

To program a DigitalOut Output#() instruction in a job, perform the following steps:

- 1. In MANUAL (TEACH) mode, move the cursor to a line to insert the instruction in the Job Contents view.
- 2. Open {COMMANDS} from the Navigation Bar.
- 3. Select {DigitalOut} under {I/O}. The DigitalOut will be inserted in the Job Contents.
- 4. Open Detail Edit by tapping the right of the cursor.
- 5. Select the type of output as single universal output {OT#()}.
- 6. Insert the output signal number (ex. insert 1 for output number 1).
- 7. Choose ON/OFF/INVERT.
- 8. Press {SAVE ALL}.



By default, once an Output has been turned ON, it will remain ON it is turned OFF by a job instruction or manually turned OFF.

- 7 Concurrent I/O (Input/Output)
- 7.3 I/O Instructions

7.3.2 Digital Output for a Group

The Digital Output instruction with the OutputGroup#() tag commands all 8 output bits in the designated Universal Output Group to become the status of Byte range of 0-255. The decimal number is converted into a binary number, with each bit identifying the status for the individual outputs in the group.

For example, the result of DigitalOut OutputGroup#(1) = 162 would be Outputs 2, 6 and 8 ON (2 + 32 + 128 = 162), and Outputs 1, 3, 4, 5 and 7 would be OFF.

In the job example below, Outputs 1 and 5 would be turned ON (1 + 16 = 17) as all others in the group would be turned OFF. The DigitalOutput OuputGroup#(2) turns all 8 outputs in the group OFF.

DigitalOut OutputGroup #(1) 17

JointMove Speed = 25%

DigitalOut OutputGroup #(1) 0

7 Concurrent I/O (Input/Output)

7.4 Monitoring I/O from Smart Pendant Interface

7.4 Monitoring I/O from Smart Pendant Interface

7.4.1 Monitoring I/O Signals by I/O Monitor

I/O signals can be monitored using the Watch Window, placed under {Program/Operate} in {MENU}.

To maximize I/O panel, tap the expand icon on the right-hand side of the title of I/O. Tap it again to change the panel back to its original size.

The values shown in the Watch Windows are updated every second.

Fig. 7-1: I/O Monitor

| < ₩ | Vatch Window | | | | Î | CLEAR ALL |
|-----------|--------------|---------------------------|----------|--------|------|-----------|
| Variables | K 7 K 9 | Q BROWSE VARIABLES | Positior | | | POSITIONS |
| No. | Contents | Name 📑 | No. | Name | Tool | Ĩ |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| nputs/Ou | utputs (I/O) | | | | Q B | ROWSE I/O |
| nput | Status Nam | e Î F | Output | Status | Name | Ĩ |
| | | | | | | |

7 Concurrent I/O (Input/Output)

7.4 Monitoring I/O from Smart Pendant Interface

7.4.2 I/O Windows

Signal status can be monitored using the instructions described in this section.

7.4.2.1 Smart Pendant I/O Configuration

The YRC Controller has a total of 4096 signals available for both input and output. From the Software Pendant, these can be configured/mapped to a variety of physical or network devices. These signals can also be used as purely logical signals. In practice, only a small subset of these signals will be used in most applications.

The Smart Pendant will read the I/O configuration from the YRC Controller and display the configured data. There is also an option for displaying any "unmapped" signals so that the entire 4096 range can be viewed on Smart Pendant if desired. The following sections will describe the screens for monitoring these I/Os as well as how to configure the displays.



I/O Signal Allocation/Mapping must be done on Software Pendant. Smart Pendant will only use configuration already present on YRC Controller.

7.4.2.2 I/O Screens

To access the I/O Screens, press {MENU}, {Program/Operate}, and then select {I/O}. This will open the main I/O Screen. This screen has two main views: Group View and Individual View. By default, the Group View will be visible. The Group/Individual View can be changed from the I/O Setting panel described under *"I/O Settings"* section.

7-6

- 7 Concurrent I/O (Input/Output)
- 7.4 Monitoring I/O from Smart Pendant Interface

Group View

In Group View, the signals are displayed in groups of 8. ON status is shown as a green circle, and OFF status is shown as a white circle. The status is shown from 1 to 8 with a bit order reading from right to left. When the group is selected on the left side, the status of each I/O number will be displayed on the right side of the screen.

Fig. 7-2: I/O Group View

| | | | SERVO |) | | | F 2 |
|-------|--------|----------|--------|-------|-----------------------|------|------------------------------|
| ÷ | I/O | | | | | | |
| Inp | uts | Outputs | | ± 4/2 | Go To: | 1 | Settings |
| Group | Inputs | Status (| | GROU | JP: 5 | | VALUE (DEC): 2 |
| | | 7 6 5 4 | 3210 | | T: 33-40 : General | | VALUE (HEX): 0x02 |
| 1 | 1-8 | 0000 | 0000 | | | | |
| 2 | 9-16 | 0000 | 0000 | Input | Status | Name | |
| 3 | 17-24 | •000 | 0000 | 33 | 0 | | |
| 4 | 25-32 | 0000 | 0000 | 34 | ٠ | | |
| 5 | 33-40 | 400000 | 000033 | 35 | 0 | | |
| 6 | 41-48 | 0000 | •000 | 36 | 0 | | |
| 7 | 49-56 | 0000 | 0000 | 37 | 0 | | |
| 8 | 57-64 | •000 | 0000 | 38 | 0 | | |
| 9 | 65-72 | 0000 | 0000 | 39 | 0 | | |

■ Go To an I/O Group Containing an I/O Number

- 1. Press the text field to the right of {Go To:}.
 - The keypad will appear.
- 2. Enter the I/O number and press {Enter}.
 - The view will go to the I/O group containing that I/O number and highlight it.

Additional information about the selected group is displayed on the top right of the screen. This information includes:

- GROUP: the group number of the inputs.
- INPUT: the 8 inputs within the specified group.
- TYPE: The input type as configured from the YRC Controller
- VALUE (DEC): the value of the group in decimal.
- VALUE (HEX): the value of the group is hexadecimal.
- Enable Toggle (for Outputs only): Output signals can be toggled with toggle switches. When {Enable Toggle} checkbox is not checked, the output toggle switch is disabled. When {Enable Toggle} checkbox is checked, the output toggle switch is enabled for individual outputs. This is shown in *fig. 7-3 "Toggle Output from Group View"*.

- 7 Concurrent I/O (Input/Output)
- 7.4 Monitoring I/O from Smart Pendant Interface

Fig. 7-3: Toggle Output from Group View

| | | | SERVO | D | | P 🕿 |
|-----------|---------|----------|-------|---------------------------|----------|------------|
| ← Inpu | I/O | Outputs | | <u>+</u> ,,, Go To: | 1 § | Settings |
| Group | Outputs | Status (| Bits) | GROUP: 3 OUTPUT: 17-24 | VALUE (| |
| 1 | 1-8 | 0000 | 0000 | TYPE: General | | ble toggle |
| 2 | 9-16 | 0000 | 0000 | Output Otatus | | |
| 3 | 17-24 | 240000 | 00017 | Output Status | Name | Toggle |
| 4 | 25-32 | 0000 | 0000 | 17 • | SUCTION | |
| 5 | 33-40 | 0000 | 0000 | 18 🔴 | BLOW OFF | |

Individual View

In Individual View, each I/O signal is displayed on a separate line as shown in *fig. 7-4 "I/O Individual View"*.

Fig. 7-4: I/O Individual View

| | งม 🏹 | | L) | SERVO | | P 2 |
|-------|--------|---------|---------------------------------------|-------|------------------|-------------------------|
| ÷ | I/O | | | | | |
| Inpu | uts | Outputs | [⊥] _{⊲/>} Go To: | 1 | Display only nar | ned Q 🔅 Settings |
| No. 🔺 | Status | Toggle | Туре | | Name | Enable toggle |
| 20 | • | | General | | | |
| 21 | 0 | | General | | | |
| 22 | 0 | | General | | | |
| 23 | 0 | | General | | | |
| 24 | 0 | | General | | | |
| 25 | 0 | | General | | | |
| 26 | • | | General | | | |
| 27 | 0 | | General | | | |
| 28 | 0 | | General | | | |
| 29 | 0 | | General | | | |
| 30 | 0 | | General | | | |
| 31 | 0 | | General | | | |
| 32 | 0 | | General | | | |
| 33 | 0 | | General | | | |
| 34 | ٠ | | General | | | |
| 35 | 0 | | General | | | |
| 36 | 0 | | General | | | |



Concurrent I/O (Input/Output)

7

7.4 Monitoring I/O from Smart Pendant Interface

Output signals can also be toggled from the Individual View. When {Enable Toggle} checkbox is not checked, the output toggle switch is disabled. When {Enable Toggle} checkbox is checked, the output toggle switch is enabled for individual outputs. This is shown in *fig. 7-5 "Toggle Output from Individual View"*.

Fig. 7-5: Toggle Output from Individual View

| | u G | | SERV | 0 | P 2 |
|-------|--------|---------|----------|----------------------|------------------------|
| ← I/ | 0 | | | | |
| Input | S | Outputs | 🔤 Go To: | 1 Display only named | ද { හි Settings |
| No. 🔺 | Status | Toggle | Туре | Name | Enable toggle |
| 1 | 0 | | General | | |
| 2 | 0 | | General | | |
| 3 | 0 | | General | | |
| 4 | 0 | | General | | |
| 5 | • | | General | | |
| 6 | 0 | | General | | |

Go To an I/O Number

- 1. Press the text field to the right of {Go To:}.
 - The keypad will appear.
- 2. Enter the I/O number and press {Enter}.

7-9

- The view will go to the I/O number and highlight it.

I/O Settings

To access I/O Settings, press the {SETTINGS} on the top of the panel. This will bring up the panel shown in *fig.* 7-6 *"I/O Display Settings"*.

| ← 1/0 | | | | | | |
|--------|---------|---|---|----------------------|---|----------|
| Inputs | Outputs | in the second s | 1 | Display only named Q | ŝ | Settings |

This panel has two sections: Display Settings (1) and Types to Display (2).

In the {Display Settings}, the view can be switched between the Group View and Individual View that are mentioned in the previous sections.

In the {Types to Display}, the I/O display can be filtered based on how the I/O are configured on the YRC Controller. For example, if all checkboxes were cleared except the "Terminal Block", then only the I/Os associated with the standard Terminal Blocks would be displayed (i.e. 1-24 for YRC1000 and 1-8 for YRC1000micro).

7.4 Monitoring I/O from Smart Pendant Interface

The "Unmapped" checkbox is false by default. Checking this box will display all 4096 I/Os can be seen on the YRC Controller.



I/O Display Type Settings are separate for Input and Output. For example, it is possible to set "Group View" for Inputs and "Individual View" for Outputs.

Fig. 7-6: I/O Display Settings

| Input Output Settings | | × |
|------------------------|-------------------------|-----|
| Input Display Type | Output Display Type | (i) |
| Groups | O Groups | |
| O Individual Inputs | Individual Outputs | |
| Input Types to Display | Output Types to Display | |
| General | General | |
| Unmapped | Unmapped | |

The "types" displayed in the above list will be dependent on the devices that have been configured for the system. These devices can either be extra I/O boards (see Chapter 12.2 of "YRC1000 INSTRUCTIONS (RE-CTO-A221)") or network devices such as EtherNet/IP. For example, if an EtherNet/IP gripper were added with the name "Gripper", then this would be displayed under the types as "Gripper". For more information on configuring EtherNet/IP devices, see "YRC1000 OPTIONS INSTRUCTIONS EtherNet/IP COMMUNICATION FUNCTION (HW143560)".

There is also a half-screen version of the I/O Screens located from the Programming Panel (*fig. 7-7 "Half Screen I/O Window"*). To access this, first select {Current Job} from the {MENU}. Then, select {Digital I/O} from the Navigation Bar. This screen has all the functionality of the full-screen I/O Windows in a half-screen form.

- 7
- Concurrent I/O (Input/Output) Monitoring I/O from Smart Pendant Interface 7.4

Fig. 7-7: Half Screen I/O Window

| | iu (| 7 🖌 | | SERVO | | | | P | 2 N |
|---------|--------------|-------------|-------------|-------|----------------------------------|------|-------|--------------------------|--------|
| {्रि} R | OBOT JOB - S | SAMPLE | | | | | 0 | | ŝ |
| 1 Sta | art Job | | | | | | | | |
| 2 Joi | ntMove | Speed=50.00 | (%) | | | | | | |
| 3 End | Job | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | () т | ACH | JOINT MOV | /E |
| | | | | | | | | | |
| €⊅⊅ | igitalOut | දිාූි Timer | දිරිූි Wait | | | | | | \sim |
| Inpu | its | Outputs | SETTING | GS | | | | | |
| Group | Inputs | Status | | | JP: 1 T: 1-8 :: Terminal B | lock | VALUE | (DEC): 32 (HEX): 0x20 | 0 |
| 1 | 1-8 | 0000 | 0000 | Input | Status | Name | | | |
| 2 | 9-16 | 0000 | 0000 | 1 | 0 | | | | |
| 3 | 17-24 | 0000 | 0000 | 2 | 0 | | | | |
| 4 | 25-32 | 0000 | 0000 | 3 | 0 | | | | |
| 5 | 33-40 | 0000 | 0000 | 4 | 0 | | | | |
| 6 | 41-48 | 0000 | 0000 | 5 | 0 | | | | |
| 7 | 49-56 | 0000 | 0000 | 6 | • | | | | |
| 8 | 57-64 | 0000 | 0000 | 7 | 0 | | | | |
| 9 | 65-72 | 0000 | 0000 | 8 | 0 | | | | |
| 10 | 73-80 | 0000 | 0000 | 77 | ~ | | | | |
| | | | | | | | | | |
| 11 | 81-88 | 0000 | 0000 | | | | | | |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

7.5 I/O Detailed View

7.5.1 I/O Detailed View Overview

The I/O Detailed View will appear on right panel of both {Inputs} and {Outputs} when an I/O group is long-pressed. It displays detailed information for a selected concurrent block of I/O groups.

- Selection size of 1, 2, 3 or 4 bytes. Each I/O group is one byte.
- Allows Output editing of the full selected I/O block in one step.
- Allows Output editing of individual half-bytes, or bytes in the selected I/O block in one step.



7-12

HW1485509

7 Concurrent I/O (Input/Output) I/O Detailed View

7.5

Fig. 7-8: Input Detailed View

| | - | Detailed Vie | | | | |
|-------|---------|---------------------|------------------|----------------------------|---------|------------------------------------|
| _ M | | | SERVO | 0 | | |
| ÷ | 1/0 | | | | | |
| Inp | outs | Outputs | | ± _{s/>} Go To: | 1 | දිාී Settings |
| Group | Inputs | Status (7 6 5 4 | Bits) 3 2 1 0 | Detail Vie | ew - In | puts |
| 1 | 1-8 | 80000 | 00001 | Number Sele | ected | Show Individually |
| 2 | 9-16 | 0000 | 0000 | | | |
| 3 | 17-24 | •000 | 0000 | Full Selecti | on | |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-1 INPUTS: 1-8 | | VALUE (DEC): 32 VALUE (HEX): 20 |
| 5 | 33-40 | 0000 | 0000 | GROUP: 1 | 7 6 5 | |
| 6 | 41-48 | 0000 | •000 | | | |
| 7 | 49-56 | 0000 | 0000 | | | |
| 8 | 57-64 | •000 | 0000 | | | |
| 9 | 65-72 | 0000 | 0000 | | | |
| 10 | 73-80 | 0000 | 0000 | | | |
| 11 | 81-88 | 0000 | 0000 | | | |
| 12 | 89-96 | •000 | 0000 | | | |
| 13 | 97-104 | 0000 | 0000 | | | |
| 14 | 105-112 | 0000 | 0000 | | | |
| 15 | 113-120 | 0000 | •000 | | | |
| 16 | 121-128 | 0000 | 0000 | | | |
| 17 | 129-136 | •000 | 0000 | | | |
| 18 | 137-144 | 0000 | 0000 | | | |
| 19 | 145-152 | 0000 | 0000 | | | |
| 20 | 153-160 | 0000 | 0000 | | | |
| 21 | 161-168 | •000 | 0000 | | | |
| 22 | 169-176 | 0000 | 0000 | | | |
| | | | | | | |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Fig. 7-9: Output Detailed View

| ме | | L 14 | SERV | 0 e 2 |
|-------|---------|----------|-------|---|
| ÷ | I/O | | | |
| Inp | uts | Outputs | | ± _{s/s} Go To: 1 {☉} Setting |
| Group | Outputs | Status (| Bits) | Detail View - Outputs |
| 1 | 1-8 | 80 0 0 | 00001 | Number Selected |
| 2 | 9-16 | 0000 | 0000 | One Byte ~ Show individually |
| 3 | 17-24 | 0000 | 0000 | Full Selection |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-1 Write Format OUTPUTS: 1-8 Hex Dec |
| 5 | 33-40 | 0000 | 0000 | |
| 6 | 41-48 | 0000 | 0000 | VALUE (DEC): 64 |
| 7 | 49-56 | 0000 | 0000 | 7 6 5 4 3 2 1 0 GROUP: 1 Image: Compare the second s |
| 8 | 57-64 | 0000 | 0000 | |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | |
| 11 | 81-88 | 0000 | 0000 | |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | |
| 14 | 105-112 | 0000 | 0000 | |
| 15 | 113-120 | 0000 | 0000 | |
| 16 | 121-128 | 0000 | 0000 | |
| 17 | 129-136 | 0000 | 0000 | |
| 18 | 137-144 | 0000 | 0000 | |
| 19 | 145-152 | 0000 | 0000 | |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

■ Accessing the I/O Detailed View from the Main Menu

1. Go to {MENU} \rightarrow {Program/Operate} \rightarrow {I/O}.

7-14

- 2. To view the Inputs Detailed View, press {Inputs} or to view the Outputs Detailed View, press {Outputs}.
- 3. Press and hold an I/O group row in the left panel for two seconds.
 - The I/O Detailed View will appear in the right panel.
 - The default number selected is one byte, the size of one I/O group.
- 4. To set the number of bytes selected, press {Number Selected} and select {One Byte}, {Two Bytes}, {Three Bytes} or {Four Bytes}.



- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View
- Accessing the I/O Detailed View from the Current Job Screen 1. Go to {MENU} → {Current Job}.
 - 2. Press {Digital I/O} in the lower left corner of the screen.
 - 3. The I/O view will appear in the lower half of the screen.
 - 4. To view the Inputs Detailed View, press {Inputs} or to view the Outputs Detailed View, press {Outputs}.
 - 5. Press and hold an I/O group row in the left panel for two seconds.
 - The I/O Detailed View will appear in the right panel.
 - The default number selected is one byte, the size of one I/O group.
 - 6. To set the number of bytes selected, press {Number Selected} and select {One Byte}, {Two Bytes}, {Three Bytes} or {Four Bytes}.

Fig. 7-10: I/O Detailed View from Current Job

| | | | SERVO | |
|-----------|---------------|---------------------|------------------|---|
| | ROBOT JOB - L | LONGJOB | | 2 🗟 🔅 |
| 1 | Start | Job | | |
| 2 | Digita | alOut Output# | ‡(5) OFF | |
| 3 | Shift(| On P[B005] | | |
| 4 E (|] Joint | Move Speed=10 | 00.00(%) Acc | eleration=50(%) |
| 5 E (|] Joint | Move Speed=75 | 5.00(%) Acce | leration=50(%) Deceleration=20(%) |
| 6 E (|] Linea | rMove Speed=2 | 250.0(mm/sec |) PositionLevel=0 |
| 7 | Digita | alOut Output# | ‡(5) ON | |
| 8 | Timer | Time=0.50(se | econds) | TEACH JOINT MOVE |
| 9 Г (|] Linea | Move Speed=: | 250 0(mm/sec | |
| \supset | DigitalOut | လ္ကို Timer | င့်} Wait | leration=RAAA(%) |
| Inp | uts | Outputs | | ि Go To: 1 🔅 Settings |
| Group | Inputs | Status (7 6 5 4 | Bits) 3 2 1 0 | Detail View - Inputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected One Byte V |
| 2 | 9-16 | 0000 | 0000 | |
| 3 | 17-24 | •000 | 0000 | Full Selection |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-1 VALUE (DEC): 32 INPUTS: 1-8 VALUE (HEX): 20 |
| 5 | 33-40 | 0000 | 0000 | 7 6 5 4 3 2 1 0 GROUP: 1 Image: Complex com |
| 6 | 41-48 | 0000 | •000 | |
| 7 | 49-56 | 0000 | 0000 | |
| 8 | 57-64 | •000 | 0000 | |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | |
| 11 | 81-88 | 0000 | 0000 | |
| DIG | ↑ ITAL I/O | B= VARIABLES | | G COMMANDS TEST/RUN JOB |



- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Switching Between Output Decimal and Hexadecimal Write Formats In {Outputs} I/O Detailed View, press the {Write Format} switch under {Full Selection}.

| E ME | NU 🖓 | La je | SERV | 0 | P 2 |
|-------|---------|---------------------|-------|-----------------------------|---------------------------|
| ÷ | I/O | | | | |
| Inpu | uts | Outputs | | ±,,, Go To: 1 | දිූි Settings |
| Group | Outputs | Status (7 6 5 4 | Bits) | Detail View - Outp | outs |
| 1 | 1-8 | 80 • 00 | 00001 | Number Selected | Show Individually |
| 2 | 9-16 | 0000 | 0000 | | |
| 3 | 17-24 | 0000 | 0000 | Full Selection | |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-1 OUTPUTS: 1-8 | Write Format Hex 🚺 Dec |
| 5 | 33-40 | 0000 | 0000 | VALUE (DEC): | 64 |
| 6 | 41-48 | 0000 | 0000 | 7 6 5 4 | 3210 |
| 7 | 49-56 | 0000 | 0000 | GROUP: 1 O O O O | |
| 8 | 57-64 | 0000 | 0000 | | |
| 9 | 65-72 | 0000 | 0000 | | |
| 10 | 73-80 | 0000 | 0000 | | |
| 11 | 81-88 | 0000 | 0000 | | |
| 12 | 89-96 | 0000 | 0000 | | |
| 13 | 97-104 | 0000 | 0000 | | |
| 14 | 105-112 | 0000 | 0000 | | |
| 15 | 113-120 | 0000 | 0000 | | |
| 16 | 121-128 | 0000 | 0000 | | |
| 17 | 129-136 | 0000 | 0000 | | |
| 18 | 137-144 | 0000 | 0000 | | |
| 19 | 145-152 | 0000 | 0000 | | |
| | | 0.000 | 0000 | | |

F

0000 0000

0000 0000

0000 0000

153-160

161-168

169-176

20

21

22

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Input Full Selection Layout

Near the top of the input Detailed View. It has information for the selected input groups as a block.

{Full Selection} has:

① Selected input group numbers.

② Selected input numbers.

③ Decimal or hexadecimal value for the entire block as one number.

 \circledast Circles that show the status of each bit in the block, and the bit number above each circle. Green is on, white is off. Zero is the least significant bit.

| Fig. 7-1 | 2: Input | Detailed | View | Full | Selection |
|----------|----------|----------|------|------|-----------|
|----------|----------|----------|------|------|-----------|

| ≡ м | ENU 🧖 | 12 L | SERV | · 🛛 🖉 🕿 |
|-------|---------|---------------------|------------------|---|
| ÷ | I/O | | | |
| Inp | outs | Outputs | | 🗐 Go To: 1 🛞 Settings |
| Group | Inputs | Status (7 6 5 4 | Bits) 3 2 1 0 | Detail View - Inputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected One Byte V Show Individually |
| 2 | 9-16 | 0000 | 0000 | |
| 3 | 17-24 | 0000 | 0000 | Full Selection |
| 4 | 25-32 | 0000 | 0000 | 0 GROUPS: 1-1 |
| 5 | 33-40 | 0000 | 0000 | @ GROUP: 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 |
| 6 | 41-48 | 0000 | 0000 | |
| 7 | 49-56 | 0000 | 0000 | |
| 8 | 57-64 | 0000 | 0000 | |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | |
| 11 | 81-88 | 0000 | 0000 | |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | |
| 14 | 105-112 | 0000 | 0000 | |
| 15 | 113-120 | 0000 | 0000 | |
| 16 | 121-128 | 0000 | 0000 | |
| 17 | 129-136 | 0000 | 0000 | |
| 18 | 137-144 | 0000 | | |
| 19 | 145-152 | 0000 | 0000 | |
| 20 | 153-160 | 0000 | 0000 | |
| 20 | | 0000 | 0000 | |
| | 161-168 | | | |
| 22 | 169-176 | 0000 | 0000 | |

HW1485509

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Input Individual Sections Layout

Located under the {Full Selection} in the I/O Detailed View. It has information on each individual I/O group in the selected block.



Individual Selections are not visible by default.

- ① Selected I/O group number.
- ② Selected I/O numbers.
- ③ Selected I/O group type.
- ④ Decimal or hexadecimal value for the I/O group.

© Circles that show the status of each bit in the block, and the bit number above each circle. Green is on, white is off. Zero is the least significant bit.

© Decimal or hexadecimal value for the two half-bytes in the I/O group.

7 Concurrent I/O (Input/Output) I/O Detailed View

7.5

Fig. 7-13: Input Detailed View Individual Selection

| | NU 🖓 | L_ 14 | SERV | |
|-------|----------------------|------------|------------------|---|
| ÷ | I/O | | | |
| Inpu | uts | Outputs | | 느,, Go To: 1 (한 Settings |
| Group | Inputs | Status (| Bits) 3 2 1 0 | Detail View - Inputs |
| 1 | 1-8 | 80 • 00 | 00001 | Number Selected Two Bytes 🗸 🗹 Show Individually |
| 2 | 9-16 | 16 🔿 🔵 🔿 🔿 | 00009 | |
| 3 | 17-24 | 0000 | 0000 | Full Selection Swap Byte Order |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-2 VALUE (DEC): 16448 INPUTS: 1-16 VALUE (HEX): 4040 |
| 5 | 33-40 | 0000 | 0000 | 7 6 5 4 3 2 1 0 GROUP: 1 Image: Compare the second s |
| 6 | 41-48 | 0000 | 0000 | 15 14 13 12 11 10 9 8 GROUP: 2 |
| 7 | 49-56 | 0000 | 0000 | |
| В | 57-64 | 0000 | 0000 | Individual Selections |
| 9 | 65-72 | 0000 | 0000 | ① GROUP: 1 ④ VALUE (DEC): 64 ② INPUTS: 1-8 VALUE (HEX): 40 |
| 10 | 73-80 | 0000 | 0000 | In TYPE: General |
| 11 | 81-88 | 0000 | 0000 | 7 6 5 4 3 2 1 0 (a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c |
| 12 | 89 <mark>-</mark> 96 | 0000 | 0000 | © DECIMAL: 4 0 HEX: 04 00 |
| 13 | 97-104 | 0000 | 0000 | GROUP: 2 VALUE (DEC): 64 |
| 14 | 105-112 | 0000 | 0000 | INPUTS: 9-16 VALUE (HEX): 40 TYPE: General |
| 15 | 113-120 | 0000 | 0000 | |
| 16 | 121-128 | 0000 | 0000 | O |
| 17 | 129-136 | 0000 | 0000 | |
| 18 | 137-144 | 0000 | 0000 | |
| 19 | 145-152 | 0000 | 0000 | |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Output Full Selection Layout

Near the top of the output Detailed View. It has information for the selected I/O groups as a block.

{Full Selection} has:

- ① Selected output group numbers.
- ② Selected output numbers.
- ③ Decimal or hexadecimal value for the entire block as one number.

 Gircles that show the status of each bit in the block, and the bit number above each circle. Green is on, white is off. Zero is the least significant bit.



7-20

| | NU 🖓 | | SERV | • 📮 🕿 |
|-------|--------------------|---------------------|-------|--|
| ÷ | I/O | | | |
| Inpu | uts (| Outputs | | 🗐 Go To: 1 ६००००००००००००००००००००० |
| Group | Outputs | Status (7 6 5 4 | Bits) | Detail View - Outputs |
| 1 | 1-8 | 80000 | 0001 | Number Selected One Byte |
| 2 | 9-16 | 0000 | 0000 | |
| 3 | 17-24 | 0000 | 0000 | Full Selection |
| 4 | 25-32 | 0000 | 0000 | |
| 5 | 33-40 | 0000 | 0000 | ③ VALUE (DEC): 4 |
| 6 | 41-48 | 0000 | 0000 | 7654 3210 |
| 7 | 49-56 | 0000 | 0000 | GROUP: 1 O |
| 8 | 57-64 | 0000 | 0000 | |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | |
| 11 | 81-88 | 0000 | 0000 | |
| 12 | <mark>89-96</mark> | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | |
| 14 | 105-112 | 0000 | 0000 | |
| 15 | 113-120 | 0000 | 0000 | |
| 16 | 121-128 | 0000 | 0000 | |
| 17 | 129-136 | 0000 | 0000 | |
| 18 | 137-144 | 0000 | 0000 | |
| 19 | 145-152 | 0000 | 0000 | |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

HW1485509

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Output Individual Sections Layout

Located under the {Full Selection} in the output Detailed View. It has information on each individual output group in the selected block.



Individual selections are not visible by default.

- ① Selected output group number.
- ② Selected output numbers.
- ③ Selected output group type.
- ④ Decimal or hexadecimal value for the output group.
- © Circles that show the status of each bit in the block, and the bit number above each circle. Green is on, white is off. Zero is the least significant bit.
- © Decimal or hexadecimal value for the two half-bytes in the output group.
- ⑦ Dec/Hex write format switch.

7-21

- 7 Concurrent I/O (Input/Output) I/O Detailed View
- 7.5

Fig. 7-15: Output Detailed View Individual Selection

| ≡ мі | | L i | SERVO | |
|-------|----------------------|---------------------|-------|--|
| ÷ | I/O | | | |
| Inp | outs | Outputs | | للله Go To: 1 دُمْ |
| Group | Outputs | Status (7 6 5 4 | Bits) | Detail View - Outputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected Two Bytes V Show Individually |
| 2 | 9-16 | 160000 | 00009 | |
| 3 | 17-24 | 0000 | 0000 | Full Selection Swap Byte Order |
| 4 | 25-32 | 0000 | 000 | GROUPS: 1-2 Write Format OUTPUTS: 1-16 Hex ODEC |
| 5 | 33-40 | 0000 | 0000 | VALUE (DEC): 0 |
| 6 | 41-48 | 0000 | 0000 | 7654 3210 |
| 7 | 49-56 | 0000 | 0000 | GROUP: 1 0000 0000 |
| 8 | 57-64 | 0000 | 0000 | 15 14 13 12 11 10 9 8 GROUP: 2 Image: Comparison of the second |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | Individual Selections |
| 11 | 81-88 | 0000 | 0000 | GROUP: 1 VALUE (DEC): 0 OUTPUTS: 1-8 TYPE: General |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | 7 6 5 4 3 2 1 0 0000 0000 |
| 14 | 105-112 | 0000 | 0000 | DECIMAL: 0 I 0 |
| 15 | 113-120 | 0000 | 0000 | GROUP: 2 VALUE (DEC): 0 |
| 16 | 121-128 | 0000 | 0000 | OUTPUTS: 9-16 TYPE: General |
| 17 | 129-136 | 0000 | 0000 | 15 14 13 12 11 10 9 8 |
| 18 | 137-144 | 0000 | 0000 | 0000 0000 |
| 19 | 145-152 | 0000 | 0000 | DECIMAL: 0 0 |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | <mark>169-176</mark> | 0000 | 0000 | |
| | | | | |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Accessing Individual Selections



{Show Individually} checkbox is only visible if more than {One Byte} is selected in the {Number Selected} dropdown.

In {Inputs} or {Outputs} I/O Detailed View panel, press {Show Individually} checkbox in the upper right corner of the right panel.

Fig. 7-16: I/O Detailed View Show Individually

| | | | SERVC | | F 2 |
|-------|---------|----------------------|------------------|----------------------------------|-------------------|
| ÷ | I/O | | | | |
| Inpu | uts | Outputs | | ≝ | ැති Settings |
| Group | Outputs | Status (1 7 6 5 4 | Bits) 3 2 1 0 | Detail View - Outp | outs |
| 1 | 1-8 | 80000 | •0001 | Number Selected Two Bytes 🗸 🔽 | Show Individually |
| 2 | 9-16 | 160000 | •••• | | |

7.5.2 Editing Output Values

- Editing requires Editing Security level or above.
- Editing output values is disabled if the selected I/O groups are of different types and a warning will appear. Change your selection so only I/O groups with the same type are selected.

Fig. 7-17: Output Detailed View Editing Warning

| | NU D | | SERV | ′0 | e 2 |
|-------|---------|----------|---------|---|-------------------|
| ÷ | I/O | | | | |
| Inpu | its | Outputs | | ≝ _{⊲>} Go To: 1 | Setting: |
| Group | Outputs | Status (| Bits) | - a . 223 - B | |
| | | 7 6 5 4 | 3 2 1 0 | Detail View - Outp | outs |
| 18 | 137-144 | 0000 | 000● | Selected groups have diffe Editing disabled. | rent types. |
| 19 | 145-152 | 0000 | 0000 | Number Selected | |
| 20 | 153-160 | 0000 | 0000 | Two Bytes 🗸 🗹 | Show Individually |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Press the text field for the value you wish to change.

- A keypad will appear for decimal values, or a keyboard will appear for hexadecimal values.
- Press the keys to set the value and press {Enter}.

Fig. 7-18: Output Detailed View Editing

| MENU ← I/O | | <u>]ı</u> | SEF | RVO | |
|-------------|---------|------------|-----------------|-----------------------|-------------------------------------|
| Inputs | Outputs | | | ± _{s/>} G | io To: 1 දිටු Settings |
| Group Outpu | | Status (Bi | its) 3 2 1 0 | Deta | il View - Outputs |
| 18 137- | | | 0000 | | er Selected |
| 19 145- | 152 00 | 00 | 0000 | One B | yte 🗸 🗹 Show Individually |
| 20 153- | 160 00 | 00 | 0000 | Full S | election |
| 21 161- | 168 00 | 00 | 0000 | | S: 31-31 Write Format |
| 22 169- | 176 🔿 🔵 | 00 | 0000 | UUTPU | ITS: 241-248 Hex 🚺 Dec |
| 23 177- | 184 00 | 00 | 0000 | | VALUE (DEC): 64 |
| 24 185- | 192 00 | 00 | 0000 | GROUP | 7 6 5 4 3 2 1 0 31 0 0 0 0 0 0 0 |
| 25 193-: | 200 00 | 00 | 0000 | | |
| 26 201-3 | 208 00 | 0 | 0000 | Indivi | dual Selections |
| 27 209-2 | 216 🔿 🔵 | 00 | 0000 | | ITS: 241-248 |
| 28 217-2 | 224 00 | 00 | 0000 | TYPE: | General |
| 29 225-: | 232 00 | 00 | 0000 | | 7 6 5 4 3 2 1 0 ••••• |
| 30 233- | 240 00 | 00 | 0000 | DECIM | AL: 4 0 |
| | .0.5 | | T RIGHT | ► c | LEAR |
| | 7 | | <u>ر</u> ۲ | | |
| | | 1 | 2 | 3 | × |
| | | 4 | | 6 | |
| | | 4 | 5 | 6 | |
| | | 7 | 8 | 9 | |
| | | | 0 | · | Enter |

7.5 I/O Detailed View

Table 7-1: Valid Decimal Ranges:

| | Value |
|---|-----------------------|
| 0 | 15 |
| 0 | 255 |
| 0 | 65,535 |
| 0 | 16,777,215 |
| 0 | 4,294,967,295 |
| | 0 0 0 0 0 |

Table 7-2: Valid Hexadecimal Ranges:

| Size | Minimum Value | Maximum Hexadecimal Value |
|-------------|---------------|------------------------------|
| Half Byte | 0 | F |
| One Byte | 0 | FF |
| Two Bytes | 0 | FFFF |
| Three Bytes | 0 | FFFFF |
| Four Bytes | 0 | FFFFFFF |

Swap Byte Order

There are two different formats for combining multiple bytes into one multibyte number.

- Smallest group number is the least significant byte, {Swap Byte Oder} not checked, default.
- Largest group number is the least significant byte, {Swap Byte Order} checked.

External devices connected to the Robotic system often use varying methods of data transfer. Try swapping the byte order if unexpected values appear while reading or writing multi-byte values.



{Swap Byte Order} is only available when more than {One Byte} is selected in {Number Selected} dropdown

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Swap Byte Order Example

For example, if GROUP 1 has a value of one and GROUP 2 has a value of zero, and both are selected, then the full value is ((GROUP 2) (GROUP 1)), or in binary, (0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1) which has a value of 1.

| Fig. 7-19: Swap | Order Example | e Not Checked |
|-----------------|---------------|---------------|
|-----------------|---------------|---------------|

| | 0 | | SERVC | |
|-----------|------------|---------------------|-------|--|
| ← Inpu | I/O uts | Outputs | | 🚋 Go To: 1 🔅 Settings |
| Group | Outputs | Status (7 6 5 4 | Bits) | Detail View - Outputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected |
| 2 | 9-16 | 160000 | 00009 | Two Bytes V Show individually |
| 3 | 17-24 | 0000 | 0000 | Full Selection Swap Byte Order |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-2 Write Format OUTPUTS: 1-16 Hex Oct |
| 5 | 33-40 | 0000 | 0000 | VALUE (DEC): 1 |
| 6 | 41-48 | 0000 | 0000 | 7654 3210 |
| 7 | 49-56 | 0000 | 0000 | GROUP: 1 0000 0000 |
| 8 | 57-64 | 0000 | 0000 | 15 14 13 12 11 10 9 8 GROUP: 2 O |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | Individual Selections |
| 11 | 81-88 | 0000 | 0000 | GROUP: 1 VALUE (DEC): 1 OUTPUTS: 1-8 TYPE: General |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | 7 6 5 4 3 2 1 0 0000 000 |
| 14 | 105-112 | 0000 | 0000 | DECIMAL: 0 I 1 |
| 15 | 113-120 | 0000 | 0000 | GROUP: 2 VALUE (DEC): 0 |
| 16 | 121-128 | 0000 | 0000 | OUTPUTS: 9-16 TYPE: General |
| 17 | 129-136 | 0000 | 0000 | 15 14 13 12 11 10 9 8 |
| 18 | 137-144 | 0000 | 0000 | 0000 0000 |
| 19 | 145-152 | 0000 | 0000 | DECIMAL: 0 I 0 |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

- 7 Concurrent I/O (Input/Output)
- 7.5 I/O Detailed View

Pressing the {Swap Byte Order} checkbox reverses the byte order, and the highest I/O group number is the least significant byte. In the previous example, swapping the byte order would change the full value to ((GROUP 1) (GROUP 2)) or in binary, (0 0 0 0 0 0 1 0 0 0 0 0 0 0 0) which has a decimal value of 256.

Fig. 7-20: Swap Order Example Checked

| | 0 | | SERV | |
|-----------|------------|----------|-------|---|
| ← Inpu | I/O uts | Outputs | | 🔄 Go To: 1 🐯 Settin |
| Group | Outputs | Status (| Bits) | |
| | | 7654 | 3210 | Detail View - Outputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected Two Bytes V Show Individually |
| 2 | 9-16 | 160000 | 90009 | |
| 3 | 17-24 | 0000 | 0000 | Full Selection Swap Byte Order |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 2-1 Write Format OUTPUTS: 1-16 Hex Dec |
| 5 | 33-40 | 0000 | 0000 | |
| 6 | 41-48 | 0000 | 0000 | VALUE (DEC): 256 |
| | | | | 7 6 5 4 3 2 1 0 GROUP: 2 0000 |
| 7 | 49-56 | 0000 | 0000 | 15 14 13 12 11 10 9 8 |
| 8 | 57-64 | 0000 | 0000 | GROUP: 1 0000 000 |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | Individual Selections |
| 11 | 81-88 | 0000 | 0000 | GROUP: 2 VALUE (DEC): 0 OUTPUTS: 9-16 TYPE: General |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | 7 6 5 4 3 2 1 0 0000 0000 |
| 14 | 105-112 | 0000 | 0000 | DECIMAL: 0 0 |
| | | | | |
| 15 | 113-120 | 0000 | 0000 | GROUP: 1 VALUE (DEC): 1 OUTPUTS: 1-8 |
| 16 | 121-128 | 0000 | 0000 | TYPE: General |
| 17 | 129-136 | 0000 | 0000 | 15 14 13 12 11 10 9 8 |
| 18 | 137-144 | 0000 | 0000 | 0000 0000 |
| 19 | 145-152 | 0000 | 0000 | DECIMAL: 0 I 1 |
| 20 | 153-160 | 0000 | 0000 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

- 7 Concurrent I/O (Input/Output)
- 7.6 EtherNet/IP Status Warning

7.6 EtherNet/IP Status Warning

Problems with EtherNet/IP communication will be illuminated by a yellow warning box surrounding the EtherNet/IP Status byte in the {Inputs} panel. A help icon will appear containing descriptions for each bit in the EtherNet/ IP Status byte.

How To View the EtherNet/IP Status Byte

- 1. Go to {MENU} \rightarrow {Program/Operate} \rightarrow {I/O}.
- 2. Press {Inputs}.
- 3. Press {Settings}.
 - {Input Output Settings} panel will appear.
- 4. Under {Input Types to Display} check {EtherNet/IP Status}.
- 5. Click {X} in upper right of {Input Outputs Settings} panel.
 - {Input Output Settings} panel will close.
 - The {EtherNet/IP Status} input group will be in the left panel.

Fig. 7-21: EtherNet/IP Status Warning

| Inpu | uts | Outputs | | ± | Go To: | 1 | දිබූ Settings |
|-------|--------|-----------|---------|--------------|--------|-----------|-----------------|
| Group | Inputs | | | GROU | IP: 4 | | VALUE (DEC): 32 |
| | | 7 6 5 4 | 3 2 1 0 | INPUT: 25-32 | | | |
| 1 | 1-8 | 0000 | 0000 | | | in otatuo | |
| 2 | 9-16 | 0000 | 0000 | Input | Status | Name | |
| 3 | 17-24 | 0000 | •000 | 25 | 0 | | |
| 4 | 25-32 | () 32○○●○ | 000025 | 26 | 0 | | |
| 5 | 33-40 | •000 | 0000 | 27 | 0 | | |
| 6 | 41-48 | 0000 | 0000 | 28 | 0 | | |
| 7 | 49-56 | 0000 | 0000 | 29 | 0 | | |
| 8 | 57-64 | 0000 | •000 | 30 | • | | |
| 9 | 65-72 | 0000 | 0000 | 31 | 0 | | |
| 10 | 73-80 | • • • • • | 0000 | 32 | 0 | | |

- 7 Concurrent I/O (Input/Output)
- 7.6 EtherNet/IP Status Warning
- Accessing the EtherNet IP/Status Warning From the Current Job Screen
 - 1. Go to {MENU} \rightarrow {Current Job}.
 - 2. Press {Digital I/O} in the lower left corner of the screen.
 - The I/O view will appear in the lower half of the screen.
 - 3. Press {Inputs}.
 - 4. Press {Settings}.
 - {Input Output Settings} panel will appear.
 - 5. Under {Input Types to Display} check {EtherNet/IP Status}.
 - 6. Click {X} in upper right of {Input Outputs Settings} panel.
 - {Input Output Settings} panel will close.
 - The {EtherNet/IP Status} input group will be in the left panel.

EtherNnet/IP Status Warning Help

Pressing the help icon will display a help screen with info on what bits 4-7 represent to help troubleshoot.

Fig. 7-22: EtherNet/IP Status Warning Help

| Signal bit 0 to 3 Description Vendor-reserved (not available) bit 4 Indicates error in EtherNet/IP adapter (e.g. PLC) communication Normal status: OFF | |
|---|-------|
| bit 4 Indicates error in EtherNet/IP adapter (e.g. PLC) communicatio Normal status: OFF | |
| Normal status: OFF | |
| | n |
| Communication error: ON | |
| bit 5 Indicates presence of a non-connected EtherNet/IP device (sca Connecting to all devices normally: OFF | nner) |
| Non-connected device(s) exist: ON | |
| bit 6 Indicates the status of EtherNet/IP communication Normal status: OFF | |
| Communication error: ON | |
| bit 7 Indicates the operating status of the EtherNet/IP CPU Board | |
| Normal status: OFF Communication error: ON | |


- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

7.7 Block I/O

The Block I/O feature allows the user to quickly configure I/O sequences that can be used to communicate with a tool attached to a Robot or external devices (e.g. a machine tool or conveyor). This feature currently supports the basic INFORM commands (DigitalOut, Group DigitalOut, Timer) required to communicate with a device and provides a pair of states for each setting to perform two related tasks (e.g. OFF and ON). Block I/O settings can then be accessed from the Robot Jog panel via the {Block I/O} to either physically perform an action or to add the stored commands to the current Job. This enables quick programming for complicated external devices that require several commands to execute.

For example, a basic parallel gripper typically has two states: Open and Close. To close the gripper, Output #1 must be turned OFF, and Output #2 must be turned ON. A Timer can be added before and/or after the commands if needed to ensure a good pick. Thus the "OFF" (close) state could be configured as the following figure.

Fig. 7-23: Close State of a Gripper




Similarly, opening the gripper might have the inverse logic (turn ON Output #1 and OFF Output #2)




The interface currently only supports two states (ON and OFF).

Fig. 7-24: Open State of a Gripper

7-30





- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

Block I/O Screen

To create a new Block I/O Configuration:



1. Go to {MENU} \rightarrow {Program/Operate} \rightarrow {Block I/O}.

- Block I/O screen will appear.

Fig. 7-25: Block I/O Setting

| Block I/O: Parallel Gripper | | |
|-------------------------------------|------------------------|------------------|
| Name Parallel Gripper | Select State to Edit: | OFF ON () |
| OFF State Commands: | d∮ Test State ON State | e Commands: |
| Timer T=0.50 | Time | r T=0.50 |
| DigitalOut OT#(1) O | FF 🗍 Digit | talOut OT#(1) ON |
| Timer T=0.50 | Time | r T=0.50 |
| \ominus DigitalOut \ominus Grou | p DigitalOut (於 Timer | |

- 2. Select a state to edit, {OFF} or {ON}
 - The selected state will be editable. The other state will appear disabled but is still visible for the user to compare the contents of both states. The list of commands can be edited in the same manner as an INFORM program, described in *chapter 7.3 "I/O Instructions*".
- 3. Press the {Test State} to execute the commands in the active state.
 - A confirmation pop-up window will appear.

- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

NOTE

- 4. Press {PROCEED} after confirming the contents of the pop-up window.
 - INFORM commands associated with the active Block I/O state will be executed.
 - During testing of a Block I/O state, its execution can be canceled.
 - This may be necessary if the Block I/O commands contain Timer(s) that are set to long durations.
 - While Block I/O is executing, other pendant functions are not accessible
 - On the Block I/O screen, the user can also view:
 - a list of all Block I/O settings
 - view & compare details for selected Block I/O states
 - create a new Block I/O setting
 - delete an existing Block I/O setting

7 Concurrent I/O (Input/Output) Block I/O

7.7

7.7.1 Edit a Block I/O Setting

The Block I/O screen provides an interface through which output and timer commands can be added to the active state using buttons in the tab at the bottom of fig. 7-25 "Block I/O Setting".

- 1. Press {Timer} to insert a Timer command.
- 2. Press {DigitalOut} to insert a DigitalOut command (output bit).
- 3. Press (Group DigitalOut) to add a DigitalOut command (output byte).
- 4. Enter the desired output number when an output command is added using the numeric keyboard (fig. 7-26 "Editing a Block I/O State").
- 5. For DigitalOut, select the action for the output using the dropdown.
- 6. For Group DigitalOut, enter the value of the resulting byte:

- Acceptable input range is 0 - 255.

Fig. 7-26: Editing a Block I/O State

| Name Parall | el Gripper | | Sele | ct State to | Edit: OFF ON |
|----------------|------------|---|------|-------------|----------------------|
| | | | | | ON State Commands: |
| | T= | | | CANCEL | Timer T=0.75 |
| | 1 | 2 | 3 | × | DigitalOut OT#(4) ON |
| | 4 | 5 | 6 | - | Timer T=0.50 |
| | 7 | 8 | 9 | Enter | |
| | (|) | • | (Save) | |

- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

7.7.2 Using Block I/O for Tool Operation

A Block I/O setting can be linked with the active tool to easily execute commands from the Robot Jog panel using the {Block I/O: Tool #}. If the link has not been established, a yellow warning symbol will appear on the button (*fig. 7-27 "Block I/O Not Linked with Tool on Robot Jog Panel"*). When pressed, a pop-up will appear that guides the user to the Tool Settings screen to establish the link (*fig. 7-28 "Block I/O Not Assigned on Tool Settings Screen"*).






Fig. 7-28: Block I/O Not Assigned on Tool Settings Screen

| ← Tools | | | Display only named | Search by name | ٩ |
|---------------------------|------------------|------------|--------------------|----------------|------------|
| Tool No. 🔺 | Tool Name | Weight | Block I/O Name | | |
| 0 | Vacuum | 2.000 | | | |
| 1 | Parallel Gripper | 3.000 | | | |
| Tool #1: Par | allel Gripper | | | | |
| Name | | | | | <i>(i)</i> |
| Parallel Grip | per | | | | |
| Block I/O No Block I/O |) Assigned | . ① | Weight | 3.000 kg | |

Fig. 7-29: Block I/O: Tool # Button Successfully Linked with Tool

7-34

| loint Ĵ ≥ , | ~ | Tool #1: Parallel Gripper 🛛 🖌 |
|--------------------|----------|---|
| | | BLOCK I/O: TOOL #1 |
| d | LOW | GO TO POINT Motion Command Not Selected |

- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

Pressing the configured {Block I/O: Tool #} (*fig. 7-29 "Block I/O: Tool # Button Successfully Linked with Tool"*) will open the Toggle Block I/O panel (*fig. 7-30 "Toggle Block I/O Panel"*) where the following actions can be performed:


- {Tool $\# \rightarrow$ OFF/ON} takes the user to the Block I/O screen to view the contents of the setting that is linked to the active tool
- {TOGGLE OFF/ON} executes the commands for the Active Tool's respective OFF/ON state
- {ADD TO JOB} adds the commands of a desired Block I/O state to the current job at the position of the highlighted line above
- {Add Comments} adds comments to the start and end of an inserted Block I/O state when added to a job (*fig. 7-31 "Add to Job with Comments"*). This option is checked by default.

Fig. 7-30: Toggle Block I/O Panel



- 7 Concurrent I/O (Input/Output)
- 7.7 Block I/O

Fig. 7-31: Add to Job with Comments



Block I/O Example For Programming a Job:

- 1. Move the manipulator above the desired workpiece with the gripper ready for a pick.
- 2. Toggle the tool ON using Toggle Block I/O panel.
 - The workpiece will be picked.
- 3. Press {ADD TO JOB}.
 - The commands are added to pick the workpiece to the current job.

7.8 I/O Allocation and EtherNet/IP Configuration

7.8 I/O Allocation and EtherNet/IP Configuration

The I/O Configuration screens can be used to perform the following actions:

Changing I/O Settings and Allocations can affect the operation of peripheral devices. Make sure hardware is in safe state (e.g. no payloads in Grippers) before modifying configuration.

- View List of I/O Devices

7-37

- View I/O Allocation Data (i.e. what Input/Output Groups are used vs. available)
- Add/Delete/Modify EtherNet/IP Adapters and Scanners

To access this screen, select {Menu} \rightarrow {System Settings} \rightarrow {I/O Configuration}.



 All Input/Output #s and Group #s in this section and on these screens refer to the Universal Input/Output #s which also correspond to the numbers used in Inform commands. Thus, if a device is mapped to Starting Group # 20, then the first byte of the device's mapping can also be accessed by "DigitalOut OutputGroup#(20)".

 If Concurrent I/O program has been changed from the default, some I/O may be marked as unavailable. If using a non-standard CIOPRG.LST file, use Software Pendant for I/O Configuration.

7.8 I/O Allocation and EtherNet/IP Configuration

7.8.1 I/O Device List

The Device List is the default view when first navigating to the I/O Configuration Screen (or it can be selected by pressing the {List} tab at the top of the screen). This view is simply a list of the devices configured on the YRC Controller.

Selecting a device will display its details on the bottom panel as shown in *fig.* 7-32.

Fig. 7-32: I/O Device List

| | | SERVO | | Ę | N. | | | |
|---------------------|---------------------|------------|-------------|--------------------------|----|--|--|--|
| ← I/O Configuration | | | | | | | | |
| List Inp | out Table Output Ta | ble | | | | | | |
| Name | Туре | Input Size | Output Size | IP Address (Scanners) | | | | |
| ASF01(AI001 NPN) | Terminal Block | 2 bytes | 2 bytes | . | | | | |
| EtherNet/IP CPU | EtherNet/IP Status | 1 bytes | 1 bytes | 5 | | | | |
| EtherNet/IP CPU | EtherNet/IP Adapter | 16 bytes | 24 bytes | - | | | | |
| VIPA | EtherNet/IP Scanner | 8 bytes | 5 bytes | 10.7.3.21 | Ċ | | | |

| Name VIPA | | IP Address 10.7.3.21 | | | |
|----------------|-----------------|-------------------------|---------------------|---------------------|-----------------------------|
| | Instance Id | Size (bytes) | Starting Group # | I/O Range (bits) | External Range (Yaskawa) |
| Input: | 60 | 8 | 20 | 153-216 | #20230-#20307 |
| Output: | 50 | 5 | 28 | 217-256 | #30310-#30357 |
| Configuration: | 30 | 0 | | | |
| | RPI Target->Or | iginator (| Connection Type | | |
| | 20 | ms | Exclusive Owne | er 🗸 | |
| | RPI Originator- | >Target (| Connection Time | out | |
| | 20 | ms 4 | 4 tries | ~ | |

7.8 I/O Allocation and EtherNet/IP Configuration

If a device has been modified, a (!) icon will appear next to its name prompting the user to reboot the YRC Controller (*fig.* 7-33).

Fig. 7-33: I/O Device List with Modified Device

| List In | put Table Output Ta | ble | | | |
|------------------|---------------------|------------|-------------|--------------------------|---|
| Name | Туре | Input Size | Output Size | IP Address (Scanners) | |
| ASF01(AIO01 NPN) | Terminal Block | 2 bytes | 2 bytes | - | |
| EtherNet/IP CPU | EtherNet/IP Status | 1 bytes | 1 bytes | - | |
| EtherNet/IP CPU | EtherNet/IP Adapter | 16 bytes | 24 bytes | - | |
| UIPA | EtherNet/IP Scanner | 8 bytes | 5 bytes | 10.7.3.21 | Û |



7

Changing I/O Device Settings will require a YRC Controller reboot before becoming active.

7.8 I/O Allocation and EtherNet/IP Configuration

7.8.2 Input/Output Table

The Input/Output table provides a visual representation of the Inputs and Outputs allocated for the YRC Controller. This is divided into two tables because the Input and Output properties do not always match (e.g. a device could have 16 bytes of Inputs but only 8 bytes of Outputs, etc...). On the Table View, each device is grouped together and selecting any group within a device will highlight the entire device and display the details in the panel below.

For example, the device selected below begins on Group 20 and is 8 bytes in length. Thus, pressing anywhere in the range of Group 20-27 will highlight the entire range and display the details on the panel below.

| E ME | NU | | S L | Δ | Ĵ. | | SEI | RVO | | | | | | F | 2m |
|--------------|---------|-------|---------------|---------|----------------|------------------|----------------|--------------------|-----------|----------|-------------|---------|------------------|----------|--------|
| ÷ | I/0 C | onfig | uration | 1 | | (+) M | IEW AI | LLOCA | ΓΙΟΝ | | | | | | () |
| L | ist | | Input | Table | 0 | output ' | Table | | | | | | ✓ S | how Le | gend |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 |
| 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 |
| 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 |
| 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | 128 |
| 129 | 130 | 131 | 132 | 133 | 134 | 135 | 136 | 137 | 138 | 139 | 140 | 141 | 142 | 143 | 144 |
| 145 | 146 | 147 | 148 | 149 | 150 | 151 | 152 | # | Used | # | Avail | able | # (| Unavaila | ble |
| 161 | 162 | 163 | 164 | 165 | 166 | 167 | 168 | # - ref | ers to li | nput/Ou | tput Gro | oup Nur | nber | | |
| 177 | 178 | 179 | 180 | 181 | 182 | 183 | 184 | 185 | 180 | 187 | 188 | 189 | 190 | 191 | 192 |
| Settir | ngs - E | ther | Net/IP S | Scanne | er | | | | | | | | | | \sim |
| Name VIPA | 2 | | | | | ddress 7.3.21 | | | | | | | | | |
| | | | Instar | nce Id | Size | e (byte: | s) | Startir Group | ng # | | ange ts) | E | kternal (Yask | | е |
| | Inp | out: | 70 | | 8 | | 2 | 20 | | 153 | -216 | # | 20230- | #20307 | 7 |
| | Outp | out: | 50 | | 5 | | 2 | 8 | | 217 | -256 | # | 30310- | #30357 | 7 |
| Confi | igurati | ion: | 30 | | 0 | | | | | | SEL | ECT INF | PUTS | | |
| | | | RPI Tar 20 | get->0i | riginato ms | or | | nection usive (| | ~ | | | | | |
| | | | RPI Ori | ginator | ->Targe ms | et | Conr 4 trie | nection es | Timec | out ~ | | | | | |

7.8 I/O Allocation and EtherNet/IP Configuration

7.8.3 EtherNet/IP Adapter

Configuring the YRC Controller as an EtherNet/IP Adapter will allow the YRC Controller to communicate with a device that is configured as an EtherNet/IP Scanner. The most common use case for this is to communicate data with a PLC (e.g. Rockwell ControlLogix or CompactLogix).

7.8.3.1 Creating an Adapter

To configure the YRC Controller as an Adapter, press the {NEW ALLOCATION} button on the top of the screen. From the dropdown menu that appears, select "EtherNet/IP Adapter".

Fig. 7-34: Selecting EtherNet/IP Adapter

| | | SERVO | | F 2 |
|-----------|-------------|-----------------------------|-------------|--------------------------|
| ← I/O Con | figuration | EtherNet/IP Adapter $ \sim$ | | |
| List | Input Table | C EtherNet/IP Adapter | | |
| Name | Туре | EtherNet/IP Scanner | Output Size | IP Address (Scanners) |

- 7 Concurrent I/O (Input/Output)
- 7.8 I/O Allocation and EtherNet/IP Configuration

This will create a new entry in the device list for an EtherNet/IP Adapter. The detail panel will automatically start with the {Save}/{Cancel} buttons. Pressing {Cancel} will remove the new adapter. Note that the initial "Size" and "Starting Group #" are 1 and 0 respectively which is not a valid configuration. Valid data will need to be entered before saving.

Fig. 7-35: New EtherNet/IP Adapter

| Adapter Settings | 5 | | | | NCEL 🔗 SAVE |
|------------------|-------------|------------------|---------------------|---------------------|-----------------------------|
| | Instance Id | Size (bytes) | Starting Group # | I/O Range (bits) | External Range (Yaskawa) |
| Input: | 0 | 1 | 0 | _ | - |
| | | Invalid Group Nu | mber: 0 | | |
| Output: | 0 | 1 | 0 | _ | - |
| | | Invalid Group Nu | mber: 0 | | |
| Configuration: | 0 | 0 | | | |

- Only one "Adapter" can be configured on a YRC Controller. If the Adapter has already been configured, selecting "Adapter" again will display an error message.
- If an Adapter has been previously configured, the previous Instance and Size numbers will be auto-populated. Thus, Adapters can be deleted and then re-added without needing to manually re-enter the settings.
- 7.8.3.2 Configuring the Adapter

After the Adapter appears in the device list, the following information can be entered:

1. Enter the desired Instance Numbers for the Input, Output and Configuration sections.

7-42

 These are used-defined numbers that are paired between the YRC Controller and the PLC.



The Input/Output Instance Numbers should be opposite between the YRC Controller and PLC. For example, if the Input Instance is 50 and the Output Instance is 100 on the YRC Controller, then the Input Instance should be 100 and the Output instance should be 50 on the PLC. See *fig.* 7-37 for an example.

7

7.8 I/O Allocation and EtherNet/IP Configuration

- 2. Enter the desired size in bytes for the Input, Output and Configuration sections.
 - For a new Adapter, the Starting Group # will automatically be filled in after entering the size by finding the first Group # that can contain that size of an allocation. After saving a new Adapter, the Starting Group # can be entered manually here or the {Select Inputs} and {Select Outputs} buttons can be used to visually choose the allocation location (see Section 7.8.5).
- Fig. 7-36: Inputting Adapter Sizes

| Settings - EtherNet/IP Adapter | | | | | | | | | |
|--------------------------------|---------------|---------------|---------------------|---------------------|-----------------------------|--|--|--|--|
| Adapter Settings SAVE | | | | | | | | | |
| | Instance Id | Size (bytes) | Starting Group # | I/O Range (bits) | External Range (Yaskawa) | | | | |
| Input: | 0 | 8 | 4 | 25-88 | - | | | | |
| Output: | 0 | 8 | 4 | 25-88 | - | | | | |
| Configuration: | 0 | 0 | | | | | | | |
| | Controller IP | Address: 10.7 | .3.42 | | | | | | |



The Input, Output, and Configuration Sizes must match exactly between the YRC Controller and the PLC for correct communications.

- 3. Reboot the YRC Controller to verify configuration.
 - Note that a reboot does not have to be done immediately, but the settings will not take effect until after a reboot.
 - An example of matched settings between a YRC Controller and a Rockwell PLC is shown in *fig.* 7-37. Note that the IP Address set on the Rockwell PLC is the IP Address of the YRC Controller which is also shown on the Adapter Settings Panel.

7.8 I/O Allocation and EtherNet/IP Configuration

Fig. 7-37: Example Rockwell PLC Settings

| Vendor: Parent: | Allen-Bradley Ethernet | | | | | |
|--------------------|-----------------------------|-----------|-----------------|----------------------------------|-------|---------|
| Name: | YRC_Robot | Records 1 | Connection Para | ameters Assembly Instance: | Size: | |
| Description: | | <u>^</u> | Input: | 100 | 24 | (8-bit) |
| | | - | Output: | 50 | 16 | (8-bit) |
| Comm Format | :: Data - SINT lost Name | | Configuration: | 150 | 0 | (8-bit) |
| IP Addre | ess: 10 . 7 | . 3 . 43 | Status Input: | | | |
| ⊚ Host Na | me: | | Status Output: | | | |

Settings - EtherNet/IP Adapter

 \checkmark

Adapter Settings

| | Instance # | Size (bytes) | Starting Group # | I/O Range | External Range |
|----------------|------------|--------------|---------------------|-----------|----------------|
| Input: | 50 | 16 | 4 | 25-152 | #20070-#20227 |
| Output: | 100 | 24 | 4 | 25-216 | #30070-#30307 |
| Configuration: | 150 | 0 | | | |

HW1485509

7.8 I/O Allocation and EtherNet/IP Configuration

7.8.4 EtherNet/IP Scanner

Adding an EtherNet/IP Scanner to the YRC Controller allows the YRC Controller to communicate with devices such as Network I/O, Grippers, etc... Up to 32 Scanners can be added to the YRC Controller.

Before adding or configuring a Scanner, the following information is needed:

- IP Address of device (should be configured from the device, not Smart Pendant)
- Input/Output/Configuration Instance Numbers. These numbers will be provided by the device manufacturer.
- Input/Output/Configuration Sizes (in bytes). These numbers will be provided by the device manufacturer.

Before configuring the device, it is a good idea to "ping" both the YRC Controller and the device from the PC on the same network to ensure the network is configured properly.

7.8.4.1 Creating a Scanner

To configure a new Scanner, press the {NEW ALLOCATION} button on the top of the screen. From the dropdown menu that appears, select "EtherNet/IP Scanner".

Fig. 7-38: Selecting EtherNet/IP Scanner

| | | SERVO | | F 🕿 |
|-----------|-------------|----------------------------|-------------|--------------------------|
| ← I/0 Cor | nfiguration | EtherNet/IP Adapter \sim | | |
| List | Input Table | EtherNet/IP Adapter | | |
| Name | Туре | EtherNet/IP Scanner | Output Size | IP Address (Scanners) |

This will create a new entry in the device list for an EtherNet/IP Scanner with default name "NewScanner". The detail panel will automatically start with the {Save}/{Cancel} buttons. Pressing {Cancel} will delete the new Scanner.

Note the initial "Size" and "Starting Group #" are 1 and 0 respectively which is not a valid configuration. Valid data will need to be entered before saving.

7 Concurrent I/O (Input/Output)

7.8 I/O Allocation and EtherNet/IP Configuration

Fig. 7-39: New Scanner Settings

| Name NewScanner | | IP Address | | | ICEL 🔗 SAVI |
|--------------------|-----------------|---------------------------------------|---------------------|---------------------|-----------------------------|
| | Instance Id | Size (bytes) | Starting Group # | I/O Range (bits) | External Range (Yaskawa) |
| Input: | 0 | 1 | 0 | - | - |
| | | Invalid Group Nu | imber: 0 | | |
| Output: | 0 | 1 | 0 | - | - |
| | | Invalid Group Nu | imber: 0 | | |
| Configuration: | 0 | 0 | | | |
| | RPI Target->Or | ininator (| Connection Type | 1 - | |
| | 20 | | Exclusive Own | | |
| | RPI Originator- | ->Target (| Connection Time | eout | |
| | 20 | 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 4 tries | ~ | |

7.8.4.2 Configuring a Scanner

After the Scanner appears in the device list, the following information can be entered:

- 1. Enter a user-defined name for the Scanner.
- 2. Enter the IP Address of the Scanner.
- 3. Enter the Instance Numbers for the Input, Output and Configuration sections.
 - These are manufacturer-defined numbers that are paired between the YRC Controller and the device.
- 4. Enter the size in bytes for the Input, Output and Configuration sections.
 - These sizes are defined and provided by the device manufacturer. As the Input/Output sizes are entered, the Starting Group # will automatically be filled in by finding the first Group # that can contain that size of an allocation. After saving a new Scanner, the Starting Group # can be entered manually here or the {Select Inputs} and {Select Outputs} buttons can be used to visually choose the allocation location (see *chapter 7.8.5 "Modifying Allocations using Input/Output Table"*).

Concurrent I/O (Input/Output)

7

7.8 I/O Allocation and EtherNet/IP Configuration

| Settings - Ether | Net/IP Scanne | er | | | ` |
|------------------------|----------------------|-------------------------|-----------------------------------|---------------------|-----------------------------|
| Name Gripper | | IP Address 10.7.3.30 | | 😣 CA | NCEL SAVE |
| | Instance Id | Size (bytes) | Starting Group # | I/O Range (bits) | External Range (Yaskawa) |
| Input: | 20 | 12 | 20 | 153-248 | - |
| Output: | 25 | 12 | 28 | 217-312 | - |
| Configuration: | 30 | 0 | | | |
| | RPI Target->Or 20 | 0 | Connection Type Exclusive Owne | | |
| | RPI Originator | | Connection Time | | |
| | 20 | ms 4 | 4 tries | ~ | |



The Input, Output, and Configuration Sizes must match exactly between the YRC Controller and the PLC for correct communications.

- 5. Enter the RPI and Connection information at the bottom of the screen.
 - These values should not be changed from their default values unless the instructions from the manufacturer say to do so.
- 6. Reboot the YRC Controller to verify configuration.
 - Note that a reboot does not have to be done immediately, but the settings will not take effect until after a reboot.

- 7 Concurrent I/O (Input/Output)
- 7.8 I/O Allocation and EtherNet/IP Configuration

7.8.5 Modifying Allocations using Input/Output Table

After a device has been added, its allocation (i.e. "Starting Group #") can be modified from the Input/Output Table by the following steps:

1. From the Input/Output table, press the {Select Inputs} or {Select Outputs} button.



 This will enter a special "Selection Mode", and the bottom detail panel will be disabled.

Fig. 7-41: Input Table Selection Mode

| | ME | NU | Solution | 1 | Δ | ĴŁ, | | SE | RVO | | | | | | Ģ | S. |
|---|--------------|---------|----------|---------------|---------|---------------|------------------|------------|---------|-----------|--------|----------|---------|--------|----------|------|
| 1 | (| I/0 C | onfigu | ration | | | • | IEW AI | LOCA | TION | | | | | | () |
| | L | ist | | Input | Table | 0 | utput | Table | | | | | | SI | now Le | gend |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 |
| | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 |
| | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 |
| | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | 128 |
| | 129 | 130 | 131 | 132 | 133 | 134 | 135 | 136 | 137 | 138 | 139 | 140 | 141 | 142 | 143 | 144 |
| | 145 | 146 | 147 | 148 | 149 | 150 | 151 | 152 | # | Used | # | Avail | able | # L | Jnavaila | ble |
| | 161 | 162 | 163 | 164 | 165 | 166 | 167 | 168 | # - ref | ers to In | put/Ou | tput Gro | oup Nun | nber | | |
| _ | 177 | 178 | 179 | 180 | 181 | 182 | 183 | 184 | 185 | 180 | 187 | 168 | 189 | 190 | 191 | 192 |
| ŝ | Setti | ngs - E | therN | et/IP S | Scanne | er | | | | | | | | | | ~ |
| | lame /IPA | | | | | | ddress 7.3.22 | | | | | | | | | |
| - | | | | | _ | | | . 3 | Startir | | 1/0 R | ange | Ex | ternal | Rang | a. |
| | | | - | Instar | ice Id | Size | (byte | s) | Group | # | (bi | | | (Yaska | awa) | |
| | | Inj | our e | Selec | tion | Mode | 9 | | | | | | > | < 04 | #20307 | |
| | | Outj | | | | desir pres | | | ation | on th | ie sci | reen | | 0-4 | #30357 | 7 |
| | Conf | igurati | | | und | pres | 00/11 | L . | | | | | | | | |
| | John | gurat | | | | | | | | | | | | | | |
| | | | | | | | | | × | CANCE | | \sim | SAVE | | | |
| | | | | RPI <u>On</u> | ginator | ->Targo | et | Conn | ection | Timeou | ıt | | | | | |
| | | | 1 | 20 | | ms | | 4 trie | es | | ~ | | | | | |
| | | | | | | | | | | | | | | | | |

7-48

- 7 Concurrent I/O (Input/Output)
- 7.8 I/O Allocation and EtherNet/IP Configuration
- 2. Press the desired Group # to move the allocation. Only Group #'s where the allocation will "fit" can be selected.
 - The allocation will show in the new allocation with a light blue highlight. For example, Group #52 is selected in the example below.

Fig. 7-42: Select New Input Group

| Ξ | | INU | S | Ŀ | Δ | ĴŁ, | | SEF | RVO | | | | | | P | 2 |
|---|-----|-------|----------|--------------------|-------|-----|------------------|--------|---------|-----------|-----|-------|------|------|----------|------------|
| | ÷ | I/0 C | onfigu | ration | | | (+) | IEW AL | LOCA | ΓΙΟΝ | | | | | | <i>(i)</i> |
| | L | ist | | Input ⁻ | Table | 0 | utput | Table | | | | | | ✓ SI | now Le | gend |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| | 65 | 66 | 67 | Ì | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 |
| | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 |
| | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 |
| | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | 128 |
| | 129 | 130 | 131 | 132 | 133 | 134 | 135 | 136 | 137 | 138 | 139 | 140 | 141 | 142 | 143 | 144 |
| | 145 | 146 | 147 | 148 | 149 | 150 | 151 | 152 | # | Used | # | Avail | abla | # (| Jnavaila | blo |
| | 161 | 162 | 163 | 164 | 165 | 166 | 167 | 168 | | | | | | | mavalla | bild |
| | 177 | 178 | 179 | 180 | 181 | 182 | 183 | 184 | # - ref | ers to In | 187 | 188 | 189 | 190 | 191 | 192 |

- 3. To finalize the new allocation, press the {SAVE} button on the Selection Mode Popup
 - The allocation is now updated.
- Fig. 7-43: Selection Mode Popup



7

Concurrent I/O (Input/Output) I/O Allocation and EtherNet/IP Configuration 7.8

Fig. 7-44: New Allocation Saved

| | INU | <pre></pre> | | Δ | ĴŁ, | | SEI | RVO | | | | | | F | 2 |
|------------------------------|---------|-------------|---------------|---------|----------------|------------------|----------------|--------------------|-----------|--------------|-------------|---------|-----------------|--------------|------|
| ÷ | I/O C | onfig | uration | | | (+) N | IEW AI | LOCA | ΓΙΟΝ | | | | | | (i |
| L | ist | _ | Input | Table | 0 | utput 1 | Table | | | | | | ✓ S | how Le | gend |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 |
| 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 |
| 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 |
| 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | 128 |
| 129 | 130 | 131 | 132 | 133 | 134 | 135 | 136 | 137 | 138 | 139 | 140 | 141 | 142 | 143 | 144 |
| 145 | 146 | 147 | 148 | 149 | 150 | 151 | 152 | # | Used | # | Avail | able | # (| Unavaila | ble |
| 161 | 162 | 163 | 164 | 165 | 166 | 167 | 168 | # - ref | ers to In | put/Out | tput Gro | oup Nun | nber | | |
| 177 | 178 | 179 | 180 | 181 | 182 | 183 | 184 | 185 | 180 | 187 | 188 | 189 | 190 | 191 | 192 |
| Settin Name VIPA | | ther! | let/IP S | Scanne | IP Ad | ddress 7.3.22 | | | | | | | | | ~ |
| | | | Instar | ice Id | Size | (bytes | | Startir Group | | I/O R (bi | ange ts) | Ex | ternal (Yask | Rang awa) | e |
| | Inp | out: | 60 | | 8 | | 5 | 52 | | 409 | -472 | #2 | 20550- | #20627 | 7 |
| | Outp | out: | 50 | | 5 | | 2 | 8 | | 217 | -256 | #: | 30310- | #30357 | 7 |
| Conf | igurati | ion: | 30 | | 0 | | | | | | SELI | ECT INP | UTS | | |
| | | | RPI Tar 20 | get->0i | riginato ms | or | | nection usive (| | ~ | | | | | |
| RPI Originator->Target 20 ms | | | | | | et | Conr 4 trie | nection | Timeo | ut | | | | | |

8 System and YRC Controller Setting

General System Settings allows setting language, changing passcodes for security levels, as well as getting important information on software versions and ID numbers. To access the General screen, go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{General\}.$

Fig. 8-1: General Settings

| ← General Settings | |
|---|--|
| Organization Your organization name | Date & Time 2019-07-19 11:10:53 AM |
| Language English ~ | |
| Enable Membrane Key Lege | end |
| Security Level Settings | |
| Access Edit ~ | SET PASSCODE |
| Startup Level Management | |
| Remote Screen Sharing (| VNC) Screen |
| Remote Screen Sharing (Password 4567 | VNC) Screen Auto off idle time 10 min Auto Off |
| Password | Auto off idle time Auto Off |
| Password 4567 | Auto off idle time Auto Off 10 min Brightness |
| Password 4567 Off O On | Auto off idle time Auto Off 10 min Brightness |
| Password 4567 Off On Pendant Software Version 1.4.4 | Auto off idle time Auto Off 10 min Brightness 100 % ID Numbers Pendant 54:ee:75:a7:49:20 USB ID 60A44C413C8CF130A985013F |
| Password 4567 Off O On Pendant Software Version 1.4.4 Release 2019-07-15 | Auto off idle time 10 min Brightness 100 % ID Numbers Pendant 54:ee:75:a7:49:20 USB ID 60A44C413C8CF130A985013F |

8-1

YRC Controller Settings allows modification of YRC Controller settings and parameters, including network interfaces. YRC Controller software version, features and Robot model information is also shown. To access the YRC Controller Settings screen, go to

 $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{Controller\}.$

Fig. 8-2: YRC Controller Settings

| System Features Controller Software YAS2.81.00A(JP/E | (i) | Robot Model 1-06VXHC10-A0*(HC10) | D RESTART CONTROLLER |
|--|-----------------------|--|------------------------------|
| Functional Safety Ur Installed | it (FSU) | Power & Force Limiting (PFI Available (may be inactiv | |
| Network | | | |
| CN106 (LAN2) | | | |
| IP Address | Subnet Mask | | Source |
| 10.7.3.98 | 255.255.25 | 00:01:02:03:04 | 4:05 Manual ~ |
| | _ | | |
| Settings ① | layback Cycle Ope | ration Mode | Continuous ~ |
| Settings (j) Power-on First P | | ration Mode ach) Operation Mode | Continuous ~ Continuous ~ |
| Settings (i) Power-on First P First Playback Cy | rcle in Manual (Tea | | |
| First Playback Cy | vcle in Manual (Tea | ach) Operation Mode | Continuous ~ |

- 8 System and YRC Controller Setting
- 8.1 General

8.1 General

Under General, the following items are shown:

① Organization

2 Date & Time

③ Language

| 1 | Organization Your organization name | 2 | Date & Time 2018-08-29 10:10:28 AM |
|---|--|---|---------------------------------------|
| 3 | Language English | ~ | |
| | | | |

8.1.1 Organization

User can input the organization name here. Constraints on name are:

- 0 to 32 alphanumeric characters can be used.
- Both upper and lower case letters can be used.
- All symbols and space can be used.

8.1.2 Date & Time

The current date and time as set on the YRC Controller is shown here. Software Pendant Application is required to change the date and time in the YRC Controller. Date and Time can only be changed under Maintenance Mode.

8.1.3 Language

The current selected language appears here. User can change the language used on the Smart Pendant. Two languages can be displayed alternately. Select the language from the pull-down list to change the language.

The available languages are:

- English
- Japanese

The Smart Pendant requires a restart when changing the language.

- 8 System and YRC Controller Setting
- 8.2 Security Level Settings

8.2 Security Level Settings

Under Security Level Settings, the following items can be set:

1 Access

② Startup Level

| | Security Level S | ettings | | | |
|---|------------------|---------|--------------|------------|--|
| 1 | Access Edit | ~ | SET PASSCODE | \bigcirc | |
| 2 | Startup Level | ~ | | | |
| | Edit | ~ | | | |

8.2.1 Access

The passcode for Security Access can be changed.

- 1. Select the security level from the drop-down list to change the passcode.
- 2. Press the {SET PASSCODE}.

For more information on Security Access and its procedures, go to *chapter 1.17.5 "Security Level Settings"*.

8.2.2 Startup Level

The Security Level at startup or restart can be set to Operation, Edit or Management level. Startup Level can be modified by operating in Management Level or higher.

- 8 System and YRC Controller Setting
- 8.3 Pendant Software

8.3 Pendant Software

The information on the Smart Pendant is shown under Pendant Software. The following items are displayed:

- 1 Version
- 2 Release
- ③ Pendant ID
- ④ USB ID
- ⑤ Update Pendant Software



8.3.1 Version

The software version of the Smart Pendant that is used appears. When the pendant software is updated by following the procedure in the *chapter* 8.3.5 "Update Pendant Software", the version number will be changed to the updated version number.

8.3.2 Release

The released date of the installed pendant software version is shown.

8.3.3 Pendant ID

Each Smart Pendant has a unique ID number, useful for identifying it to support personnel and in log files.

8.3.4 USB ID

The serial number of any USB storage device currently inserted is shown here. This can be used to tie license files to specific USB storage devices.

8.3.5 Update Pendant Software

The Smart Pendant's software can be updated to a newer version by connecting the official YASKAWA update USB storage device.

- 1. Connect the USB storage device to the Smart Pendant.
 - USB port is located on the back-side of the pendant (bottom-right corner).
- 2. Press the {UPDATE PENDANT SOFTWARE} on the screen.
 - Pendant will start updating.
 - Do not disconnect the USB storage device until the pendant restarts.
 - Pendant will automatically restart.

For more information on an USB storage device, refer to *chapter 13 "External Memory Device"*.



- 8 System and YRC Controller Setting
- 8.4 Bundled Resources

8.4 Bundled Resources

User can access and download related resources, which are:

- Documentation (Instruction manuals)
- Software Pendant Application
- Open Source Licenses

| Bundled Res | sources | | |
|-------------|---------------|-------------------------------|----------|
| EXPORT | Documentation | Software Pendant" Application | Licenses |
| | | | |

- 1. Check the checkbox of the desired resources to export to USB storage device.
- 2. Press {EXPORT...}.
 - Resources can be exported in Edit Level or higher security level.
 - Resources can be exported if an USB storage device with sufficient free space is inserted.

| Exporting |
|--|
| |
| Pendant/Documentation/HW1485509_1.pdf |
| Please wait while files are copied to the USB storage device. |
| (do not remove the USB storage device until the operation is complete) |
| X CANCEL |
| |


- 3. Remove the USB storage device after completing the export.
- 4. Connect the USB storage device to Windows PC.
 - Exported files can be read.

- 8 System and YRC Controller Setting
- 8.4 Bundled Resources

8.4.1 Documentation

Important documents can be obtained from the Smart Pendant.

- 1. Open the "Documentation" folder under USB storage folder.
- 2. Click the desired manuals to read.



8.4.2 Software Pendant Application

Software Pendant application software is an application that provides supplementary functions for using the Smart Pendant with the YRC Controller. The Software Pendant application should be installed on a Windows PC. Refer to *chapter 12 "Software Pendant"* for how to install the application on a computer.

8.4.3 Licenses

The list of the Open Source licenses for the software used are available here. For more information on the licenses, refer to the license documents that can be downloaded by exporting.

8-7

- 8 System and YRC Controller Setting
- 8.5 System Features

8.5 System Features

Information about the YRC Controller is shown in the System Features section on the YRC Controller Settings Screen. The following items are displayed:

- ① YRC Controller Software
- ② Robot Model
- ③ Functional Safety Unit
- ④ Power & Force Limiting



8.5.1 YRC Controller Software

The version of the YRC Controller software that is used appears.

8.5.2 Robot Model

The model number of the manipulator that is set on the YRC Controller appears. The type number is shown at first, and model number is shown afterwards in the bracket.

8.5.3 Functional Safety Unit (FSU)

The status of whether Functional Safety Unit (FSU) is enabled or disabled is shown. For more information on FSU, refer to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576)" or "YRC1000micro OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1484544)".

8.5.4 Power & Force Limiting (PFL)

The availability of the PFL function is shown. For more information on PFL function, refer to "YRC1000/YRC1000micro Collaborative Operation Instructions (HW1484764)".

8.5.5 Restart YRC Controller

If YRC Controller software supports it, the {Restart} button will be available.. It allows restarting the YRC Controller computer CPU, which also briefly interrupts power to the Smart Pendant, hence also restarting it.

8-8

8 System and YRC Controller Setting

8.5 System Features

8.5.6 Output Full Selection Layout

Near the top of the output Detailed View. It has information for the selected I/O groups as a block. Information about the YRC Controller is shown in the System Features section on the Robot Controller Settings Screen.

{Full Selection} has:

- ① Selected output group numbers.
- ② Selected output numbers.
- ③ Decimal or hexadecimal value for the entire block as one number.

④ Circles that show the status of each bit in the block, and the bit number above each circle. Green is on, white is off. Zero is the least significant bit.

- 8 System and YRC Controller Setting
- 8.5 System Features

Fig. 8-3: Output Detailed View Full Selection

| ME | NU R | L 1 | SER | /0 📮 🕾 |
|-------|---------|---------------------|-------|--|
| ÷ | 1/0 | | | |
| Inpu | uts | Outputs | | 🔤 Go To: 1 |
| Group | Outputs | Status (7 6 5 4 | Bits) | Detail View - Outputs |
| 1 | 1-8 | 80000 | 00001 | Number Selected |
| 2 | 9-16 | 0000 | 0000 | One Byte |
| 3 | 17-24 | 0000 | 0000 | Full Selection |
| 4 | 25-32 | 0000 | 0000 | GROUPS: 1-1 Write Format OUTPUTS: 1-8 Hex Dec |
| 5 | 33-40 | 0000 | 0000 | |
| 6 | 41-48 | 0000 | 0000 | ③ VALUE (DEC): 4 |
| 7 | 49-56 | 0000 | 0000 | 7 6 5 4 3 2 1 0 ④ GROUP: 1 0 0 0 0 0 0 0 |
| В | 57-64 | 0000 | 0000 | |
| 9 | 65-72 | 0000 | 0000 | |
| 10 | 73-80 | 0000 | 0000 | |
| 11 | 81-88 | 0000 | 0.00 | |
| 12 | 89-96 | 0000 | 0000 | |
| 13 | 97-104 | 0000 | 0000 | |
| 14 | 105-112 | 0000 | 0000 | |
| 15 | 113-120 | 0000 | 0000 | |
| 16 | 121-128 | 0000 | 0 | |
| 17 | 129-136 | 0000 | 0000 | |
| 18 | 137-144 | 0000 | 0000 | |
| 19 | 145-152 | 0000 | 0000 | |
| 20 | 153-160 | 0000 | 0.00 | |
| 21 | 161-168 | 0000 | 0000 | |
| 22 | 169-176 | 0000 | 0000 | |

- 8 System and YRC Controller Setting
- 8.6 Network

8.6 Network

To access the Networking settings screen, go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{Controller\}$

Fig. 8-4: Network Setting Screen

| Network | | | | |
|--------------------|---------------|-------------------|--------|---|
| CN106 (LAN2) | | | | |
| IP Address | Subnet Mask | MAC Address | Source | |
| 10.7.3.98 | 255.255.255.0 | 00:01:02:03:04:05 | Manual | ~ |
| | | _ | | |
| Gateway IP Address | | | | |
| 10.7.3.1 | | | | |

8.6.1 YRC1000 Network

The YRC1000 has three network ports:

Table 8-1: Network Port for the YRC1000

8-11

| Port | Channel | Description |
|------|---------|---|
| LAN1 | CN105 | This port is used for pendant connection and is not available for application use. |
| LAN2 | CN106 | This port is for customer application use. The IP settings of this port can be configured as per user requirements. |
| LAN3 | CN107 | This port is for customer application use. The IP settings of this port can be configured as per user requirements. Software Pendant is required to view or configure the IP settings for CN107 (LAN3). |

The network ports are located in the CPU Unit of the YRC1000. Refer to *chapter 12.3.1 "Wiring*" for the location of the network ports in YRC1000.

8.6.2 YRC1000micro Network

The YRC1000micro has two network ports: CN105 (LAN1) and CN106 (LAN2). The functions supported by these ports are similar to YRC1000 as described in *chapter 8.6.1 "YRC1000 Network*".

- 8 System and YRC Controller Setting
- 8.6 Network

8.6.3 MAC Address

- 1. Go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{Controller\}.$
- 2. {MAC Address} is under {Network}.

8.6.4 Setting IP Address

Requires Management Security

The IP Address can be set manually (static) or automatically acquired. To have the IP address acquired automatically via the standard DHCP protocol, select {Auto (DHCP)} as the Source. To set the IP address and subnet mask manually, to a fixed static value, use the following.

- 1. Go to $\{MENU\} \rightarrow \{System Settings\} \rightarrow \{Controller\}.$
- 2. {IP Address} is under {Network}.
- 3. Select the {Source} as {Manual}.
- 4. Press {IP Address}.
 - The keypad will appear.
- 5. Enter the IP Address and press {Enter}.
 - IP Address must be 4 numbers 0-255 separated by decimals. Ex. 10.6.3.42
 - A notice will appear stating that the YRC Controller will have to be restarted for the new IP Address to take effect.

IP Addresses reserved for special use should not be used for the YRC Controller.



- 0.0.0.0 (Current Network).
- 255.255.255.255 (Limited Broadcast).
- Any IP Address starting with 127 (Loopback Addresses).
- 6. Optionally set the {Subnet Mask} if the common default 255.255.255.0 is not appropriate.

- 8 System and YRC Controller Setting
- 8.7 Settings and Parameters

8.7 Settings and Parameters

Various YRC Controller parameter settings can be adjusted using these controls. The specific settings available may vary by region.

Fig. 8-5: Setting and Parameter Controls

| Power-on First Playback Cycle Operation Mode | Continuous ~ |
|--|--------------|
| irst Playback Cycle in Manual (Teach) Operation Mode | Continuous ~ |
| irst Playback Cycle in Automatic (Play) Operation Mode | Continuous ~ |
| External Start Permitted | Off On |
| | |
| ameters | |

- 8 System and YRC Controller Setting
- 8.8 Remote Screen Sharing

8.8 Remote Screen Sharing

The screen of the Smart Pendant can be shared via the network to a PC. This may be useful for allowing multiple people to simultaneously view the screen for demonstration or educational purposes, for example by displaying it on a large screen. The sharing uses the standard VNC (Virtual Network Computing) desktop sharing protocol, for which many viewer applications for many operating systems are available.

The Remote Screen Sharing settings are shown below:

Fig. 8-6: Remote Screen Sharing

| Remote Screen | Sharing (VNC) |
|----------------------|--|
| Password mysecret | |
| Off 🌒 On | Connect VNC Viewer to: 169.0.0.2:20023 (unencrypted) |

Remote connections to view the Smart Pendant screen will require a password before being able to view the screen, for security. You must create a password to use for that purpose. It is good practice not to use the same password as used for security access. To enter a screen share password, ensure the pendant is in the Management security access level.

To start sharing the Smart Pendant screen, tap the switch into the {On} position. The remote viewing application you choose to use will require the IP address and port number, as displayed. The IP address will match that of the YRC Controller Ethernet port, which must be connected to the same LAN as your PC viewer (LAN2 for YRC1000 Controller or LAN for the YRC1000micro Controller).

When a remote viewer application attempts to connect, a prompt will appear on the Smart Pendant to allow the remote viewer. This ensures that the screen cannot be remotely viewed without the knowledge of the Smart Pendant operator.

A popular viewer application for PC is the "VNC© Viewer for Google Chrome" by Real Networks. This allows use of the Google Chrome web browser to view the pendant screen, and is available from the Google Chrome Web store.

The Remote Screen Sharing is stopped when the Smart Pendant is restarted and is not automatically restarted on startup.

- 9 Utility
- 9.1 Limit Release

9 Utility

9.1 Limit Release


The manipulator's operating range is monitored by the system software in order to stop the manipulator moving before its speed and force limits are exceeded. If the manipulator moves to an unexpected location due to system or operation errors, the operator can temporarily release the limit, and then move the manipulator back to the desired zone.

The Smart Pendant allows enabling and disabling three types of limit:

- Soft Limits
- Self-Interference (only for certain Robot model)
- All Limits

Fig. 9-1: Limit Release

| ✓ Limit Rel | lease | × |
|-------------|------------------|---|
| | Soft Limits | |
| | Enable Disable | |
| | All Limits | |
| | Enable O Disable | |
| | | |
| | | |
| | | |
| | | |
| | | |



- 9 Utility
- 9.1 Limit Release

9.1.1 Soft Limits

The operating range of the manipulator is controlled by two soft limits:

- The maximum motion range for each axis
- The cubic operation area set parallel to the Robot coordinate system

The axis range can be reduced using the software pendant, and allowing the axis range to be limited by the soft limit. Cubic Zones can be set to prevent the manipulator from entering specific areas of the workspace.

To set the soft limit using the Software Pendant, refer to the INSTRUCTIONS of the YRC Controller.

9.1.2 Self-Interference

The manipulator that has self-interference function enabled (e.g. MOTOMAN-HC10) will have this feature. It is the function that controls prohibiting interfere between the manipulator and the attached tool.




Make sure to take safety measures when disabling selfinterference. Failure to observe this instruction may cause contact with the manipulator, which may result in equipment damage.

9.1.3 All Limits

All limits include the following limit settings:

Table 9-1: All Limit Settings

| Limit | Description |
|-------------------------|---|
| Mechanical Limit | Limit to check manipulator's range of motion |
| L-U Interference | Limit to check L- and U-axis interference area |
| Soft Limit on Each Axis | Soft limit to check manipulator's range of motion |
| Cubic Zone | Limit to check cubic zone set by user |



- 9 Utility
- 9.2 Brake Release

9.2 Brake Release

If the manipulator has the brake release function enabled, it is possible to release the brake of the manipulator.

If the manipulator moves to an unexpected place because of system or operation errors, and the manipulator cannot be moved to its normal operating range with Limit Release function, then brake release can be used to move the axis of the manipulator.

9.2.1 Brake Release for YRC1000

YRC1000 allows releasing the brake with only one axis at the time.

1. Select {Enable} on the Brake Release.

| 4 | Brake Release |
|---|--|
| | |
| | Brake Release |
| | Disable Disable |
| | Select Axis to Release Brakes On: |
| | S-Axis |
| | O L-Axis |
| | O U-Axis |
| | O R-Axis |
| | O B-Axis |
| | O T-Axis |
| | RELEASE BRAKES |
| | Warning: Releasing brakes may result in robot motion due to gravity |

- 2. Select axis to release the brake.
- 3. Press and hold {RELEASE BRAKES}.

9-3

- The selected axis' servos are off and can be manually moved.

| NOTE | The axes may also move due to gravitational forces. |
|-----------------|--|
| SUPPLE -MENT | The brake release function works in both MANUAL (TEACH) and AUTOMATIC (PLAY) modes and is available to all Security Access Levels. |

- 9 Utility
- 9.2 Brake Release

9.2.2 Brake Release for YRC1000micro

YRC1000micro allows releasing the brake with S-, L- U- axes as one group, and R-, B-, T-axes as another group. To release each brake group, select S-axis or R-axis, instead of each axis.


1. Select {Enable} on the Brake Release.

| ← Brake Release | e |
|-----------------|--|
| | |
| | Brake Release |
| | Disable Enable |
| | Select Axes to Release Brakes On: |
| | S-Axis |
| | C-Axis |
| | U-Axis |
| | O R-Axis |
| | O B-Axis |
| | O T-Axis |
| | RELEASE BRAKES |
| | Warning: Releasing brakes may result in robot motion due to gravity |

- 2. Select either S-, L-, U-axes group or R-, B-, T- axes group to release the brake.
- 3. Press and hold {RELEASE BRAKES}.

9-4

- The selected group axis' servos are off and can be manually moved.



- 9 Utility
- 9.2 Brake Release

9.2.3 Execute Brake Release

To execute a brake release:

- 1. Turn servos OFF.
 - This can be accomplished by pressing the {SERVO} or by pressing the Emergency Stop button.
 - In MANUAL (TEACH) mode, if servos are in Servo On Ready state (Orange), press Emergency Stop button or change mode to AUTOMATIC (PLAY) to cancel Servo On Ready state.
 - After Emergency Stop button is pressed, turn the Emergency Stop button to release the Emergency Stop state.
- 2. Enable the Brake Release function.
- 3. Select the axis.
- 4. Squeeze the Enable Switch during the release operation.
- 5. Press and hold the {RELEASE BRAKES}.



Depending on the axis and its posture, the axis may fall due to its own weight or it may abruptly move upward due to the attached balancer or weight, which may result in personal injury and/or equipment damage.

- 9 Utility
- 9.3 Backup and Restore

9.3 Backup and Restore

9.3.1 System Backup

System Backup screen allows the user to backup YRC Controller system file and pendant files on to a USB drive plugged in to the pendant. This function can be accessed from {Menu} \rightarrow {Utility} \rightarrow {Backup and Restore}.

Fig. 9-2: System Backup Screen

| Target Device: Pendant USE | B Drive | | |
|-------------------------------|--------------------|-----------|--|
| Status | | | |
| USB drive inserted | | | |
| USB Memory | | | |
| 40 MBytes required. 1000 MByt | es available. | | |
| Target Folder | | | |
| Target Folder Path | | | |
| SYS-BACKUP | | | |
| Backup Description | | | |
| Description | | | |
| Description Here | | | |
| | | | |
| | | | |
| BACKUP | SYSTEM DATA TO PEN | IDANT USB | |

System Backup saves the following files:

- YRC Controller System Backup file (CMOS.BIN)
 - CMOS.BIN is a binary file that includes all YRC Controller setting parameters and data files. This file can be used to restore the YRC Controller.
- Pendant files
 - Pendant configuration files.
 - Pendant log files.

Procedure for system backup is shown as follows.

- 1. Insert a USB drive into the pendant.
- 2. Make sure there is at least 40 MB free space on the USB drive.
- 3. If necessary, specify a target folder name. Backups will be created inside this folder.
- 4. If necessary, enter a description for the backup.
- 5. Press {Backup System Data to Pendant USB}.
 - A confirmation pop-up window will appear.

9-6

- 9 Utility
- 9.3 Backup and Restore
- 6. Press YES to continue. This will:
 - Create a backup folder inside the target folder.
 - Files will be copied into the backup folder.
 - A text file named BackupDescription.txt will be created. This file contains the date and time of the backup and the description.

Backup folder is named using "YYYYMMDD-NN" format. Example: 20180321-01 • YYYY: Year • MM: Month • DD: Day • NN: two-digit number starting with 1. If the same folder name already exists, this number will increment.

The backup operation can fail under the following conditions:

- USB drive is removed during backup.
- Power failure during backup.

When backup has failed, the following operations will occur:

- The description in BackupDescription.txt will be "System Backup Failed".
- The files with zero size will be removed from the target folder.

9.3.2 System Restore

Restore function requires the use of the Software Pendant application. For more information on the Software Pendant, refer to *chapter 12 "Software Pendant"*.

- 9 Utility
- 9.4 File Transfer

9.4 File Transfer

9.4.1 File Transfer Overview

File Transfer screen allows the user to copy Job files and YRC Controller data files from the YRC Controller to a USB drive. The user can also copy files saved in a USB drive to the YRC Controller. This function can be accessed from $\{MENU\} \rightarrow \{Utility\} \rightarrow \{File Transfer\}.$

File Transfer can be used to transfer the following files:

- Job (.JBI) Files
- YRC Controller data files
 - General data files such as tool data (TOOL.CND), user frame data (UFRAME.CND), and variable value (VAR.DAT)
 - Parameter files such as system definition parameter (SD.PRM) and batch parameter (ALL.PRM)
 - I/O data files such as CIO program (CIOPRG.LST) and I/O name data (IONAME.DAT)
 - System data files such as Home position calibration data (ABSO.DAT) and Alarm history data (ALMHIST.DAT)

To save the YRC Controller system backup data file (CMOS.BIN), use Backup and Restore function (refer to *chapter 9.3 "Backup and Restore"*).

9.4.2 Procedures for File Transfer from YRC Controller

- 1. Go to {MENU} \rightarrow {Utility} \rightarrow {File Transfer}.
 - File Transfer screen will appear.
- 2. Select {From Controller} tab if not selected.
- 3. Insert a USB drive into the pendant.
- 4. Change the target folder if necessary.
- 5. Select the file group from the following to show in the file list view ().
 - All (shows all files on the YRC Controller)
 - Job
 - General Data
 - Parameter
 - I/O Data
 - System Data
- 6. Check the checkbox to select the files to copy from the YRC Controller.
 - Checking the checkbox (2) allows to select/deselect all files.
- 7. Press {COPY FILES FROM CONTROLLER}.
 - A confirmation pop-up window will appear.
- 8. Press {YES}.

- 9 Utility
- 9.4 File Transfer

 - {Overwrite or Skip Files Confirmation} pop-up appears if the target folder has conflicting files. Otherwise, selected files are copied from the YRC Controller to the target folder.

Fig. 9-3: File Transfer from the YRC Controller Screen

| 4 | File Transfer | | | | |
|-------|-----------------|----------------------|---------------------------|--------------|--|
| | From C | ontroller | Т | o Controller | |
| Targ | et Device: Pend | dant USB Drive | | | |
| Statu | s | | USB Memory | | |
| USB | drive inserted | | 2514 MBytes available | | |
| Targ | et Folder | | | | |
| | | Target Folder Path | | | |
| c | HANGE FOLDER | USB: | | | |
| | | | Select File Group: | All | |
| | Name | Description | Grou | p | |
| | CIOPRG.LST | CIO program | 1 /O Data 1/0 C | Data | |
| ~ | IONAME.DAT | I/O name data | 1/0 0 | Data | |
| | PSEUDOIN.DAT | Pseudo input signals | s VO C | Data | |
| ~ | EXIONAME.DAT | External I/O name da | ata VOC | Data | |
| | IOMNAME.DAT | Register name data | I/O C | Data | |
| | YSFLOGIC.DAT | YSF logic file | 1/0 0 | Data | |
| | USRGRPIN.DAT | User Group Input | I/O C | Data | |
| | USRGRPOT.DAT | User Group Output | 1/0 0 | Data | |
| | | Sy | stem Data | | |
| | | | | | |

16 file(s) in the target folder

COPY FILES FROM CONTROLLER

- 9 Utility
- 9.4 File Transfer

9.4.2.1 Overwrite or Skip Files

The following shows options to select in {Overwrite or Skip Files} Confirmation pop-up:

Overwrite All

The copy process replaces existing files in the target folder.

• Skip Existing Files


The copy process skips existing files in the target folder.

- Let Me Decide for Each File The copy process will show a separate confirmation pop-up window for the user to decide what to do for each existing file.
- Cancel

Copy process will be canceled. The files that have already been copied will be left in the target folder.

Fig. 9-4: {Overwrite or Skip Files} Confirmation Pop-up

9-10




- 9 Utility
- 9.4 File Transfer

9.4.2.2 Overwrite or Skip Individual File

When {Let Me Decide for Each File} is selected in {Overwrite or Skip Files} Confirmation pop-up window, {Overwrite or Skip File} Confirmation pop-up window will appear before copying a file that already exists in the target folder.





- 9 Utility
- 9.4 File Transfer

9.4.3 Procedures for File Transfer to YRC Controller

- 1. Go to {Menu} \rightarrow {Utility} \rightarrow {File Transfer}.
 - File Transfer screen will appear.
- 2. Select {To Controller} tab if not selected.
- 3. Insert a USB drive into the pendant.
- 4. Change the source folder to where files are saved.
- 5. Select the file group from the following to show in the file list view ().
 - Job
 - General Data
 - Parameter
 - I/O Data
 - System Data
- 6. Select the files to copy to the YRC Controller by checking the check boxes.
 - Checking the checkbox (2) allows to select/deselect all files.
- 7. Press {Copy Files to Controller}.
 - A confirmation pop-up window will appear.
- 8. Press {YES}.
 - {Overwrite or Skip Files Confirmation} pop-up window appears if the YRC Controller has JOB files with the same names. Otherwise, selected files are copied from the source folder to the YRC Controller.



File Transfer forces an override of Safety related settings.

9-12

After transferred files, make sure Safety related settings work properly.




"Enable Condition" of transferred {Safety Functions} settings are changed to "Always OFF".



The YRC Controller must be restarted for Safety related settings to take effect.

- 9 Utility
- 9.4 File Transfer



| | ≡м | | 2 2 | SERVO | P 2 |
|----|--------------|----------------------|--------------------|------------------------|-----|
| | ÷ | File Transfer | | | () |
| | | From (| Controller | To Controller | 1 |
| | Sou | rce Device: Per | ndant USB Drive | | |
| | Statu USB | is drive inserted | | | |
| | Sou | rce Folder | | | |
| | CI | HANGE FOLDER | Source Folder Path | UP/HC10-2/2018-05-31 | |
| | | | | Select File Group: Job | ~ |
| 2 | | Name | Description | Group | |
| | | | | doL | |
| | | 5TIMERS.JBI | | Job | |
| | | ABTEST.JBI | | Job | |
| | | ABTEST2.JBI | | Job | |
| | | ANDREW-TOOLT | EST.JBI | Job | |
| ①► | | ANDREW2.JBI | | Job | |
| | | ATTICUS.JBI | | Job | |
| | | AV1.JBI | | Job | |
| | | AV2.JBI | | Job | |
| | | BEEPALARM.JB | l. | Job | |
| | | CALLJOBTESTB | ASE.JBI | Job | |
| | | CALL INRTECTO | ETLIDN IRI | lah | |

59 file(s) in the source folder, 0 file(s) selected

9-13

COPY FILES TO CONTROLLER

9 Utility

9.4 File Transfer

9.4.4 Selection of Target/Source Folder

The user can change the target/source folder using Select Folder screen.

In this screen, the user can:

- create a new folder
- rename an existing folder
- select the target/source folder
- Fig. 9-7: Select Folder Screen

| | 2 2 | SERVO | P 2 | | |
|-----------------------------------|-----------------|---------------------|-----|--|--|
| Select Target Folde | er | | | | |
| Current Folder: USB: | | | | | |
| + NEW SUB-FOLDER | | | | | |
| Sub-folder Modified | | | | | |
| 1234567890 | 12 2018-05-22 1 | 10:40 am | | | |
| 2 | 2018-05-08 1 | 2018-05-08 11:12 am | | | |
| СМОЅВК | 2018-05-22 0 | 2018-05-22 05:53 pm | | | |
| ENCODING | 2018-04-21 0 | 2018-04-21 05:08 am | | | |
| FILE-BACKUP | 2018-05-30 0 | 2018-05-30 09:16 am | | | |
| Pendant | 2018-04-04 10 | 2018-04-04 10:34 am | | | |
| SYS-BACKUP | 2018-05-04 03 | 2018-05-04 03:15 pm | | | |
| TEST | 2018-05-22 1 | 2018-05-22 10:17 am | | | |
| TEST01 | 2018-05-11 1 | 2018-05-11 11:10 am | | | |
| YRC-PARAM | 2018-04-19 0 | 2018-04-19 08:47 am | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| Full Path of Current Folder: USB: | | | | | |
| | CANCEL | SELECT CURRENT FOLD | ER | | |
| | | | | | |
| | | | | | |
| | | | | | |

9-14

- 9 Utility
- 9.4 File Transfer

9.4.4.1 Create a New Folder

- 1. Press {+ NEW SUB-FOLDER}.
 - New Folder screen will appear.

| Select Target Folder | | |
|----------------------|-----------------------------|--|
| | Current Folder: FILE-BACKUP | |
| TO PARENT FOLDER | + NEW SUB-FOLDER | |
| Sub-folder | Modified \$ | |
| НС10-1 | 2018-05-22 03:19 pm | |
| HC10-2 | 2018-05-24 04:26 pm | |
| HC10-3 | 2018-05-17 04:44 pm | |

2. Enter a new folder name.

| New Folder | Name | | |
|----------------|------------|----------|--|
| (1-12 characte | ers) | _ | |
| | | | |
| | a <u>a</u> | | |
| CANCEL | CREATE NEW | / FOLDER | |
| | | | |

- 3. Press {CREATE NEW FOLDER}.
 - New folder is created unless a folder with the same name already exists.

9 Utility

9.4 File Transfer

9.4.4.2 Rename an Existing Folder

- 1. Press {...} on the target sub-folder in the folder list view.
 - {RENAME} will appear.



2. Press {RENAME}.

- Rename Folder screen will appear.

| Sub-folder | Modified 🜩 | |
|------------|---------------------|--------|
| 05102018 | 2018-05-11 04:53 am | RENAME |
| 2018 | 2018-05-17 06:08 pm | 100 |


3. Enter a new folder name.

| Rename Folder | |
|---------------|--------------------------|
| | |
| | New Folder Name 05102018 |
| | (1-12 characters) |
| | CANCEL RENAME FOLDER |
| | |

- 4. Press {RENAME FOLDER}.
 - Folder name is renamed unless a folder with the same name already exists.

9.4.4.3 Select the Target/Source Folder

- 1. Press the sub-folder name in the folder list view.
 - A sub-folder will open.
- 2. Press {TO PARENT FOLDER}.
 - A parent folder will open.
 - If the current folder it the root folder, this button will not show up.
- 3. Press {SELECT CURRENT FOLDER}, if the current folder is the target/source folder.



- 9 Utility
- 9.5 Robot Status Watch

9.5 Robot Status Watch

The Robot Status Watch can be used to view Robot information for debugging or verification. It can be used in either AUTOMATIC (PLAY) or MANUAL (TEACH) modes and can be viewed as a half-screen or quarter-screen size. To access the Robot Status Watch, select {Main Menu}, {Utility}, and {Robot Status Watch}.

The Robot Status Watch window has the following information (as labeled in *fig. 9-8 "Robot Status Watch"*):

1. Current Job name and line

This will be updated as a job is executed.

2. Robot Position


The "Ref. Coord" selection can be used to switch between Joint, World, Robot, and User coordinates. Current active tool is also displayed.

3. Limit Release Status

This will display the current status of the limit release. Green is enabled and white is disabled.

4. Allowable Max Torque of Shock Detection

This will display the currently active Allowable Max Torque of Shock Detection. For more information, see the *chapter 6.5 "Shock Detection Setting*".




| V Robot Status | × |
|---|---|
| Current Job: LONGJOB Current Line: 1 | Limit Status Soft Limits Released O 3 All Limits Released O |
| Robot Position | Shock Detection Levels |
| S 90.00 ° Ref. Coord. Joint ~ | S 100 |
| L -45.00 ° | L 100 |
| U 12.73 ° | U 100 |
| R -121.21 ° 2 | R 100 4 |
| B -174.90 ° | B 100 |
| T 0.01 ° | T 100 |
| Active Tool #: 2 - CTool 2 | |
| | |
| | |

To resize the window to quarter-screen, press the collapse icon (\mathbf{x}). This window can now be moved left/right and up/down using the arrow buttons on the top right of the Robot Status Watch window (shown in *fig. 9-9 "Quarter-size Robot Status Watch"*).

- 9 Utility
- 9.5 Robot Status Watch

Fig. 9-9: Quarter-size Robot Status Watch



- 10 Direct Teach
- 10.1 Direct Teach Description

10 Direct Teach

10.1 Direct Teach Description

A manipulator equipped with Direct Teach (ex. MOTOMAN-HC10DT) supports automatic INFORM program generation with hand guiding. This is accomplished using the Direct Teach Hub on the tool flange of the manipulator. The Direct Teach Hub has three pairs of buttons, described below.

Button Description **MOVE Button** Press and hold this button to move the manipulator using OR hand guiding #1 Button TOOL UTILITY Use this button to activate the tool and automatically add Button commands to the job. The duration of the button pushes results in the following behavior: OR #2 Button Short-push: Change tool number and toggle Block Long-push¹⁾: Teaches the current position and adds Block I/O commands **TEACH Button** Use this button to teach a position and automatically add a Motion command to the job. The duration of the button pushes results in the following behavior: Short-push: Teaches the current position with no Position Level. Long-push¹⁾: Teaches the current position with Position Level = 0. This means that the manipulator will stop at this position.

Table 10-1: Direct Teach Attachment Buttons

1 For a long-push, press and hold the button for more than 1 second.

Fig. 10-1: Direct Teach Hub





Block I/O must be configured properly prior to use of the TOOL Button. Refer to *chapter 6.2 "I/O for Tool"* for more information.




- 10 Direct Teach
- 10.2 Direct Teach Access and Setup Panel

10.2 Direct Teach Access and Setup Panel

To access Direct Teach, select Hand Guiding Mode on the Robot Jog panel.

| Fig. 10-2: Hand (| Guiding N | Лode |
|-------------------|-----------|------|
|-------------------|-----------|------|



10.2.1 Set Jog Mode

In the Hand Guiding Robot Jog panel, three sub-modes are provided:

- All JOINTS: User can move any Robot joint by hand
- TOOL JOINTS: User can move the outward-most 3 tool joints by hand
- XYZ+TOOL: The tool is free to move in XYZ. The tool joint can also rotate

The Robot joints that can be moved in each respective mode will be displayed in green in the *fig. 10-2 "Hand Guiding Mode*".

10.2.2 Select Motion Type

The motion type of a command taught by Direct Teach will follow the same pattern as a command taught using standard methods. Verify motion instruction type on the screen and change as necessary. Refer to *chapter 4.1.4.1 "Teaching Motion Instructions"* for more information on selecting the motion instruction type. Press [TEACH] on the Direct Teach Hub to teach the position.



10-2

- 10 Direct Teach
- 10.2 Direct Teach Access and Setup Panel

10.2.3 Select Tool for Direct Teach

Change the tool to one of the entered number in the Robot Jog panel.



10.2.4 Enable Direct Teach

Press the Direct Teach Settings on the Hand Guiding Robot Jog panel. Once the settings are completed, the Direct Teach can be used. Refer to *chapter 10.3 "Direct Teach Settings"* for the detail.

- 10 Direct Teach
- 10.3 Direct Teach Settings

10.3 Direct Teach Settings

Open the Direct Teach Setup panel by tapping the link on the bottom-left of the Hand Guiding Robot Jog panel.

Fig. 10-3: Hand Guiding Screen





Fig. 10-4: Direct Teaching Setup Panel

10-4



- 10 Direct Teach
- 10.3 Direct Teach Settings

10.3.1 Enable Teach Button and Enable Tool Button

If Direct Teach is only needed for hand guiding the manipulator, use the switch controls on the panel to disable teach and tool button operations.

10.3.2 Tool Number for Block I/O State

Use this option to specify which tool setting is used for each tool state (ON/OFF). For example, Tool 0 state should be used when specifying properties of a tool without a workpiece. Conversely, Tool 1 state should be used when specifying properties of a tool with a workpiece.

To Set Block I/O: Open the {Block I/O} screen under {Program/Operate} in {MENU}

Create the program for both OFF and ON state, and this program will be operated and added to the program when Tool I/O button on the Direct Teach Hub is pushed (Button $#2 - \log push$)

See example on *fig. 10-5 "Block I/O Screen"*, and *chapter 10.3.3 "Example on Setting Direct Teach"*.

Fig. 10-5: Block I/O Screen

Plook I/O: ToolSwitch

| Name FoolSwitch | Select State to E | dit: OFF | NO (|
|---------------------|-------------------|--------------------|----------------|
| OFF State Commands: | | ON State Commands: | ¦¦↓ Test State |
| Timer T=0.50 | | Timer T=0.50 | Ĉ |
| DigitalOut OT#(5) | OFF | DigitalOut OT#(5) | ON |
| Timer T=0.50 | | Timer T=0.50 | |
| | | | |
| | | | |
| | | | |
| | | | |

- 10 Direct Teach
- 10.3 Direct Teach Settings

10.3.3 Example on Setting Direct Teach

Tool setting example is shown as following:

| Tool | Description |
|---------|--|
| Tool #0 | Before pick of workpiece. Tool is OFF. Tool weight is set as weight of the tool. |
| Tool #1 | After pick of workpiece. Tool is ON. Total weight is set as weight of the tool plus the weight of workpiece. |

Further detail:

Set Tool number on Tool Setting screen. Refer to *chapter 6.1 "Tool Settings"*.

Create Block I/O on Block I/O screen. Refer to chapter 6.2 "I/O for Tool".

Link Block I/O to Tool #0 and #1 on Tool screen.

- 10 Direct Teach
- 10.4 Direct Teach Example

10.4 Direct Teach Example

The following INFORM program is an example of how to teach "pick and place" motion using Direct Teach.

| Line | Tool | Instructions | Comment | Tasks |
|------|---|---|--|---|
| 1 | [0] | JointMove Speed=10.00% | Start position | Short-push Teach Button |
| 2 | [0] | JointMove Speed=10.00% | Approach position for pick | Short-push Teach Button |
| 3 | [0] | LinearMove Speed=50.0mm/s Pick position PositionLevel=0 | | Long-push Teach Button |
| 4 | [1] LinearMove Speed=50.0mm/s Special Line for changing Tool number. (Same position as previou line) | | Tool number. (Same position as previous | Short-push Tool Button Long-push Tool Button |
| 5 | | Toggle Tool #0 to #1 | Toggle tool I/O | |
| 6 | [1] | LinearMove Speed=50.0mm/s | | Short-push Teach Button |
| 7 | [1] | LinearMove Speed=50.0mm/s | Approach position for placing | Short-push Teach Button |
| 8 | [1] | LinearMove Speed=50.0mm/s PositionLevel=0 | Place position | Long-push Teach Button |
| 9 | [0] | LinearMove Speed=50.0mm/s | Special Line for changing Tool number. (Same position as previous line) | Short-push Tool Button Long-push Tool Button |
| 10 | | Toggle Tool #1 to #0 | Toggle tool I/O | |
| 11 | [0] | LinearMove Speed=50.0mm/s | | Short-push Teach Button |
| 12 | [0] | JointMove Speed=10.00% | Move back to start position | Short-push Teach Button |

- 11 Safety Function
- 11.1 System Structure

11 Safety Function

The following are safety functions of the YRC Controllers:

- Emergency Stop switch input (Robot Controller/Smart Pendant)
- Enable switch input (Smart Pendant)
- Safeguarding interlock signal input (safety plug)
- External Emergency Stop switch input
- Servo power enable input
- Overrun input (manipulator/external axis)
- General-purpose safety input (including external enable switch input)
- Safety Logic Circuit

These safety functions conform to the following safety standards:

- EN ISO 13849-1: 2015 Cat.3/PLe
- EN 62061 (IEC 61508) SIL CL3

Also, by using Functional Safety Function (Optional), the position and speed of the Robot as well as the posture of its tool can be monitored.

Functional Safety Function conform to the following safety standards.

- EN ISO 13849-1: 2015 Cat.3/PLd

11-1

- EN 62061 (IEC 61508) SIL CL2

11.1 System Structure

The functional safety function and collaborative operation function are performed by using the safety circuit board and PFL circuit board.

11.1.1 Safety Circuit Board (JANCD-ASF01-E)

For details on the safety circuit board, refer to "YRC1000 INSTRUCTIONS (RE-CTO-A221) chapter 14.6.1 Safety Circuit Board (JANCD-ASF01-E)".

11.1.2 PFL Circuit Board (JANCD-ASF04-E)

For details on the PFL circuit board, refer to "YRC1000 SUPPLEMENTARY INSTRUCTIONS FOR HC10/HC10DT (HW1484756) chapter 4.1 PFL Board (JANCD-ASF04-E)".

- 11 Safety Function
- 11.1 System Structure

11.1.3 Expansion Safety I/O Board (JANCD-ASF02-E)

For details on the Expansion Safety I/O Board, refer to:

- "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576) chapter 2.1.2 Expansion Safety I/O Board (JANCD-ASF02-E)"
- "YRC1000micro OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1484544) chapter 2.1 Outline"
- "YRC1000micro SUPPLEMENTARY INSTRUCTIONS FOR HC10/ HC10DT (HW1485285) chapter 4.2 Expansion Safety I/O Board"

11.1.4 Expansion Safety Terminal Block Board

For details on the Expansion Safety Terminal Block Board, refer to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576) chapter 2.1.3 Expansion Safety Terminal Block Board".

- 11 Safety Function
- 11.2 Common Operation

11.2 Common Operation

11.2.1 Security Level

To use the PFL function, change the YRC Controller security access level to Safety level. Refer to chapter 1.17 "Security Level Setting" regarding how to change the security mode.

11.2.2 Readback Operation

The data related to the safety function is copied to the safety circuit board's memory or PFL circuit board's memory for safety. Readback is the operation to confirm whether the data saved in the safety circuit board or PFL circuit board is correct.

If the data for safety settings or tool settings changed, readback operation is required.

- 1. Edit the data related to the safety function.
 - {READBACK} and {CANCEL} appear on the screen.

| Axis Range Limit #1: Sample Axis | RangeLimit 🛛 🗙 c/ | ANCEL 🔗 READBACK |
|----------------------------------|-------------------|------------------|
| Name | Enable Condition | (\tilde{I}) |
| Sample AxisRangeLimit | Always ON 🗸 | |

| {READBACK} : | Transmits the edited data to the safety circuit board. |
|--------------|---|
| {CANCEL} : | Deletes the edited data and returns to the previous settings. |

2. Press {READBACK} to set the data.

- The data transmits to the safety circuit board.
- The readback data from the safety circuit board appears.
- {WRITE} and {CANCEL} appear on the screen.



| {WRITE} : | Stores the settings of the edited data in the safety circuit board. |
|------------|---|
| {CANCEL} : | Deletes the edited data and returns to the previous settings. |

11 Safety Function

11.2 Common Operation

3. Compare the readback result.

If the readback result matches the edited data, it is successfully transferred. But if the readback result does not matches the edited data, the comparison result is shown as "***". If so, the edited data or readback data can be seen by selecting {Edit Value} or {Readback Value} in {Display} option.

If comparison result does not match the edited data, the setting cannot be entered and saved.

| Axis Range Limit #1: Sample AxisRangeLimit | | CONFIRM |
|--|---------------------------------|---------------|
| Name Sample AxisRangeLimit | Enable Condition Always ON ~ | (\tilde{l}) |

- 4. Press {WRITE} to update the settings of the safety circuit board.
 - {CONFIRM} appears on the screen if the setting requires confirmation.
- 5. Press {CONFIRM} to enable the safety function after confirmation.

11.2.3 Tool Configuration

Specific safety functions read and use tool settings. The following table lists the safety functions and indicates which functions require tool settings before using the safety functions.

| Safety Functions | Tool Settings Requirement |
|------------------------|---------------------------|
| Robot Range Limit | 0 |
| Axis Range Limit | X |
| Speed Limit | 0 |
| Axis Speed Monitor | X |
| Tool Angle Monitor | 0 |
| Tool Change Monitor | X |
| External Force Monitor | 0 |

O: tool setting required, X: tool setting not required

The tool setting must be properly specified for the precise monitoring of the safety function. To perform the tool setting properly refer to chapter 6.1 "Tool Settings".

- 11 Safety Function
- 11.2 Common Operation

11.2.4 Tool Interference Configuration

Specific safety functions read and use tool interference. The following table lists the safety functions and indicates which functions require tool interference before using the safety functions.

Table 11-2: Tool Interference Configuration for Safety Functions

| Safety Functions | Tool Interference Requirement |
|------------------------|-------------------------------|
| Robot Range Limit | 0 |
| Axis Range Limit | х |
| Speed Limit | х |
| Axis Speed Monitor | х |
| Tool Angle Monitor | х |
| Tool Change Monitor | 0 |
| External Force Monitor | X |

O: tool interference setting required,

X: tool interference setting not required

The tool interference setting must be properly specified for the precise monitoring of the safety function. To perform the tool interference setting, use the Software Pendant. Refer to chapter 12 "Software Pendant" for the use of the Software Pendant, and "YRC1000 OPTIONS INSTRUCTION FOR FUNCTIONAL SAFETY FUNCTION (HW1483576) chapter 6.4 "Tool Interference File Setting" for setting the tool interference.

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3 Safety Logic Circuit

11.3.1 Introduction

The safety logic circuit is a is a feature used for programming the basic safety logic of the system using a simple ladder logic programming interface. It enables to set up the logical operations, such as stopping the manipulator and outputting the servo ON signal.

The followings are the contents of this function:

- Executes the safety logic circuit by the safety circuit board in compliance with safety certification.
- The safety logic circuit consists of a "System" section and a "User" section.
- The System section of the safety logic circuit is the specific circuit of YASKAWA and cannot be edited. The User section allows users to add/edit their own safety logic.
- Both the System and User sections of the safety logic circuit consist of a circuit with two inputs and one output or a circuit with one input and one output.
- Both the System and User sections of the safety logic circuit consist of 128 lines.
- Both the System and User sections of the safety logic circuit are executed on a 2ms cycle.
- Both the System and User sections of the safety logic circuit can be viewed in all security modes; however, the user section can be edited only when the security mode is "SAFETY MODE", and the system is in MANUAL (TEACH) mode with the servo power turned OFF.
- Conventionally, some functions were performed only by using hardwired signals. With the YRC Controller, by using an optional safety PLC and an optional safety logic circuit, these functions can be controlled from the safety PLC. This enables less wiring. Meanwhile, the signals which have been controlled by hardware are always monitored. Thus, the safety function, which turns OFF the servo power supply when the error is detected, is maintained.


The YRC Controller with an optional Safety PLC and optional Safety Logic Circuit can be controlled with the Ethernet Cable wiring. This is an improvement over previous conventional systems that required hard wired solutions.


The signals that are controlled by hardware are always monitored so the safety function that turns off the servo power supply when errors are detected is maintained.


11-6

- 11 Safety Function
- 11.3 Safety Logic Circuit

Fig. 11-1: Safety PLC Configuration with YRC1000 Controller Example:







In YRC1000, for the connection of the General Purpose Safety I/O board (Option), either the board of JANCD-ASF02-E (8 points available) or JANCD-ASU03-E(16 points available) can be connected to each safety circuit board (JANCD-ASF01-E).



11-7

JANCD-ASF02-E: For both input and output, 8 points of GP safety I/O signal can be used.

JANCD-ASU03-E: For both input and output, 16 points of GP safety I/O signal can be used.

In YRC1000micro, for the connection of the Extension GP Safety I/O board (optional), the board of JANCD-ASF32-1E (8 points available) can be connected to each safety circuit board (JANCD-ASF30-1E).



- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.2 Available I/O Signals in Safety Logic Circuit

The following tables describe the input and output signals available in the safety logic circuit.

Table 11-3: Input Signals

| No. | Kind | Display | Contents | Note |
|-----|---------------------------------|--------------|---|--|
| 1 | Physical Discrete Safety I/O | #n GSIN[x] | General Purpose safety input signal 2 points ● : OFF [release]/ ○ : ON [short circuit] | This signal is shown only in YRC1000 |
| 2 | | #n GSOUT[x] | General Purpose output signal 2 points ● : ON output/ ○ : OFF output | |
| 3 | | #n FSBIN[x] | General Purpose safety input signal (8 or 16 points) ● : OFF [release]/ ○ : ON [short circuit] | This signal is shown when the optional GP safety I/O board is connected. |
| 4 | | #n FSBOUT[x] | General Purpose safety output signal (8 or 16 points) ● : ON status/ ○ : OFF status | |
| 5 | Fieldbus Safety I/O | SFBIN[x] | Safety field bus input signal 64 points ● : ON status/ ○ : OFF status | This signal is shown when the optional safety fieldbus function is enabled. |
| 6 | | SFBOUT[x] | Safety field bus output signal 64 points ● : ON status/ ○ : OFF status | |
| 7 | Virtual Discrete Safety I/O | MSOUT[x] | Machine safety output used in the safety logic circuit (64 points) ● : ON status/ ○ : OFF status | This signal is shown when the functional safety function (option) is enabled. |
| 8 | - | FSOUT[x] | Functional safety output used in the safety logic circuit 64 points ● : ON status/ ○ : OFF status | |
| 9 | | #n PFLIN[x] | Output signal to PFL board (ASF04-E) 32 points ● : ON status/ ○ : OFF status | This signal is shown when the optional PFL board (ASF04-E) is connected. |
| 10 | | #n PFLOUT[x] | Input signal from PFL board (ASF04-E) 32 points ● : ON status/ ○ : OFF status | |
| 11 | | R[x] | Work area 128 points (auxiliary relay) ● : ON status/ ○ : OFF status | |

Safety Function
 Safety Logic Circuit

| No. | Kind | Display | Contents | Note |
|-----|-------------------|------------------|--|---|
| 12 | Other I/O Signals | SPIN[x] | Specific input signal 32 points ● : ON status/ ○ : OFF status | |
| 13 | | #n ONEN[x] | Servo power supply individual control input signal 4 points • : Individual servo OFF status/ • : Normal status | This signal is shown only on YRC1000 |
| 14 | | #n S-ONEN[x] | Servo power supply individual control input signal in the safety logic circuit 4 points • : Individual control group servo OFF status/ ○ : Servo ON status/ servo ON enabled status | |
| 15 | | #n SFRON[x] | Servo ON/OFF signal 4 points • : Servo ON/ • : Servo OFF | |
| 16 | | PPESP | Pendant Emergency Stop signal ● : Under Emergency Stop [release]/ ○ : Not under Emergency Stop [short circuit]) | |
| 17 | | PBESP | YRC Controller Emergency Stop signal ● : Under Emergency Stop [release]/ ○ : Not under Emergency Stop [short circuit] | This signal is shown only on YRC1000 |
| 18 | | EXESP | External Emergency Stop input signal ● : Under Emergency Stop [release]/ ○ : Not under Emergency Stop [short circuit] | |
| 19 | | PPDSW | Pendant enable switch signal ● : Released [release]/ ○ : Grip [short circuit] | |
| 20 | | MANUAL (TEACH) | MANUAL(TEACH) mode • : MANUAL (TEACH) mode/ • : Not MANUAL (TEACH) mode | |
| 21 | | AUTOMATIC (PLAY) | AUTOMATIC (PLAY) mode • : AUTOMATIC (PLAY) mode/ • : Not AUTOMATIC (PLAY) mode | |

- 11Safety Function11.3Safety Logic Circuit

| No. | Kind | Display | Contents | Note |
|-----|-------------------------|-----------|---|--|
| 22 | Other I/O Signals Cont. | REMOTE | REMOTE mode ● : REMOTE mode/ ○ : Not remote mode | |
| 23 | | Hold | Hold ● : OFF (Hold signal is not input.)/ ○ : ON (Hold signal is being input.) | |
| 24 | | PROFISafe | PROFISafe communication status ● : Communication OK/ ○ : Error communication | Appears only when the optional PROFISafe is enabled. |
| 25 | | SVON | Servo ON/OFF status ● : Servo ON/ ○ : Servo OFF | |
| 26 | | SVONRDY0 | Servo ON ready ● : Servo ON available status/ ○ : Servo OFF | |
| 27 | | SAFF | Safety fence signal ● : Open/ ○ : Close | |
| 28 | | S-EXESP | External Emergency Stop signal in the safety logic circuit ● : Release/ ○ : Press (Emergency Stop status) | |
| 29 | | S-EXDSW | External enable switch signal in the safety logic circuit • : ON (servo ON enabled)/ : OFF (servo OFF status) | |
| 30 | | S-SVON_EN | - | This signal is shown only when the enable switch link function is enabled. For details, refer to "YRC1000 INSTRUCTIONS (RE-CTO-A221) chapter 8.26.13 "Enable Switch Link Function ". |
| 31 | | S-SAFF | Safety fence signal in the safety logic circuit ● : Close/ ○ : Open (servo OFF status) | |
| 32 | | S-FST | Full speed mode in the safety logic circuit ● : Full speed mode/ ○ : Safety speed | Refer to chapter 11.3.6.3 "Full Speed Mode" |

Safety Function
 Safety Logic Circuit

| No. | Kind | Display | Contents | Note |
|-----|-------------------------|---------|--|---|
| 33 | Other I/O Signals Cont. | CSCFG1 | Safety data monitoring Monitoring result of the safety-related parameter files ● : Normal monitoring (Parameter is not changed.) ○ : Abnormal monitoring (Parameter is changed.) | This signal is shown only in YRC1000 |
| | | | Compare the stored CRC for the safety- related parameter and the current CRC for the safety-related parameter, and show whether there is any change in the data. | |
| 34 | | CSCFG2 | Safety data monitoring Monitoring result of the Safety Logic Circuit • : Normal monitoring (Safety Logic Circuit is not changed.) : Abnormal monitoring (Safety Logic Circuit is changed.) | This signal is shown only in YRC1000 |
| | | | Compare the stored CRC for the machine safety data file and the current CRC for the machine safety data file, and show whether there is any change in the data. | |

- 11 Safety Function
- 11.3 Safety Logic Circuit

| No. | Kind | Display | Contents | Note |
|-----|-------------------------|---------|--|---|
| 35 | Other I/O Signals Cont. | CSCFG3 | Safety data monitoring Monitoring result of the functional safety setting files • : Normal monitoring (Data file is not changed.) · : Abnormal monitoring (Data file is changed.) Compare the stored CRC for the functional safety data file and the current CRC for the functional safety data file, and show whether there is any change in the data. When the functional safety function is disabled, it is always | This signal is shown only in YRC1000 |
| | _ | | "ON" (Normal monitoring). | |
| 36 | | CSCFG4 | Safety data monitoring Monitoring result of all safety related files : Normal monitoring (Parameter and the data file not changed.) : Abnormal monitoring (Either of the parameter or the data file changed.) Compare the stored CRCs for the safety- related parameter and the data files of the machine safety and the functional safety and the current CRCs for the parameter and the data file. Show whether there is any change in the | This signal is shown only in YRC1000 |
| | | | data. (Equivalent to AND of CSCFG01, CSCFG02, and CSCFG03) | |

n: The number of safety circuit boards (Maximum 8)

Safety Function
 Safety Logic Circuit

Table 11-4: Output Signals

| No. | Kind | Display | Contents | Note |
|-----|---------------------|---------------|--|--|
| 1 | Discrete Safety I/O | #n GSOUT[x] | General Purpose output signal 2 points ● : ON output/ ○ : OFF output | This signal is shown only in YRC1000 |
| 2 | | #n FSBOUT[x] | General Purpose safety output signal (8 or 16 points) ● : ON status/ ○ : OFF status | This signal is shown when the optional GP safety I/O board is connected. |
| 3 | | #n S-GSEDM[x] | General Purpose Safety Output Monitoring Signal 2 points | This signal is shown only in YRC1000 |
| 4 | | #n S-XEDM[x] | General Purpose Safety Output Monitoring Signal (8 or 16 points) | This signal is shown when the optional GP safety I/O board is connected. |
| 5 | Fieldbus Safety I/O | SFBOUT[x] | Safety field bus output signal 64 points ● : ON status/ ○ : OFF status | This signal is shown when the optional safety fieldbus function is enabled. |
| 6 | Safety Logic Signal | MSOUT[x] | Machine safety output used in the safety logic circuit (64 points) ● : ON status/ ○ : OFF status | This signal is shown when the functional safety function (option) is enabled. |
| 7 | | #n PFLIN[x] | Output signal to PFL board (ASF04-E) 32 points • : ON status/ • : OFF status | This signal is shown when the functional safety function (option) is enabled. |
| 8 | | R[x] | Work area 128 points (auxiliary relay) ● : ON status/ ○ : OFF status) | |
| 9 | Other Signals | #n S-ONEN[x] | Servo power supply individual control input signal in the safety logic circuit 4 points ● : Individual control group servo OFF status/ ○ : Servo ON status/ servo ON enabled status | |
| 10 | | SVOFF CAT0 | Turns OFF the servo power supply to the Robot. (Category0 stopped) ● : Robot stop request/ ○ : Not Robot stop request | |
| 11 | | SVOFF CAT1 | Turns OFF the servo power supply to the Robot. (Category1 stopped) ● : Robot stop request/ ○ : Not Robot stop request | |

- 11 Safety Function
- 11.3 Safety Logic Circuit

| No. | Kind | Display | Contents | Note |
|-----|---------------------|-----------|---|---|
| 12 | Other Signals Cont. | S-EXESP | External Emergency Stop signal in the safety logic circuit ● : Release/ ○ : Press (Emergency Stop status) | |
| 13 | | S-EXDSW | External enable switch signal in the safety logic circuit ● : ON (servo ON enabled)/ ○ : OFF (servo OFF status) | |
| 14 | | S-SVON_EN | Servo ON enable signal in the safety logic circuit ● : Servo ON enabled status/ ○ : Servo OFF) | This signal is shown only when the enable switch link function is enabled. For details, refer to "YRC1000 INSTRUCTIONS (RE-CTO-A221) chapter 8.26.13 "Enable Switch Link Function". |
| 15 | | S-SAFF | Safety fence signal in the safety logic circuit ● : Close/ ○ : Open (servo OFF status) | |
| 16 | | S-FST | Full speed mode in the safety logic circuit ● : Full speed mode/ ○ : Safety speed | Refer to chapter 11.3.6.3 "Full Speed Mode" |
| 17 | | SICFGTRG | Safety data monitoring Reset trigger for Monitoring result (CSCFG) When this signal falls (ON to OFF), each CRC of the safety related parameter, the machine safety data file, and the functional safety data file is stored. The safety data can be monitored by using the stored CRC. | This signal is shown only in YRC1000 |
| | | | (For the monitoring result, refer to CSCFG01, CSCFG02, CSCFG03, CSCFG04.) | |

n: The number of safety circuit board (Maximum 8)

11 Safety Function

NOTE

11.3 Safety Logic Circuit

When using the GSOUT signal and the FSBOUT signal, output signal for 20 ms or longer to execute the confirmation of the machine safety internal diagnosis function and the verification of wiring.

The confirmation of the machine safety internal diagnosis function and the verification of wiring is always executed. Confirm the ON time signal is 20 ms or longer prior to performing the automatic operation. When the ON time is less than 20 ms, the following alarms may be detected wrongly.

- Alarm 4771 M-SAF GENERAL OUTPUT DIAG. ERROR
- Alarm 4767 M-SAF GENERAL OUT FB DIAG. ERROR
- Alarm 4926 M-SAF GENERAL OUTPUT UNMATCH
- Alarm 4772 M-SAF GENERAL OUTPUT DIAG. ERROR2
- Alarm 4768 M-SAF GENERAL OUTPUT FB DIAG. ERROR2
- Alarm 4927 M-SAF GENERAL OUTPUT UNMATCH2

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3 Operation of Safety Logic Circuit

11.3.3.1 Display the Screen

Select {MENU} \rightarrow {Safety Functions} \rightarrow {Safety Logic Circuit}.

- Safety Logic Circuit Screen is shown.

| | LA ERVO | F | N. |
|------------------|--|---|--------------|
| ← Safety Logic C | Circuit | | |
| User | System | Û | ŝ |
| | There are no configured settings. Press the {NEW GROUP} button in the top panel to create a new setting. For details on using this function, please refer to Help Info. | | |
| Details | | | \checkmark |
| | Please select Relay to Edit. | | |


- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3.2 Selecting System and User Circuits

By pressing Tab shown on the pendant and selecting the "User" or "System", the display can be switched between user and system safety logic circuit.

SYSTEM: The system section of the safety logic circuit is shown.

USER: The user section of the safety logic circuit is shown.



11.3.3.3 Create New Safety Logic Circuit

To create new safety logic circuit, press {NEW LOGIC}.

| (| Safety Logic Circui | t | | |
|--------------|---------------------|--------|---|---|
| | User | System | Û | ŝ |
| | | | | |
| | | | | |
| | | | | |

A new line is created with one input relay and one output relay as shown below.

| ~ | Safety Logic Circui | t 🕀 NEW LOGIC | CANCEL COREADBACK |
|-----|---------------------|---------------|-------------------|
| | User | System | ₫ 錄 |
| Nev | v Logic 1 | | |
| 1 | FSBIN01 |) | Easer Setting1 |
| | | | |

Each line can have one or more input relays. Each line can have only one output relay, and the same output signal cannot be set on multiple lines.

When the Safety Logic Circuit has been edited, the {Readback} shows on top of the screen.

11-17

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3.4 Edit Input Relays

Press the input relay to edit.

- Detail of the input relay will be shown on the detail panel.

| test | | |
|-----------------------------------|-----------------------|--------|
| 5 Laser Scanner Area W LINE |) | GSOUT2 |
| Details | | \sim |
| Input Type Normally Open - | ~ | (j) |
| Signal | Name | |
| FSBIN01 | ✓ Laser Scanner Area1 | |

① If {Input Type} is pressed, the type of the input relay can be changed. To select "Detect OFF \rightarrow ON" or "Detect ON \rightarrow OFF", the number of Input relay should be 2 or less.

② If {Signal} is pressed, the input signal can be changed. Refer to chapter 11.3.2 for list of available signals and their meanings.

③ If {Name} is pressed, the name of the signal can be edited. The name of the signal is also shown in the line of the Safety Logic Circuit. The name of the signal also can be edited in the Signal Setting screen. The name of signals which is not shown in the Signal Setting screen cannot be edited.

Input type can be selected from table 11-5.

Safety Function
 Safety Logic Circuit

| No. | Display | Contents |
|-----|---------|---|
| 1 | | Normally Open contact. |
| | 11 | If the signal is TRUE (ON), then this expression is CLOSED (ACTIVE). |
| 2 | | Normally Closed contact. |
| | -1/- | If the signal is TRUE (ON), then this expression is OPEN (INACTIVE). |
| 3 | | Detect OFF \rightarrow ON |
| | ┥╂┣╸ | Detect a rising edge of signal. |
| | | If the signal changes from FALSE (OFF) to TRUE (ON) then this expression is CLOSEE (ACTIVE) for only ONE cycle of the Safety Logic Circuit. Output to far right of this signal must be a PULSE output type. |
| 4 | | Detect $ON \rightarrow OFF$ |
| | | Detect a falling edge of signal. |
| | | If the signal changes from TRUE (ON) to FALSE (OFF) then this expression is CLOSEE (ACTIVE) for only ONE cycle of the Safety Logic Circuit. |
| | | Output to far right of this signal must be PULSE output type. |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3.5 Edit Output Relays

Press output relay to edit.

- Detail of the output relay will be shown on the detail panel.

| 5 PSBINOT Laser Sr Area1 P NEW LINE Details Output Type 1 DN Delay 1 2 ON Delay 1 3 100 msec | Signa (4) SB | al OUT01 | Name 5 Laser Scanner Setting1 | |
|---|-----------------|-------------|----------------------------------|--------|
| 5 Laser Sr Area1 Laser Scanner Setting1 | Outp | ut Type | \cap | |
| | | | | 100 ms |
| | | FSBIN01 | | |

1 If {Output Type} is pressed, the type of the output relay can be changed. To select "Pulse", the number of Input relay should be two or less.

② Timer number for the output relay can be changed. This item will be shown when the output type is "Pulse", "ON Delay", or "OFF Delay". The same timer number cannot be used on multiple lines.

③ Specifies the timer value. Timer value should be multiple of 4. If the input value is not multiple of 4, the value will be changed to multiple of 4. This value can be changed in Timer Setting screen.

④ If {Signal} is pressed, the input signal can be changed. The same output signal cannot be set to the multiple line. Refer to chapter 11.3.2 for list of available signals and their meanings.

(5) If {Name} is pressed, the name of the signal can be edited. The name of the signal is also shown in the line of the Safety Logic Circuit. The name of the signal also can be edited in the Signal Setting screen. The name of signals which is not shown in the Signal Setting screen cannot be edited.



To use "Detect OFF \rightarrow ON" or "Detect ON \rightarrow OFF" for Input relay, Output relay should be "Pulse". Also, to use "Pulse" for Output relay, one of the input relay should be "Detect OFF \rightarrow ON" or "Detect ON \rightarrow OFF".

Number of Input relay should be two or less.

Safety Function
 Safety Logic Circuit

| No. | Display | Contents |
|-----|----------------------|--|
| 1 | -0- | Output signal. When there is a path of CLOSED (ACTIVE) signals connecting the left side to this output then this expression is CLOSED (ACTIVE). |
| 2 | Pulse1 100 ms | Pulse Output signal with a single pulse. When there is a path of CLOSED (ACTIVE) signals connecting the left side to this output then this expression is CLOSED (ACTIVE) for the specified time. |
| | | This output should be used onl when the input signals are DETECT OFF \rightarrow ON or DETECT ON \rightarrow OFF. Only 8 Pulse outputs may be used. |
| 3 | ON Delay1 100 ms | ON Delay Turn ON signal after specified delay. |
| | | When there is a path of CLOSED (ACTIVE) signals connecting the left side to this output, this expression will be CLOSED (ACTIVE) after the specified delay amount. |
| | | Only 4 ON DELAY outputs ma be used. |
| 4 | OFF Delay1 100 ms | OFF Delay Turn OFF signal after specified delay. |
| | | When there is a path of CLOSED (ACTIVE) signals connecting the left side to this output, this expression will be CLOSED (ACTIVE) but when the input path is OPEN (INACTIVE) the signal wait for specified delay amount before turning off. |
| | | Only 4 ON DELAY outputs ma be used. |


- 11 Safety Function
- 11.3 Safety Logic Circuit

Pulse

Output signal with Pulse.

Up to 8 "Pulse" Outputs can be set.

< When setting the 1 sec to Pulse>





To use "Detect OFF \rightarrow ON" or "Detect ON \rightarrow OFF" for Input relay, Output relay should be "Pulse". Also, to use "Pulse" for Output relay, one of the input relay should be "Detect OFF \rightarrow ON" or "Detect ON \rightarrow OFF".


Number of Input relay should be two or less.

ON Delay

Turn ON signal after timer delay.

Up to four "Pulse" Outputs can be set.

< When setting the 500 msec to ON Delay>




- 11 Safety Function
- 11.3 Safety Logic Circuit

OFF Delay

Turn OFF signal after timer delay.


Up to four "Pulse" Outputs can be set.

<When setting the 300 msec to OFF Delay>



11.3.3.6 Add Relay


To add a new input relay, press {+} next to the input relay.



Or, press input relay, then press {+} on the input relay. New input relay will be added at the corresponding position.




- ① Add new input relay on the left side of the selected input relay.
- ② Add new input relay on the right side of the selected input relay.



- 11 Safety Function
- 11.3 Safety Logic Circuit


③ Add new input relay on the bottom side of the selected input relay.



11.3.3.7 Delete Relay

Press input relay to select, then press {Trash can} to delete the input relay.

- Selected input relay will be deleted.




- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3.8 Delete Line


Press the line to select, then press {Trash Can} to delete the line.

- Selected line is deleted.



11.3.3.9 Move Relay

Press the input relay, and drag to move the input relay. An icon appears to show where the relay will be placed when dropped.



- Each line must have at least one input relay.
 - If there are input relays in the line after moving the relay, the line is also deleted.
- Each line must have at least one output relay.
 - Because of this, output relay cannot be moved.

11.3.3.10 Cancel Edit

SUPPLE

To cancel the edit, press {CANCEL}. This reverts any current changes.



- 11 Safety Function
- 11.3 Safety Logic Circuit
- 11.3.3.11 Transferring and Updating Safety Logic Circuit File
 - ① After creating the safety logic circuit, press {READBACK}.
 - The safety logic circuit file is transferred to the safety circuit board.
 - When transferring of the safety logic circuit file is successfully performed, the readback data from safety circuit board will show. Button changes to {WRITE}.

| ÷ | Safety Logic Circuit | Display Comparison Result | • 😣 | CANCEL 🔗 WRITE |
|-----|----------------------|------------------------------|-----|----------------|
| | User | System | | <u></u> |
| New | / Logic 1 | | | |
| 1 | FSBIN01 | | | FSBOUT01 |

- ① Verify that there is no problem in readback data, then press {WRITE}.
 - the file transferred to the safety circuit board is written in the FLASH ROM.

1 If {CANCEL} is pressed, the file will not update. Edited data is discarded.

| | When selecting {READBACK}, all output signals that outputted from the safety circuit board are turned OI until the writing process is completed. When selecting {WRITE}, all information related to the safety logic circuit is transferred to the safety circuit board as the safety logic circuit file and written in the FLASH ROM of the safety circuit board. If the same output signal is used on multiple lines, an will be shown as following. While "!" is shown, {READBACK} cannot proceed until the safety logic circuit is corrected. | FF he e |
|------|---|---------------|
| | New Logic 1 | |
| NOTE | 1 FSBIN01 FSBOUT01 Laser S_r Area1 Laser S_etting1 | |
| | 2. Laser S_r Area2 Laser S_etting1 | |
| | | |
| | Details | \sim |
| | Output Type Out Selected Signal is used in other lines. | |
| | Signal FSBOUT01 Vame Laser Scanner Setting1 | |
| | | |
| | | |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.3.12 Execute Safety Logic Circuit

When the write operation completes, the safety logic circuit executes. If the signal is ON, the relay is "green". If the signal is OFF, the relay is "Blank".

The safety logic circuit always executes except during the write operation.



11.3.4 Setting of Input/Output Signals

Input/Output signals used in safety logic circuit can be named.

These signals are used in both the Safety Logic Circuit and the Functional Safety Function. Safety Input signals can be referred from both Safety Logic Circuit and Functional Safety Function. However, Safety Output signals can only be outputted from one of the Safety Logic Circuit or Functional Safety Function. This can be configured in the Signal Setting screen.

To open the Signal Setting screen, press {Setting} \rightarrow {Signal Setting}.



- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.4.1 Setting of General Purpose Input Signal (FSBIN)

These signals are shown when the optional General Purpose safety I/O board (ASF02, ASF03, or ASF32) is connected.

General Purpose Input signals can be named. These signals are always enabled.

| Signal Setting | | | | \times |
|---------------------------------|--------|--|-------------------------|----------|
| Physical Discrete Safety I/O | | ieldbus Virtual Discre afety I/O Safety I/O | te Other I/O Signals | |
| FSBIN | F | SBOUT | | |
| Signal | Status | Name | Enabled | |
| FSBIN01 | 0 | Laser Scanner Area1 | Enabled | |
| FSBIN02 | 0 | Laser Scanner Area2 | Enabled | |
| FSBIN03 | 0 | Safety Board Input 3 | Enabled | |
| FSBIN04 | 0 | Safety Board Input 4 | Enabled | |
| FSBIN05 | 0 | Safety Board Input 5 | Enabled | |
| FSBIN06 | • | Safety Board Input 6 | Enabled | |
| FSBIN07 | 0 | Safety relay welded shut detectio | n Enabled | |
| FSBIN08 | 0 | Resume switch | Enabled | |

11.3.4.2 Setting of General Purpose Output Signal (FSBOUT)

These signals are shown when the optional General Purpose safety I/O board (ASF02, ASF03, or ASF32) is connected.

General Purpose Output signal can be named, and also assigned to either Safety Logic Circuit or Safety Settings (Functional Safety Function).

| Signal Setting | | | | | \times |
|---------------------------------|--------|------------------------|----------------------------|---------------------------|----------|
| Physical Discrete Safety I/O | | | ual Discrete Safety I/O | Other I/O Signals | |
| FSBIN | F | SBOUT | | | |
| Signal | Status | Name | Outp | out From | |
| FSBOUT01 | 0 | Laser Scanner Setting | 1 - | | ~ |
| FSBOUT02 | 0 | Laser Scanner Setting | 2 Safe | ety Logic Circuit(M-SAFE) | |
| FSBOUT03 | 0 | Safety Board Output 3 | Safe | ety Logic Circuit(M-SAFE) | |
| FSBOUT04 | 0 | Safety Board Output 4 | Safe | ety Logic Circuit(M-SAFE) | |
| FSBOUT05 | 0 | Safety Board Output 5 | Safe | ety Logic Circuit(M-SAFE) | |
| FSBOUT06 | 0 | Safety relay welded sh | ut detection Safe | ety Settings(F-SAFE #1) | |
| FSBOUT07 | 0 | Resume switch LED | Safe | ety Settings(F-SAFE #1) | |
| FSBOUT08 | 0 | Collaborative operatio | n LED Safe | ety Settings(F-SAFE #1) | |

| 11 Safety | Function |
|-----------|----------|
|-----------|----------|

11.3 Safety Logic Circuit

| Item | Description | | |
|-----------------------------------|---|--|--|
| - | Signal is not specified | | |
| Safety Logic Circuit (M-SAFE) | The signal can be used in the safety logic circuit. | | |
| Safety Settings (F-SAFE #1 to #8) | The signal can be used in the Safety Settings (Functional Safety Function). Only the terminal which the safety I/O board is connected can be selected. | | |

11.3.4.3 Setting of Safety Fieldbus Input Signals (SFBIN (Fieldbus))

These signals are shown when the optional safety fieldbus function is enabled.

Safety fieldbus signal transmits/receives the safety-guaranteed "safety data" through the fieldbus communication path. It has 64 input signal points and 64 output signal points.

Safety Fieldbus Input signal can be only named.

These signals are always enabled.

| Signal Setting | | | | | × |
|---------------------------------|------------------------|----------------|--------------------------------|----------------------|---|
| Physical Discrete Safety I/O | Fieldbus Safety I/O | | Virtual Discrete Safety I/O | Other I/O Signals | |
| SFBIN(Fieldbus) | SFBOU | JT(Fieldbus) | | | |
| Signal | Status | Name | | Enabled | |
| SFBIN(Fieldbus)01 | 0 | PLC Sig1 | | Enabled | |
| SFBIN(Fieldbus)02 | • | PLC Sig2 | | Enabled | |
| SFBIN(Fieldbus)03 | 0 | Safety Fieldbu | is Input 3 | Enabled | |
| SFBIN(Fieldbus)04 | 0 | Safety Fieldbu | is Input 4 | Enabled | |
| SFBIN(Fieldbus)05 | 0 | Safety Fieldbu | is Input 5 | Enabled | |
| SFBIN(Fieldbus)06 | 0 | Safety Fieldbu | is Input 6 | Enabled | |
| SFBIN(Fieldbus)07 | 0 | Safety Fieldbu | is Input 7 | Enabled | |
| SFBIN(Fieldbus)08 | 0 | Safety Fieldbu | is Input 8 | Enabled | |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.4.4 Setting of Safety Fieldbus Output Signals (SFBOUT (Fieldbus))

These signals are shown when the optional safety fieldbus function is enabled.

Safety fieldbus signal transmits/receives the safety-guaranteed "safety data" through the fieldbus communication path. It has 64 input signal points and 64 output signal points.

Safety fieldbus Output signal can be named, also assigned to either Safety Logic Circuit or Safety Settings (Functional Safety Function).

| Physical Discrete Safety I/O | Fieldbus Safety I/O | | Virtual Discrete Safety I/O | Other I/O Signals | |
|---------------------------------|------------------------|--------------------------|--------------------------------|------------------------------|---|
| SFBIN(Fieldbus) | SFBOL | JT(Fieldbus) | | | |
| Signal | Status | Name | | Output From | |
| SFBOUT(Fieldbus)01 | 0 | Status Out1 | | - | ~ |
| SFBOUT(Fieldbus)02 | 0 | Status Out2 | | Safety Logic Circuit(M-SAFE) | |
| SFBOUT(Fieldbus)03 | 0 | Safety Fieldbu | s Output 3 | Safety Logic Circuit(M-SAFE) | |
| SFBOUT(Fieldbus)04 | 0 | Safety Fieldbus Output 4 | | Safety Logic Circuit(M-SAFE) | |
| SFBOUT(Fieldbus)05 | 0 | Safety Fieldbu | s Output 5 | Safety Logic Circuit(M-SAFE) | |
| SFBOUT(Fieldbus)06 | 0 | Safety Fieldbu | s Output 6 | Safety Settings(F-SAFE #1) | |
| SFBOUT(Fieldbus)07 | 0 | Safety Fieldbu | s Output 7 | Safety Settings(F-SAFE #1) | |

Table 11-8: Safety Fieldbus Output Signal

| Item | Description |
|-----------------------------------|--|
| - | Signal is not specified |
| Safety Logic Circuit (M-SAFE) | The signal can be used in the safety logic circuit. |
| Safety Settings (F-SAFE #1 to #8) | The signal can be used in the Safety Settings (Functional Safety Function). |
| Safety Settings (F-SAFE ALL) | The signal can be used in the whole safety circuit board where the functional safety is enabled. |

11.3 Safety Logic Circuit

11.3.4.5 Setting of Safety Functions Output signals (FSOUT)

These signals are shown when the functional safety function (option) is enabled.

These signals allow to use the output signal of Safety Settings (Functional Safety Function) in Safety Logic Circuit.

Safety fieldbus output signal can be named, also assigned to either Safety Logic Circuit or Safety Settings (Functional Safety Function).

| Signal Setting | | | > | < |
|----------------|--------|---|------------------------------|---|
| | | ieldbus Virtual Discret afety I/O Safety I/O | te Other I/O Signals | |
| FSOUT | N | ISOUT | | |
| Signal | Status | Name | Output From | |
| FSOUT01 | 0 | FSOUT Test1 | Safety Settings(F-SAFE #1) ~ | |
| FSOUT02 | 0 | FSOUT Test2 | Safety Settings(F-SAFE #1) | |
| FSOUT03 | • | Safety Settings Logical Output 3 | Safety Settings(F-SAFE #1) | |
| FSOUT04 | 0 | Safety Settings Logical Output 4 | Safety Settings(F-SAFE #1) | |
| FSOUT05 | 0 | Safety Settings Logical Output 5 | Safety Settings(F-SAFE #1) | |
| FSOUT06 | 0 | Safety Settings Logical Output 6 | Safety Settings(F-SAFE #1) | |
| FSOUT07 | 0 | Safety Settings Logical Output 7 | Safety Settings(F-SAFE #1) | |
| FSOUT08 | 0 | Safety Settings Logical Output 8 | Safety Settings(F-SAFE #1) | |

11-31

| Item | Description |
|-----------------------------------|---|
| - | Signal is not specified |
| Safety Settings (F-SAFE #1 to #8) | The signal can be used in the Safety Settings (Functional Safety Function). Only the terminal which the safety I/O board is connected can be selected. |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.4.6 Setting of Safety Logic Circuit Output Signals (MSOUT)

These signals are shown when the functional safety function (option) is enabled.

These signals allow the use of output signal of Safety Logic Circuit in Safety Settings (Functional Safety function, PFL function).

Safety Logic Circuit Output can be named.

These signals are always enabled.

| Signal Setting | | | | | \times |
|---------------------------------|------------------------|----------------|--|---------|----------|
| Physical Discrete Safety I/O | Fieldbus Safety I/O | | Virtual Discrete Other Safety I/O I/O Signals | | |
| FSOUT | N | ISOUT | | | |
| Signal | Status | Name | | Enabled | |
| MSOUT01 | 0 | MSOUT Test1 | | Enabled | |
| MSOUT02 | 0 | MSOUT Test2 | | Enabled | |
| MSOUT03 | 0 | Safety Logic C | ircuit Logical Outp | Enabled | |
| MSOUT04 | 0 | Safety Logic C | ircuit Logical Outp | Enabled | |
| MSOUT05 | 0 | Safety Logic C | ircuit Logical Outp | Enabled | |
| MSOUT06 | 0 | Safety Logic C | ircuit Logical Outp | Enabled | |
| MSOUT07 | • | Safety Logic C | Fircuit Logical Outp | Enabled | |
| MSOUT08 | 0 | Safety Logic C | ircuit Logical Outp | Enabled | |

Safety Function
 Safety Logic Circuit

11.3.4.7 Settings of Specific Input Signals (SPIN)



The 32 specific input signals (#40780-#40817) are allocated to the SPIN[01] to SPIN[32] signals.

These signals are available in the safety logic circuit but are not safetyrated (i.e. they are non-safety data).

Specific Input Signals can be only named.

| Signal Setting | | | | | \times |
|---------------------------------|--------|----------------------|--------------------------------|----------------------|----------|
| Physical Discrete Safety I/O | | ieldbus afety I/O | Virtual Discrete Safety I/O | Other I/O Signals | |
| Signal | Status | Name | | | |
| SPIN01 | 0 | SPIN Test1 | | | |
| SPIN02 | 0 | SPIN Test2 | | | |
| SPIN03 | 0 | Specific Inpu | ut 3 (Non-Safety data) | | |
| SPIN04 | 0 | Specific Inpu | ut 4 (Non-Safety data) | | |
| SPIN05 | 0 | Specific Inpu | ut 5 (Non-Safety data) | | |
| SPIN06 | 0 | Specific Inpu | ut 6 (Non-Safety data) | | |
| SPIN07 | 0 | Specific Inpu | ut 7 (Non-Safety data) | | |
| SPIN08 | 0 | Specific Inpu | ut 8 (Non-Safety data) | | |

11Safety Function11.3Safety Logic Circuit

| Table 11-10: | Table 11-10: Correspondence between the SPIN and Specific Input | | | | | | | | | |
|---------------------|---|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|--|--|--|
| 40787 | 40786 | 40785 | 40784 | 40783 | 40782 | 40781 | 40780 | | | |
| Safety Logic | | Safety Logic | | | |
| Circuit Specific | Circuit Specific | Circuit Specific | Circuit Specific | Circuit Specific | Circuit Specific | Circuit Specific | Circuit Specific | | | |
| Input 8 | Input 7 | Input 6 | Input 5 | Input 4 | Input 3 | Input 2 | Input 1 | | | |
| SPIN08 | SPIN07 | SPIN06 | SPIN05 | SPIN04 | SPIN03 | SPIN02 | SPIN01 | | | |

| 40797 | 40796 | 40795 | 40794 | 40793 | 40792 | 40791 | 40790 |
|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Safety Logic |
| Circuit |
| Specific |
| Input 16 | Input 15 | Input 14 | Input 13 | Input 12 | Input 11 | Input 10 | Input 9 |
| SPIN16 | SPIN15 | SPIN14 | SPIN13 | SPIN12 | SPIN11 | SPIN10 | SPIN09 |

| 40807 | 40806 | 40805 | 40804 | 40803 | 40802 | 40801 | 40800 |
|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Safety Logic |
| Circuit |
| Specific |
| Input 24 | Input 23 | Input 22 | Input 21 | Input 20 | Input 19 | Input 18 | Input 17 |
| SPIN24 | SPIN23 | SPIN22 | SPIN21 | SPIN20 | SPIN19 | SPIN18 | SPIN17 |

| 40817 | 40816 | 40815 | 40814 | 40813 | 40812 | 40811 | 40810 |
|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Safety Logic |
| Circuit |
| Specific |
| Input 32 | Input 31 | Input 30 | Input 29 | Input 28 | Input 27 | Input 26 | Input 25 |
| SPIN32 | SPIN31 | SPIN30 | SPIN29 | SPIN28 | SPIN27 | SPIN26 | SPIN25 |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.5 Setting ON/OFF Status to the Input Signals

The meaning of the ON/OFF status of input signals used in the safety logic circuit can be switched. For example, the meaning of PPESP (Pendant Emergency Stop) is usually Active = Under Emergency Stop, Inactive = Normal. This can be changed to Active = Normal, Inactive = Under Emergency Stop.

1. Select {Setting} icon - {Status Setting}



2. The meaning of the Active/Inactive status of input signals used in the safety logic circuit can be inverted by pressing checkbox.

| Status S | setting | | | × |
|----------|--|--------|--------------------------------|------------------------------------|
| Signal | Name | Invert | Active | Inactive |
| GSIN | General Purpose Safety Input Signal | | OFF(release) | ON(short circuit) |
| FSBIN | Safety Input Signal | | OFF(release) | ON(short circuit) |
| PPDSW | Pendant Enable Switch | ~ | Not Grip(Servo OFF) | Grip |
| PPESP | Pendant Emergency Stop | | Under Emergency Stop | Normal |
| PBESP | Controller Emergency Stop | | Under Emergency Stop | Normal |
| EXESP | External Emergency Stop | | Under Emergency Stop | Normal |
| SAFF | Safety Fence of Safety Board | | Safety Fence is Open | Safety Fence is Close |
| HOLD | Pause(Hold) | | Pause(Hold) signal is input | Pause(Hold) signal is not input |

- 11 Safety Function
- 11.3 Safety Logic Circuit

| No. | Signal Name | Standard | Invert |
|-----|----------------|---|---|
| 1 | GSIN | GP safety input signal (ASF01) ● : OFF [release]/ ○ : ON [short circuit] | GP safety input signal (ASF01) ● : ON [short circuit]/ ○ : OFF [release] |
| 2 | FSBIN | GP safety input signal (ASF02 or ASF03) ● : OFF [release]/ ○ : ON [short circuit]) | GP safety input signal (ASF02 or ASU03) ● : ON [short circuit]/ ○ : OFF [release]) |
| 3 | PPDSW | Pendant enable switch signal ● : Grip/ ○ : Not grip (servo OFF) | Pendant enable switch signal ● : Not grip (servo OFF)/ ○ : Grip) |
| 4 | PPESP | Pendant Emergency Stop signal ● : Under Emergency Stop/ ○ : Normal) | Pendant Emergency Stop signal ● : Normal/ ○ : Under Emergency Stop) |
| 5 | PBESP | YRC Controller Emergency Stop signal ● : Under Emergency Stop/ ○ : Normal | YRC Controller Emergency Stop signal ● : Normal/ ○ : Under Emergency Stop |
| 6 | EXESP | External Emergency Stop input signal • : Under Emergency Stop/ • : Normal | External Emergency Stop input signal ● : Normal/ ○ : Under Emergency Stop |
| 7 | SAFF | Safety fence signal ● : Open (safeguarding opened)/ ○ : Close | Safety fence signal ● : Close/ ○ : Open (safeguarding opened)) |
| 8 | HOLD | Hold ● : ON (Hold signal is being input.)/ ○ : ON (Hold signal is not input.) | Hold ● : OFF (Hold signal is not input.)/ ○ : ON (Hold signal is being input.) |

- For example, when the EXESP signal is changed from "Normal Open" to "Normal Close", the mark "●" indicates the external Emergency Stop signal is in the normal state (Normal Close) and the mark "○" indicates the external Emergency Stop signal is being input (Normal Open).
- 4. Select {READBACK} and then {WRITE} to enable changed settings.



When the ON/OFF settings of the input signals are changed, outputting the signals that have been output normally may fail. This may lead to a serious accident.

After changing the ON/OFF settings of the input signals, be sure to confirm the safety logic circuit operates normally.



Cannot change the ON/OFF status setting of the signal which is used in System Safety Logic Circuit.

11-36

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.6 About Output Signals

11.3.6.1 Correspondence with Hard Wire

The following functions can be controlled either by hard-wire or by the safety logic circuit.

| Signal Name | Hard-Wire signal name | Explanation |
|--------------|-----------------------|---|
| S-EXDSW | None | • This is the external enable switch signal and functions only in teach mode. |
| | | • When both the S-EXDSW signal and the enable switch on the programming pendant are ON, the servo power can be turned ON. |
| | | • When the S-EXDSW signal is not used in the safety logic circuit, the safety circuit board regards this as the short-circuit status. |
| S-EXESP | EXESP | This is the external Emergency Stop input signal. |
| | | When the S-EXDSW signal is turned OFF, the signal performs the same control as the EXESP signal is turned OFF. |
| | | • The hard-wired EXESP signal is always monitored. When either the EXESP signal or the S-EXESP signal is OFF, the servo power supply is turned OFF. |
| | | • When the S-EXESP signal is not used in the safety logic circuit, the safety circuit board regards this as the short-circuit status. |
| S-FST | None | This is the full speed mode signal. Refer to chapter 11.3.6.3. |
| #n S-ONEN[x] | #n ONEN[x] | This signal controls the servo power supply for each control group. (n indicates the number of the ASF01 board and x is 1 to 4. 4 points are available for one ASF01 board.) When the S-ONEN signal is input, the signal performs the same control as ON ENABLE signal. When the hard-wired signal (ON ENABLE) is input, the servo power supply for the appropriate control group is turned OFF. When the signal is turned ON, the servo ON is enabled. |
| S-SAFF | SAFF | When the S-SAFF signal is turned OFF, the signal performs the same control as the SAFF signal. The hard-wired SAFF signal is always monitored. When either the SAFF signal or the S-SAFF signal is OFF, the servo power supply is turned OFF. |
| S-SVON_EN | None | For details, refer to "YRC1000 INSTRUCTIONS (RE-CTO-A221) chapter 8.26.13 "Enable Switch Link Function ". |
| MSOUT | None | This is the data to transfer the data created in the safety logic circuit to the functional safety function (optional). |

11-37

Table 11-12: Hard-Wire Signal Name



The signals which has been controlled by a hardware are also always monitored. Thus, the safety function, which turns OFF the servo power supply when the error is detected, is maintained.

11.3 Safety Logic Circuit

11.3.6.2 Display of the Message on the Pendant

When the Robot's operation is stopped by one of these signals, the message on the pendant will recognize and display which signal (i.e. hard-wired signal of Safety Logic Circuit signal) stopped the Robot.

Table 11-13: Pendant Message

| Signal Name | Message on the Pendant |
|--------------|---|
| None | - |
| S-EXDSW | EXDSW signal is OFF.(Safety Logical Circuit) |
| EXESP | Robot is stopped by external Emergency Stop. |
| S-EXESP | Robot is stopped by external Emergency Stop. (Safety Logical Circuit) |
| None | - |
| S-FST | Full-speed test mode. (Safety Logical Circuit) |
| #n ONEN[x] | Servo ON enable signal (ON-EN) is OFF. |
| #n S-ONEN[x] | Servo ON enable signal (ON-EN) is OFF. (Safety Logical Circuit) |
| SAFF | Safety guard is open. |
| S-SAFF | Safety guard is open. (Safety Logical Circuit) |
| None | - |
| S-SVON_EN | Servo ON enable signal is OFF. (Safety Logical Circuit) |



- The upper line: the message when the manipulator is stopped by the input of the hard-wired signal.
- The lower line: the message when the manipulator is stopped by the signals input from the safety logic circuit.
- None: The appropriate signals do not exist.

11-38

11.3 Safety Logic Circuit

11.3.6.3 Full Speed Mode



When using the full-speed test function, the Robot will move at a high speed. Thus, make sure the operator is in a secure place outside the Robot's operating range from where he/she can visually check the Robot's movement and perform operations by using the Smart Pendant from that place.

Full speed mode can be used to perform a test run or a forward/backward operation of the job at the full taught speed during the MANUAL (TEACH) mode.

When the S-FST signal is turned ON during the MANUAL (TEACH) mode, full speed mode is activated.

When the full speed mode is selected, the servo power is turned OFF, and then the manual speed setting is automatically switched to the inching mode. In the same way, when the Enable Switch is released in full speed mode, the manual speed setting is automatically switched to inching mode.

The operation speed while the mode is set to full speed test mode is specified according to the manual speed setting per table 11-14.

| Manual speed operation speed limit (initial value) | | Parameter (unit: 0.01%) | | |
|--|-----------------------|----------------------------------|---------------------|--|
| Inching | 20% | S1CxG60 (initial value: 2000) | Limited to 250 mm/s | |
| Low | 50% | S1CxG61 (initial value: 5000) | | |
| Mid | 75% | S1CxG62 (initial value: 7500) | | |
| High | 100% (fixed value) | - | | |

Table 11-14: Manual Speed Settings



The operation speed limit values in the above table are the percentages with respect to the manipulator's maximum speed, not with respect to the taught speed. These are specified in order to control the operation speed so that it does not exceed the manipulator's maximum speed during a test run or a forward/backward operation.

11.3 Safety Logic Circuit

11.3.7 General-Purpose Safety Output Monitoring Signal

General-Purpose Safety Output Monitoring Signal is used for detecting error (e.g. wire sticking, etc.) by monitoring the feedback signal of the devices (safety relay, contactor, etc.) driven by the General Purpose Safety output signal (GSOUT, FSBOUT).

When feedback signal is not monitored, error (wire sticking, etc.) of the devices (safety relay, contactor, etc.) driven by the General Purpose Safety output signal (GSOUT, FSBOUT) is not detected. Perform the error detection (signal mismatch) with the receiving peripheral devices (Safety PLC, etc.).

Supports the monitoring signal by using the safety logic circuit instead of the dedicated connection terminal.

| | If the values of the functional safety general-purpose outpusing signal and the general-purpose safety output monitoring signal are judged as NG for 500 ms or more, the following alarm occurs: | | | | |
|------|---|--|----------------|--|--|
| | When the GSOUT signal is NG Alarm 4767: M-SAF GENERAL OUT FB DIAG. ERROR | | | | |
| | • When the FSBOU ⁻ Alarm 4768: M-SA | T signal is NG F GENERAL OUT F | B DIAG. ERROR2 | | |
| NOTE | For monitoring of the contact point B, the judgment is made as follows. | | | | |
| | Output value of the general-purpose safety output signal (GSOUT, FSBOUT) | Input value of the general-purpose safety output monitoring signal (GSEDM, XEDM) | Judgement | | |
| | OFF | Close | Ok | | |
| | OFF | Open | NG | | |
| | ON | Close | NG | | |
| | ON | Open | OK | | |

11.3.7.1 Activate Signals

To activate General Purpose Safety Output Monitoring signals, Software Pendant is required.

For more information on the Software Pendant, refer to chapter 12 "Software Pendant".

11-40

For more information to set the General Purpose Safety Output Monitoring signals, refer to chapter 11.3.7.2.

11.3 Safety Logic Circuit

11.3.7.2 Correspondence between General Purpose Output Signals and Monitoring Signals

Table 11-15: Correspondence Between General Purpose Output Signals and Monitoring Signals.

| General-Purpose Safety Output Signal | General-purpose safety output monitoring signal (Feedback signal) | |
|---|---|--|
| GSOUT1 | S-GSEDM1 | |
| GSOUT2 | S-GSEDM2 | |

The following signals can be used only in the system where the safety I/O expansion board (optional) is enabled. Then number of signals depends on the circuit board.

 Table 11-16: Correspondence Between General Purpose Output Signals

 and Monitoring Signals with Safety IO Expansion Board

| General-Purpose Safety Output Signal | General-purpose safety output monitoring signal (Feedback signal) | |
|---|---|--|
| FSBOUT1 (XOUT1) | S-XEDM1 | |
| FSBOUT2 (XOUT2) | S-XEDM2 | |
| FSBOUT3 (XOUT3) | S-XEDM3 | |
| FSBOUT4 (XOUT4) | S-XEDM4 | |
| FSBOUT5 (XOUT5) | S-XEDM5 | |
| FSBOUT6 (XOUT6) | S-XEDM6 | |
| FSBOUT7 (XOUT7) | S-XEDM7 | |
| FSBOUT8 (XOUT8) | S-XEDM8 | |
| FSBOUT9 (XOUT9) | S-XEDM9 | |
| FSBOUT10 (XOUT10) | S-XEDM10 | |
| FSBOUT11 (XOUT11) | S-XEDM11 | |
| FSBOUT12 (XOUT12) | S-XEDM12 | |
| FSBOUT13 (XOUT13) | S-XEDM13 | |
| FSBOUT14 (XOUT14) | S-XEDM14 | |
| FSBOUT15 (XOUT15) | S-XEDM15 | |
| FSBOUT16 (XOUT16) | S-XEDM16 | |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.7.3 Example of Setting for Monitoring Signals

Pendant Emergency Stop Signal (PPESP) is output to General Purpose Output signal1 (GSOUT1, FSBOUT1). To monitor these signals, use General Purpose Input signals (GSIN1, FSBIN01).

Example of this setting is as following.

11-42



- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.8 Safety Data Monitoring


This function is works only in YRC1000.

By using the signals for the safety data monitoring (CSCFG01, CSCFG02, CSCFG03, CSCFG04, SICFGTRG), the safety data (the safety-related parameter, the machine safety data file, and the functional safety data file) can be monitored to detect a change.

Monitoring is performed by comparing the CRC of the safety data, and if changed, that can be notified by the safety output.

When GSIN01 is the stored CRC updating trigger, the example of the monitoring results output to MS-OUT01 - 04 is shown below.

- 1. Editing the safety logic circuit
 - Correspond GSIN01 to the updating trigger SICFGTRG, and MSOUT01 - 04 to CSCFG01 - 04.



- 2. Write the Safety Logic Circuit
 - After editing, select {WRITE}.

11-43

 When the transfer is done correctly, the confirmation dialog appears. Then select {YES}.




Since the CRC for the safety data monitoring are stored by detecting falling edge of SICFGTRG(CRC updating trigger), the monitoring results are turned OFF (O: abnormal monitoring) until the stored CRC is updated by this signal.


11.3 Safety Logic Circuit

- 3. Input of the stored CRC updating trigger
 - When the stored CRC updating trigger (signal name: SICFGTRG GSIN01 is set this time) is turned ON (●) to OFF(○), the stored CRC is updated.
 - When the stored CRC is updated, the monitoring result is turned ON (•: normal monitoring) until the safety data is changed.
 - The monitoring result (signal name: CSCFG01 04) can be output to any signal by using the safety logic circuit.

The monitoring result can be output to the external device by using the safety output.





- 11 Safety Function
- 11.3 Safety Logic Circuit
- 4. Monitoring the safety data change
 - When any functional safety data file is changed, the following status appears.
 - Both CSCGF03 shown the monitoring result of the functional safety data file and CSCFG04 shown the monitoring result of changing either safety data (if any) will be turned OFF (O: abnormal monitoring).



- Also when any safety related parameter is changed, both CSCFG01 and CSCFG04 will be turned OFF (O: abnormal monitoring).
- Also when any machine safety data file is changed, both CSCFG02 and CSCFG04 will be turned OFF (O: abnormal monitoring).

- 11 Safety Function
- 11.3 Safety Logic Circuit
 - When the CRC updating trigger (signal name: SICFGTRG GSIN01 is set this time) is turned ON (●) to OFF(○) again, the stored CRC is updated and the monitoring result is turned ON (●: normal monitoring).





- 11 Safety Function
- 11.3 Safety Logic Circuit

The safety parameter and the data file for monitoring are shown below.

| Table 11-17: Safety-related parameter monitored by CSCFG1 |
|---|
| These files are monitored when functional safety function is enabled. |

| File | File Name for External Memory Device |
|------------------------------------|---|
| Function definition parameter | FD.PRM |
| System definition parameter | SD.PRM |
| Servo parameter | SV.PRM |
| Servo motor parameter | SVM.PRM |
| Robot matching parameter | RC.PRM |
| Coordinate home position parameter | RO.PRM |
| Motion function parameter | MF.PRM |
| Robot control expand parameter | RE.PRM |
| Safety function parameter | FMS.PRM |
| System matching parameter | SC.PRM |

Table 11-18: Machine Safety Data File Monitored by CSCFG2

| File | File Name for External Memory Device |
|----------------------|---|
| Safety Logic Circuit | YSFLOGIC.DAT |

Table 11-19: Functional safety data file monitored by CSCFG3. These files are monitored when functional safety function is enabled.

| File | File Name for External Memory Device |
|--------------------------------|---|
| Tool data | TOOL.CND |
| Tool interfere data | TOOLINTF.DAT |
| Home position calibrating data | ABSO.DAT |
| Axis range limit data | AXRNGLMT.DAT |
| Axis speed monitor data | AXSPDMON.DAT |
| Robot range limit data | RBRNGLMT.DAT |
| Speed limit data | SPDLMT.DAT |
| Tool angle monitor data | TLANGMON.DAT |
| Tool change monitor data | TLCHGMON.DAT |

- 11 Safety Function
- 11.3 Safety Logic Circuit

11.3.9 Example of Safety Logic Circuit

The followings are application examples that use safety logic circuit.


11.3.9.1 Example1 (AND)

This is the example of the setting to output from the GP safety output signal1 (#1 FSBOUT1) while the GP safety input signal1 (#1 FSBIN1) and 2 (#2 FSBIN2) are ON.


1. Create the following Safety Logic Circuit.



2. The timing chart is as shown below:



- 3. Verifying the safety logic circuit.
 - Switch ON the GP safety signal "1" and "2". General Purpose Safety Output signal1 becomes ON.




- 11 Safety Function
- 11.3 Safety Logic Circuit


11.3.9.2 Example 2 (OR)

This is the example of the setting to output from the GP safety output signal1 (#1 FSBOUT1) while either status of the programming pendant Emergency Stop (PPESP), safety fence (SAFF) or external Emergency Stop (EXESP) is stopped.

1. Create the following Safety Logic Circuit.



2. The timing chart is as shown below:



ON DELAY TIM1 reaches the specifie so that #1 GSOUT1 is ON

- 11 Safety Function
- 11.3 Safety Logic Circuit
- 3. Verifying the safety logic circuit.
 - When either the pendant Emergency Stop, safety fence, or the external Emergency Stop is input, General Purpose Safety Output Signal 1 becomes ON.




11.3.9.3 Example3 (Pulse)


The one-second one-shot output signal is created by the safety logic circuit. In the following example, the GP safety output signal (#1 GSOUT1) is ON for one second.

1. Create the following Safety Logic Circuit.





2. The timing chart is as shown below:



- 11 Safety Function
- 11.3 Safety Logic Circuit
- Verifying the safety logic circuit. When #1 GSIN 1 signal is turned ON, #1 GSOUT 1 is ON for one second.



When using the "Detect OFF \rightarrow ON" or "Detect ON \rightarrow ON" instruction, the signal status turns to ON only for 2 ms while the conditions are satisfied.

Because pendant display update is slower than safety logic circuit, seeing the changing status in the display is difficult, or it may be displayed longer than the actual ON time.

11.3.9.4 Example4 (ON Delay)


In the following example, one second after the emergency button of the pendant (PPESP) is pressed and the GP safety input signal 1 is OFF, the GP safety output signal1 (#1 GSOUT1) is turned ON.

1. Create the following Safety Logic Circuit.

11-51



2. The time chart is as following.



PPESP is ON and NOT #1 GSIN1 is ON, and ON DELAY TIM1 reaches the specified value so that #1 GSOUT1 is ON

- 11 Safety Function
- 11.3 Safety Logic Circuit
- 3. Verifying the safety logic circuit.
 - Confirm that the signal becomes ON when pressing the pendant Emergency Stop and switching the GP safety signal ON. GP safety output signal 1 becomes ON after one second has passed.



11.3.9.5 Example 5 (Decelerate and Stop the Robot)

In the following example, when the GP safety input signal1 (#1 GSIN1) is ON under MANUAL (TEACH) mode, the Robot decelerates and stops its operation.

1. Create the following Safety Logic Circuit.



2. The time chart is as following.

| MODE | TEACH | |
|----------------------------|-------|---|
| MODE | PLAY | |
| #1 GSIN1 | ON | |
| #100101 | OFF | |
| Decelerating processing | 011 | #1 GSIN1 : ON |
| | OFF — | Starts decelerating processing Ends decelerating processing |
| Servo ON | | |
| | | l #1 GSIN1 is ON under the teach mode so that the servo will be turned OFF after the decelerating processing |

- 3. Verifying the safety logic circuit.
 - Change the mode to MANUAL (TEACH) mode, and turn the servo ON. After that, when the GP safety signal 1 is turned ON, SFOFF CAT1 becomes ON, and the Robot decelerates and stops its operation.



- 11 Safety Function
- 11.3 Safety Logic Circuit

If the manipulator stops its operation by the safety logic circuit, the message "Robot is stopped by safety logic circuit" is shown on the message area of the pendant.

Controller Message Robot is stopped by safety logic circuit [Hold/ESP:21]

- For the safety logic circuit of the YRC Controller, even if the Robot deceleration to a stop (SVOFF CAT1) is turned ON, the robot stops its operation instantly without decelerating in MANUAL (TEACH) mode. Under the AUTOMATIC (PLAY) mode, if the manipulator deceleration to a stop (SVOFF CAT1) is turned ON, the Robot decelerates and stops its operation.
- When the Robot is stopped by the safety logic circuit signal, "Robot is stopped by safety logic circuit" is shown on the message area of the smart pendant. The control status signal #80343(Robot stopped by safety logic circuit) is turned ON.
- 11.3.9.6 Example 6 (Temporarily Disable PFL for Human Collaborative Robots)


NOT

YASKAWA recommends temporarily disabling PFL to perform certain operations to improve usability/performance. Example scenarios could include:

- Moving the Robot at full speed
- Moving the Robot near singular positions (see Chapter 11.6.3)
- When the Robot cannot be operated due to an error caused by recurring external force monitor setting violations
- Automatic estimation of tool load

Follow the steps below to temporarily disable PFL for a collaborative system in its factory state (i.e. prior to user additions/edits).

- 1. Navigate to {Safety Settings} → {Safety Logic Circuit}
- Find the line that contains an output (right side of screen) set to "MSOUT54 (Collaborative Operation Request). (First line at the top of the circuit for system in its factory state.)
 - Select the left-most gate in this line (gate = FSBIN01 in the factory state)



385 of 493

- 11 Safety Function
- 11.3 Safety Logic Circuit
- 3. Select the input relay and reverse its Input Type (i.e. change from Normally Open to Normally Closed) in the Details panel to turn OFF the MSOUT54 request signal.

| Details | | | \sim |
|-------------------------------|---------------------------------|------------|--------|
| Input Type Normally Open - | ~) — | | (1 |
| Signal | Name | | |
| FSBIN01 | Safety Boar | rd Input 1 | |

 Perform Readback → Write process to save changes. MSOUT54 should now be disabled (see below), signifying that PFL is disabled. The green light on the Robot's wrist should be OFF.



- 5. Perform *desired operation* with PFL disabled.
- 6. Restore PFL to its original state once the desired operation(s) are complete!



- 11 Safety Function
- 11.4 Functional Safety Functions

11.4 Functional Safety Functions

11.4.1 Outline

By using the functional safety function, the position and speed of the Robot and the posture of its tool are monitored.

The power supply to the motor is suspended and the Robot is completely stopped when an error is detected on safety monitoring data.

With this function, the following items can be improved:

- improving the safety of the Robot's motion
- minimizing the equipment layout area where the manipulators are installed

11.4.2 List of Safety Functions

There are six different functional safety functions for monitoring purposes.

1 Robot Range Limit

Monitors the manipulator arm or its tool to be inside the designated safety area.

② Axis Range Limit

Monitors each axis angle to be equal to or inside the designated safety area.

③ Speed Limit

Monitors the speed of manipulator TCP (Tool Center Point) and its FCP (Flange Center Point) when the Robot control group is monitored.

④ Axis Speed Monitor

Monitors each axis speed to be equal or slower than the designated speed.

5 Tool Angle Monitor

Monitors the manipulator tool angle to be inside the range of limited angle when the angle is centered on the designated standard posture.

6 Tool Change Monitor

Monitors the tool file used in the functional safety function to be consistent with the user specified tool file.

These safety functions conform to the following safety standards.

- EN ISO 13849-1: 2015 Cat.3 / PL d
- EN 62061(IEC 61508) SIL CL2

If the Robot has the collaborative operation function, the following additional function can also be used.

⑦ External Force Monitor

Monitors the external force applied to the manipulator's TCP and each joint axis by using PFL function.

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.3 Safety Functions List View

11.4.3.1 List View

Safety functions list view shows the safety function list which is set.

To show this list, select {MENU} \rightarrow {Safety Function} \rightarrow {Safety Functions}.

| ← Safety Function Settings | | Search by na | me | Q |
|--------------------------------|----------------------------|----------------|--------|---|
| 3)Name 🛊 | (4) Function Type - No. | 5 Condition \$ | Result | 6 |
| Sample Custom | Robot Range Limit - 01 | Always ON | OIn | Û |
| Sample Cubic | Robot Range Limit - 02 | Signal | 0- | |
| Sample Plane | Robot Range Limit - 03 | Signal | 0- | |
| Sample SpeedLimit | Speed Limit - 01 | Always ON | | |
| Manual(Teach) Mode Speed Limit | Speed Limit - 33 | | | |
| Sample AxisSpeedMonitor | Axis Speed Monitor - 01 | Signal | | |
| Sample AxisSpeedMonitor | Axis Speed Monitor - 02 | Signal | | |
| Sample AxisSpeedMonitor | Axis Speed Monitor - 32 | Signal | | |
| Sample Force Monitor | External Force Monitor - 0 | 1 Always OFF | | |

(1) + NEW SETTING

Create new safety setting.

② Search by Name

Search the setting in the list by name.

③ Name

It shows name of the setting. It can be sorted by name.

④ ID Number

It shows ID Number of the setting. It can be sorted by ID Number.

⑤ Condition

It shows Enable Condition of the setting. It can be sorted by Enable Condition.

it can be solled by Enable Condition.

The color of Enable Condition is changed as monitoring state. Correspondence between the color and monitoring state is as following table.

| Color | Monitoring State |
|--------|---|
| Gray | Monitoring is always OFF. |
| Black | Monitoring is OFF. It does not match as the condition of safety input signal. Or the setting is temporary disabled. |
| Orange | Monitoring is ON. |

- 11 Safety Function
- 11.4 Functional Safety Functions

6 Result

It shows the monitoring result.

| Color | Monitoring Result |
|-------|-------------------|
| White | Not safe |
| Green | Safe |

11.4.3.2 Create New Setting

The procedure to create new safety setting is as following.

1. Press {+ NEW SETTING}.

| ← Safety Function Settings | | Search by na | me Q |
|----------------------------|------------------------|--------------|---------|
| Name 🛊 | Function Type - No. | Condition \$ | Result |
| Sample Custom | Robot Range Limit - 01 | Always ON | () In 🗍 |
| Sample Cubic | Robot Range Limit - 02 | Signal | 0- |

- 11 Safety Function
- 11.4 Functional Safety Functions

2. Select the safety setting type, and press {CREATE NEW SETTING}.

| Safety Setting Types | | \times |
|---------------------------|--|----------|
| Select and Create a New | Setting | |
| Limit Motion | | |
| ROBOT RANGE LIMIT | Monitors the manipulator arm or its tool to be in the designated safety area. | |
| AXIS RANGE LIMIT | Monitors each axis angle to be equal to or in the designated safety area. | |
| Limit/Monitor Speed | | |
| SPEED LIMIT | Monitors the speed of manipulator TCP (Tool Center Point) and its FCP (Flange Center Point) when the robot control group is monitored. | |
| AXIS SPEED MONITOR | Monitors each axis speed to be equal or slower than the designated speed. | |
| Monitor Force | | |
| EXTERNAL FORCE MONITOR | Monitors external force to be equal or lower than the designated force. | |
| Monitor Tool | | |
| TOOL ANGLE MONITOR | Monitors the manipulator tool angle to be inside the range of limited angle when the angle is centered on the designated standard posture. | |
| TOOL CHANGE MONITOR | Monitors the tool file used in the functional safety function to be consistent with the user specified tool file. | |
| | CANCEL CREATE NEW SETTING | |
| | | |
| | | |
| | | |
| | | |

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.3.3 Delete Setting

The procedure to delete safety setting is as following.

- 1. Go to {MENU} \rightarrow {Safety Settings} \rightarrow {Safety Functions}.
- 2. Select the safety setting from the Safety Functions List View.
- 3. Press Trash Can icon.
 - The setting will readback.

| ← Safety Function Settings | + NEW SETTING | Search by na | me | ۹ |
|----------------------------|------------------------|--------------|--------|---|
| Name 💠 | Function Type - No. | Condition \$ | Result | |
| Sample Custom | Robot Range Limit - 01 | Always ON | ⊖In | Û |
| Sample Cubic | Robot Range Limit - 02 | Signal | 0- | |

- 4. Confirm that the Enable condition is changed to "Always OFF", and press {DELETE}.
 - Pop dialog shows.

| Robot Range Limit #1: | | X CANCEL | DELETE |
|-----------------------|----------------------------------|----------|----------|
| Name | Enable Condition Always OFF ~ | | ` |
| | | | |

5. Press {DELETE}.

| Confirm Deletion | 1? |
|------------------|--|
| | want to delete this setting? nit #1: Sample Custom" |
| | CANCEL OF DELETE |

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.4 Robot Range Limit

Robot Range Limit function is a function which monitors robot position using software.

Robot Range Limit define the Robot range of motion with 3 shapes as following, and then monitors the Robot's arm or its tool to be inside the range of motion.

- 1. Custom
- 2. Cubic
- 3. Plane

While Robot is in operation, based on the Robot motion speed, this function calculates the coasting value in case of the immediate stop by the alarm, and then, including this value, this function monitors the safety range. With this monitoring operation, the axes would not exceed the safety range even if a motion error is detected.

In case an error is detected, the power supply to the motor is stopped using the machine safety and the error is notified using an alarm.

Follow the procedures below when starting the Robot range limit function.

- Set the Tool File. (Before using this function, execute tool file setting by referring to chapter 6.1 "Tool Settings")
- Set the Tool Interference File. (Before using this function, execute tool interference file setting by referring to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576)".)
- 3. Set the Robot Range Limit function.
- 4. Confirm the safety range.
- 5. Start the Robot range limit function.

11-60

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.4.1 Condition Setting

Contents are as following.

| Robot R | ange Limit # | 1: Sample Cus | tom | | | | | | |
|---------------------------------------|---------------|-------------------------|-----|----------|----------------|----------|-----------|-----------------|------------|
| Name | Custom | | | ~ | able C ways | ondition | | | <i>(i)</i> |
| Action Alarm Shape Ty Custom | Ype Monit | or Type Robot Inside | (| Ref. | Coord. | | R | | |
| Point | x | Y | | | or. | | *+ | P P*+ | |
| 1 | 1000 mm | 0 mm | 0 | \oplus | Û | 1 | | | |
| 2 | 924 mm | 383 mm | 0 | \oplus | Û | | | Define Z value | |
| 3 | 707 mm | 707 mm | 0 | \oplus | Û | | Z Top | 1000 mm | |
| 4 | 383 mm | 924 mm | 0 | \oplus | Û | | Z Bottom | -1000 mm | |
| 5 | 0 mm | 1000 mm | 0 | \oplus | Û | | 6 Setting | g CPU Load: 16% | |
| 6 | -383 mm | 924 mm | 0 | \oplus | Û | | | | |
| Advance | ed Settings | | | | | | | | ~ |
| Setting | Activation Si | gnal | | | | | | | (i |
| 7 signa | Signal | | ~ | Statu | JS | Condi | tion | | |
| 0 | | EW SIGNAL | | | | | | | |
| Output \$ | Signal | | | | | | | | |
| 0 | Signal | | | State | s | | | | |
| 8 sig | nal | | ~ | 0 | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | Robot Jog Pane | el / |

① Name

Set Name of the setting.

② Enable Condition

Set Enable Condition of the setting.

In order for the change to take effect, it is necessary to complete WRITE.

| Value | Description | | | | |
|------------|---|--|--|--|--|
| Always OFF | Always disable the monitoring by the setting. | | | | |
| Always ON | Always enable the monitoring by the setting. | | | | |
| Signal | Change the monitoring state by referencing the safety input signal. For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions". | | | | |

- 11 Safety Function
- 11.4 Functional Safety Functions

③ Action

Select alarm or not alarm (Status) to the monitoring result of the setting.

| Value | Description | | | | | |
|--------|---|--|--|--|--|--|
| Alarm | Servo is turned OFF with an alarm when an error occurs under the monitoring condition. | | | | | |
| Status | Although monitoring is performed under the condition, the alarm does not occur, and the servo is not turned OFF even if a monitoring error occurred. The monitoring result can be obtained by the safety output signal. | | | | | |



When "Status" is set to Action, the functional safety function does not stop the manipulator operation even if a monitoring error is detected in the object file. In this regard, before operating the manipulator, sufficiently consider possible risks attributed to the no alarm operation (risk assessment) and take necessary safety measures.

④ Shape Type

| Value | Description |
|--------|--|
| Custom | Specifies the monitoring volume as a polygon on the X-Y plane with a height in Z-axis direction. |
| Cubic | Specifies the monitoring volume as a polygon on the X-Y plane with a height in Z-axis direction. |
| Plane | Specifies the monitoring area as a plane along either XY, YZ or ZX coordinates. |

⑤ Ref. Coord.

Specifies the reference coordinate for the shape.

| Value | Description |
|-------|---|
| Robot | Define the monitoring area on the Robot coordinate system. |
| World | Define the monitoring area on the World (Base) coordinate system. |

6 Estimated CPU Load

Displays the rate of CPU load for monitoring.

11-62

⑦ Setting Activation Signal

Specify the safety input signal for enable setting when "Enable Condition" is "Signal".

For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions".

® Output Signal

Specify the safety output signal for output the monitoring result.


- 11 Safety Function
- 11.4 Functional Safety Functions

| Monitoring State | Monitoring Result | Output | |
|---------------------|--|--------|--|
| Disabled | | OFF | |
| Enabled | Object manipulator or tool is inside the safety range. | | |
| | Object manipulator or tool is detected to be outside the safety range | | |
| | For the object manipulator or tool, the stop position to which coasting value is included are detected to be in error status when moving close to the border of the safety. | OFF | |

Signal output as following.

Robot Range Limit as Custom Shape

If Custom is selected in Shape Type, it specifies boundaries within which the Robot moves or boundaries that prevent Robot from entering with polygon on the X-Y plane with a height in Z-axis direction.



| Name Sample | e Custom | | | | able Condit ways ON | ion V | | () |
|---------------------|-----------------------------|---------------------|---|-------------|------------------------|----------|---------|----------------|
| Action Alarm | <u> </u> | | | | | | - | |
| 1)Shape T Custon | iype ②Monitor n 🗸 Keep R | Type obot Inside | ~ | Ref. Rob | Coord. | | D | |
| 3 Point | x | Y | | | | ~ | + | |
| 1 | 1000 mm | 0 mm | 0 | \oplus | Ĉ | | | |
| 2 | 924 mm | 383 mm | 0 | \oplus | Ĉ | | ~ | Define Z value |
| 3 | 707 mm | 707 mm | 0 | \oplus | Ô | 4 | Z Top | 1000 mm |
| 4 | 383 mm | 924 mm | 0 | \oplus | Ĉ | ZI | Bottom | -1000 mm |
| 5 | 0 mm | 1000 mm | 0 | \oplus | Ĉ | | Setting | CPU Load: 16% |
| 6 | -383 mm | 924 mm | 0 | \oplus | Ĵ | | | |

- 11 Safety Function
- 11.4 Functional Safety Functions

① Shape Type

To specifies the monitoring volume as a custom, select Custom in Shape Type.

2 Monitor Type

When selecting the {Keep Robot Inside}, the polygon can be specified by 3 to 16 points. The space inside the area is defined as the safety range. When the result of the monitoring is safe, the object arm and the tool of the manipulator are kept inside the safety range. When selecting the {Keep Robot Outside}, the polygon can be specified by 3 to 4 points. The space outside the area is defined as the safety range. When the result of the monitoring is safe, the object arm and tool of the manipulator are kept outside the range.

The area specified should be convex.

③ Point (X,Y)

Specifies the points on the X-Y plane to define the polygon. The points are connected in ascending order like

Point 1 \rightarrow Point2 \rightarrow Point3 \rightarrow \rightarrow Point1

And the line of these points becomes the wall of the range of motion. Take this procedures into consideration before specifying the points.

{ ? }: Set the point as the current TCP position.

 $\{ \oplus \}$: Add new point before selected point.

{ 📋 }: Delete selected point.


{NEW POINT}: Add new point after the list.

④ Z Top, Z Bottom

Specifies the height of the custom shape. If it is not defined, the height in the Z-axis direction is set to infinite (polygon prism of infinite height).

Robot Range Limit as Cubic Shape


If Cubic is selected in Shape Type, it specifies boundaries within which the Robot moves or boundaries that prevent Robot from entering with cuboid whose diagonal line is specified by the points.



POINT 2

396 of 493

- 11 Safety Function
- 11.4 Functional Safety Functions



① Shape Type

To specifies the monitoring volume as a cubic, select Cubic in Shape Type.

② Monitor Type

When selecting the {Keep Robot Inside}, the space inside the area is defined as the safety range. When the result of the monitoring is safe, the object arm and the tool of the manipulator are kept inside the safety range. When selecting the {Keep Robot Outside}, the space outside the area is defined as the safety range. When the result of the monitoring is safe, the object arm and tool of the manipulator are kept outside the range. The area specified should be convex.

③ Point (X, Y, Z)

Specify two points on an object coordinates system, and then a cuboid is created whose diagonal line is specified by the points.

In case any two point values input in either X, Y or Z are overlapped, the setting is regarded as an error.


 $\{\bigcirc\}$: Set the point as the current TCP position.

11 Safety Function

11.4 Functional Safety Functions

Robot Range Limit as Plane Shape

If Plane is selected in Shape Type, it specifies the monitoring area as a plane along either XY, YZ or ZX coordinates.



| Name | | | Enable Con | | (i) |
|-----------------|----------------|--------------------|-------------|------|----------------------|
| | e Plane | | Signal | ~ | |
| Action Alarm | ~ | | | | |
| () Shape T | Type ②Plane Ty | ре | Ref. Coord. | - 62 | |
| Plane | | dicular to X-Y 🗸 🗸 | Robot | ~ | |
| 3 Point | x | Y | | | S Y |
| 1 | 100 mm | 200 mm 📎 | | - 62 | 2° |
| 2 | -100 mm | -200 mm 📎 | | - 10 | |
| | | | | | +X 🗸 |
| | | | | | |
| | | | | | Setting CPU Load: 4% |
| | | | | | |
| | | | | | |

① Shape Type

To specifies the monitoring volume as a Plane, select Plane in Shape Type.

- 11 Safety Function
- 11.4 Functional Safety Functions

2 Plane Type

Specifies the plane type to make.

| Value | Description |
|-------------------------|--|
| Perpendicular to X-Y | Draw a line on either X-Y coordinate plane, and then, along the line, set a plane (wall) in the vertical direction. |
| Perpendicular to Y-Z | Draw a line on either Y-Z coordinate plane, and then, along the line, set a plane (wall) in the vertical direction. |
| Perpendicular to X-Z | Draw a line on either X-Z coordinate plane, and then, along the line, set a plane (wall) in the vertical direction. |

3 Point (X, Y) (Y, Z) (X, Z)

Specify two points to draw a straight line on a coordinate plane. In case the coordinates of these two points overlapped, the setting is regarded as an error.

 $\{\bigcirc\}$: Set the point as the current TCP position.

11.4.4.2 Confirming the Safety Range and Starting the Robot Range Limit

If "Always ON" or "Signal" for Enable Condition is selected, confirm that the monitoring works correctly in the safety range as the setting.

When confirming the safety range, move the axes of the object group into the safety range, and then enable the monitoring of the setting. If "Signal" for Enable Condition is selected, enable the setting by selecting input signals.

Move the axes of the object group to confirm that they stop within the specified safety range.

Confirm by jogging whether the set area is correct.



In the functional safety function, the range of motion is monitored by calculating the coasting values of the manipulator. For this reason, the manipulator stops just before exceeding the safety range in case it moves to the teaching point near the safety range.

In case "Alarm 4783: F-SAFE ROBOT RANGE LIMIT INTF" or "Alarm 4784: ROBOT RANGE LIMIT INTF" appeared

<Cause>

The positions of the Robot and the tool are out of its safety area, or an axis range limit error is detected when the manipulator started moving.

Inside the Robot range limit, taking the feedback speed or the coasting value which were detected by the functional safety function, into consideration, calculation of the movement is executed so that the manipulator would not come out from the safety range. For this reason, when a manipulator moves close to the border of the range, this alarm occurs because the higher its teaching speed becomes, the more its coasting value increases.

<Countermeasure>

Check that the safety range is appropriately set.

Execute the teaching operation so that the manipulator does not approach close to the border of the range.

Decrease the teaching speed near the border of the range.




11 Safety Function

11.4 Functional Safety Functions


Confirming for Custom or Cubic


If the {Keep Robot Inside} is selected for Monitor Type, move the manipulator inside the specified four walls and check that it stops just in front of the wall. In case the area is not a cuboid, check that it stops just in front of all walls.

Fig. 11-3: Confirming for {Keep Robot Inside}



If the {Keep Robot Outside} is selected for Monitor Type, to the walls, move the manipulator toward all the direction where it can make approach and check that it stops just in front of each wall (test each wall).






- 11 Safety Function
- 11.4 Functional Safety Functions

Confirming for Plane

To the specified plane, make the manipulator approach to it. And confirm that the manipulator stops at any three points on the plane.


Fig. 11-5: Confirming for Plane



11.4.4.3 Switch the Monitoring Area


When switching the monitoring area using the safety signal input, execute the switching operation after moving the manipulator to be inside the next monitoring area and stopping it completely.

When executing inside the range monitoring at multiple ranges, set the overlapped range and execute the switching only when the manipulator is inside the overlapped area.



- 11 Safety Function
- 11.4 Functional Safety Functions

When monitoring operation is validated to multiple areas at a time, the overlapped area is regarded as the safety range.







Fig. 11-7: Simultaneous Monitoring: Multiple Areas (Inside the Monitoring Area + Outside the Monitoring Area)



- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.4.4 Estimated CPU Load

The Robot range limit function can, to some extent, freely define the shape as its range of motion. However, the time period needed for processing the monitoring varies depending on the shape or the method of monitoring.

Regard the allocated processing time for Robot range limit function as 100%. The ratio of necessary processing time for the area created in the object area is indicated to this item.

Followings are processing time for each area created in the object area.

| Shape Type | Monitor Type | Number of Points | CPU Load |
|------------|-----------------------|------------------|----------|
| Custom | Keep Robot | 4 | 10% |
| | Inside | 8 | 12% |
| | | 16 | 16% |
| | Keep Robot | 3 | 7% |
| | Outside | 4 | 8% |
| Cubic | Keep Robot Inside | - | 9% |
| | Keep Robot Outside | - | 6% |
| Plane | - | - | 4% |

Displays the total {Estimated CPU Load} of the settings for which monitoring is enabled. Total CPU Load should be below 100%.

| Total CPU Load: 0 | % Setting CPU Load: 16% | | |
|----------------------|-------------------------------------|-------------------------------|------------|
| Robot Range I | Limit #1: Sample Custom | | |
| Name Sample Custo | m | Enable Condition Always ON ~ | <i>(i)</i> |
| Action Alarm ~ | | | |
| Shape Type Custom ~ | Monitor Type Keep Robot Inside ~ | Ref. Coord. Robot ~ | |

When executing the Robot range limit function even if the total CPU load has exceeded over 100%, following alarms may occur due to insufficient processing time.



Alarm 500 SEGMENT PROC NOT READY

11-71

Alarm 1899 F-SAFE MONITOR EXECUTE TIMEOVER

When an alarm has occurred, reduce the area where the monitoring is simultaneously validated to avoid the CPU load from exceeding 100%.

- 11 Safety Function
- 11.4 Functional Safety Functions


11.4.5 Axis Range Limit

Axis Range Limit function is a function which sets each axis range of motion for the Robot, and base group and monitors whether each axis is inside the already-fixed range of motion using a software.

This function specifies the upper limit and the lower limit of the range of motion to those axes and the range inside the limits is defined as the safety range.

While an axis is in operation, based on the axis motion speed, this function calculates the coasting value in case of the immediate stop by the alarm, and then, including this value, it monitors the safety range. With this monitoring operation, the axes would not exceed the safety range even if a motion error is detected.

In case an error is detected, the power supply to the motor is stopped using the machine safety. And the error is notified using an alarm.



- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.5.1 Condition Setting

| Axis Speed | Monitor #1: Sampl | e AxisSpeed | Monitor | | |
|-----------------------|-------------------|-----------------|----------|-----------|-------------------|
| 1Name | | 2 | Enable C | ondition | (\tilde{I}) |
| Sample Ax | isSpeedMonitor | | Signal | ~ | |
| 3Defined | (4) Speed (5) F | Position Tolera | ance | YASKAWA | |
| S 🗌 | °/sec | | 0 | | |
| L 🗹 | 30.0 °/sec | - | ō | | |
| U | °/sec | | o | | |
| R 🗹 | 90.0 °/sec | | 0 | | |
| в | °/sec | | 0 | | |
| т 🔽 | 150.0 °/sec | | 0 | | () UP |
| 6)Speed Unit */sec | ~ | | | | |
| Advanced | Settings | | | | ~ |
| 7Setting Act | tivation Signal | | | | <i>(i)</i> |
| | Signal | S | Status | Condition | \odot |
| signal 1 | SFBIN(Fieldbus) | 01 ~ (| 0 | ON ~ | |
| | | | | | |
| 80utput Sig | nal Signal | S | Status | | |
| signal | SFBOUT(Fieldbu | s)01 ~ (| 0 | | |
| | | | | | Robot Jog Panel 🔨 |

1 Name

Set Name of the setting.

- 11 Safety Function
- 11.4 Functional Safety Functions

② Enable Condition

Set Enable Condition of the setting.

In order for the change to take effect, it is necessary to complete WRITE.

| Value | Description |
|------------|---|
| Always OFF | Always disable the monitoring by the setting. |
| Always ON | Always enable the monitoring by the setting. |
| Signal | Change the monitoring state by referring the safety input signal. For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions". |

③ Action

Select alarm or not alarm to the monitoring result of the setting.

| Value | Description |
|--------|---|
| Alarm | Servo is turned OFF with an alarm when an error occurs under the monitoring condition. |
| Status | Although monitoring is performed under the condition, alarm does not occur, and the servo is not turned OFF even if a monitoring error has occurred. The monitoring result can be obtained by the safety output signal. |



(risk assessment) and take necessary measures to them.

④ Defined

Specify Enable/Disable for a target axis.

This setting is referred when the setting is enabled and is not referred when it is disabled.

Followings show the combination of conditions.

| Monitoring Status | Defined | Result |
|-------------------|-------------|--|
| Enabled | Defined | O Monitoring for the target axis is enabled. |
| Enabled | Not Defined | х |
| Disabled | Defined | Monitoring for the target axis is disabled. |
| Disabled | Not Defined | |

11 Safety Function

11.4 Functional Safety Functions

5 Min, Max

Values for maximum/minimum range of motion can be input for the object axis.

As their inputting range, the position value limited by the soft limit switch of the manipulator can be input.

This value can also be entered by jogging the Robot to the desired limit position and pressing $\{\bigcirc\}$.

| Value | Description |
|-------|---|
| Min | Expresses the minimum limited range in which an axis moves. |
| Max | Expresses the maximum limited range in which an axis moves. |

6 Boundary

Displays whether the range of motion of the axis includes or excludes the maximum value and/or the minimum value.

The maximum value and the minimum value of each axis can be specified independently. To include the value in the range, displays \leq (IN). To exclude the value from the range, displays \leq (EX).

This is set " \leq (IN)" as default. It can be changed by Software Pendant.

⑦ Reset All to Default

Reset all axes min, max value to soft limit. Range limit for all axes will be disabled (Defined will be unselected).

(8) Setting Activation Signal

Specify the safety input signal for enable the setting when "Enable Condition" is "Signal".

For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions".

9 Output Signal

Specify the safety output signal for output the monitoring result.

Signal output as following.

| Monitoring State | Monitoring Result | Output |
|---------------------|--|--------|
| Disabled | | OFF |
| Enabled | All the axes monitoring is validated are inside the safety range. | ON |
| | Some of the axes monitoring are validated are detected to be outside the safety range. | OFF |
| | For some of the axes monitoring are validated, the stop position to which coasting value is included are detected to be in error status when moving close to the border of the safety range. | OFF |

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.5.2 Confirming the Safety Range and Starting the Axis Range Monitor

If "Always ON" or "Signal" for Enable Condition is selected, confirm that the monitoring works correctly in the safety range as the setting.

When confirming the safety range, move the axes of the object group into the safety range, and then enable the monitoring of the setting. If "Signal" for Enable Condition is selected, enable the setting by selecting input signals.

Move the axes of the object group to confirm that they stop within the specified safety range.

Confirm by jogging whether the set area is correct.



In the functional safety function, the range of motion is monitored by calculating the coasting values of the manipulator. For this reason, the manipulator stops just before exceeding the safety range in case it moves to the teaching point near the safety range.

After confirming that the object axis moves to reach the edge of the specified safety range, select {CONFIRM} on the screen. The axis range limit can be performed.

Execute playback operation to confirm the manipulator's motion. An alarm may occur in case the teaching point or the settings are inappropriate.

When "Alarm 4780: F-SAFE AXIS RANGE LIMIT INTF" or "Alarm 4781: AXIS RANGE LIMIT INTF" appeared

<Cause>

The position of the axis is out of the safety range or a range of motion error is detected when the axis moved.

In the functional safety function, the axis position is monitored based on the feedback pulse from the motor. In this case, taking the axis speed or coasting value into consideration, calculation of the movement is executed so that the manipulator would not come out from the safety range.

For this reason, in case a teaching point is set close to the edge of the safety range, and when the teaching speed is high, this alarm occurs.

<Countermeasure>

Confirm the safety range.

Modify the teaching point so that it moves not to close to the safety range border.


Decrease the manipulator's teaching speed when it passes by the border of the safety range.

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.6 Speed Limit

11.4.6.1 Outline of the Speed Limit

Speed Limit function is a function which monitors whether the speed of the Robot control points do not exceed the limit or not. Monitored Robot control points are TCP (Tool Center Point) and FCP (Flange Center Point).




When "0" is set to the speed limit, it becomes the stop position monitoring. the stop position monitoring is performed to TCP or FCP to confirm each point does not move.

When the speed limit function setting is enabled and in case the taught speed is faster than the limited speed, the speed decreases. The actual motion speed will be smaller than the limited speed for safety reason. Once the speed is decreased, then the monitoring starts.


The time for decreasing the speed varies depending on the manipulator type or teaching conditions. For this reason, in the functional safety function, the period of time from validating the condition file to complete decreasing is regarded as the monitoring delay time and this can be set to the Speed Limit setting.


- 11 Safety Function
- 11.4 Functional Safety Functions

Fig. 11-8: Outline of Speed Limit Function



In case an abnormality is detected, the power supply to the motor is stopped using the machine safety, and alarm is notified. Press reset button on the alarm notification once the abnormality is solved.





Along with the above-mentioned monitoring, when it is in the MANUAL (TEACH) mode, the speed is always monitored to be 250 mm/sec as the MANUAL (TEACH) mode safety speed.

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.6.2 Condition Setting

Contents are as following.

| Advanced Settings Setting Activation Signal Signal 1 Status Condition Signal 1 O O O O O O O O O O O O O O O O O O | Speed Limit | #1: Sample S | SpeedLimit | | |
|---|--------------|-----------------------|------------|--------------------|-----------------|
| Sample SpeedLimit Always ON ~ ③ Speed 0.0 mm/sec ④ Position Tolerance 20.000 mm ⑤ Detection Delay Time 1.00 sec Advanced Settings Status Condition Signal Status Condition Signal | Name | | (| 2 Enable Condition | (|
| ④ Position Tolerance 20.000 mm ⑤ Detection Delay Time 1.00 sec Advanced Settings Setting Activation Signal signal 1 Signal 1 ⑦ NEW SIGNAL ⑦ Output Signal Signal Status Condition | | edLimit | | Always ON 🗸 🗸 | |
| Spetection Delay Time 1.00 sec Advanced Settings Setting Activation Signal Signal 1 Signal 1 Image: Signal 1 < | | ③ Speed | 0.0 mm/sec | YASKAWA (| |
| Advanced Settings Setting Activation Signal Signal Status Condition Signal O Condition O Condition O NEW SIGNAL Output Signal Signal Status | | | 20.000 mm | | |
| Setting Activation Signal Signal signal 1 → → NEW SIGNAL Output Signal Signal Signal Status | 5Detection D | elay Time | 1.00 sec | | |
| Setting Activation Signal Signal signal 1 O Output Signal Signal Signal Status | | | | | |
| Setting Activation Signal Signal Status Condition signal 1 | | | | | |
| Setting Activation Signal Signal signal 1 O Output Signal Signal Signal Status | | | | | |
| Setting Activation Signal Signal Status Condition signal 1 | | | | | P C |
| Setting Activation Signal Signal Status Condition signal 1 | | | | | |
| Setting Activation Signal Signal signal 1 Image: Signal 2 Image: Signal 3 Image: Signal 3 Image: Signal 3 Signal 3 Signal 3 Signal 3 | | | | | |
| Setting Activation Signal Signal signal 1 → → NEW SIGNAL Output Signal Signal Signal Status | | | | | |
| Setting Activation Signal Signal Status Condition signal 1 | | | | | |
| Setting Activation Signal Signal signal 1 O Output Signal Signal Signal Status | (N) | | | | |
| Signal Status Condition signal · Condition · NEW SIGNAL Output Signal Signal Status | Advanced S | ettings | | | |
| signal 1 ~ (+) NEW SIGNAL Output Signal Signal Status | Setting Acti | vation Signal | | | (|
| Output Signal Signal Signal Status | | Signal | | Status Condition | |
| Output Signal Status | signal 1 | | ~ | 0 | |
| Output Signal Status | | | IGNAL | | |
| Signal Status | | | | | |
| | Output Sign | | | | |
| signal 🛶 | | Signal | | Status | |
| | signal | C erection | ~ | 0 | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | Robot Jog Panel |

① Name

Set Name of the setting.

- 11 Safety Function
- 11.4 Functional Safety Functions

2 Enable Condition

Set Enable Condition of the setting.

In order for the change to take effect, it is necessary to complete WRITE.

| Value | Description | |
|------------|---|--|
| Always OFF | Always disable the monitoring by the setting. | |
| Always ON | Always enable the monitoring by the setting. | |
| Signal | Change the monitoring state by referring the safety input signal. For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions". | |

③ Speed

Specify the speed limit to the motion speed.

When "0" is set to the speed limit, it becomes the stop position monitoring.



When limiting speed with low speed (0.1 to 5 [mm/sec] or 0.1 to 5 [%]), even during speed limit, F-SAFETY SPEED LIMIT ERROR alarms may occur due to tiny motions such as turning ON of the servo.

When required, take measures, such as review the limit speed, limit section, or use stop monitoring.

④ Position Tolerance

Specify the position tolerance for the stop position monitoring. This item can be specified when "0" is set to "Speed".

Although the stop position monitoring monitors the difference between the stop position monitoring start position and the present position, to avoid any alarms from occurring due to tiny motions such as turning ON of the servo during the monitoring, "Position Tolerance" is specified. An alarm occurs when the axis moves to exceed the position where the acceptable range is added to the stop position monitoring start position.

(5) Detection Delay Time

Specify a time frame from validating the condition file to start the alarm detection.

6 Setting Activation Signal

Specify the safety input signal for enable the setting when "Enable Condition" is "Signal".

For the details of the safety signal usage, refer to chapter 11.4.

11-80

HW1485509

- 11 Safety Function
- 11.4 Functional Safety Functions

⑦ Output Signal

Specify the safety output signal for output the monitoring result.

| Signal | output | as | following. |
|--------|--------|----|------------|
|--------|--------|----|------------|

| Monitoring State | Monitoring Result | Output |
|---------------------|--|--------|
| Disabled | | OFF |
| Enabled | Monitored group is normal within the speed limit. | ON |
| | Monitored group is detected the limited speed error. | OFF |

11.4.6.3 Starting the Speed Limit

Specify the speed limit function and press {WRITE}, the speed limit function will be enabled.

11.4.6.4 Speed Limit in MANUAL (TEACH) Mode

While the MANUAL (TEACH) mode is selected, the speed is monitored at 250 [mm/sec] for safety under the functional safety function. Unlike other speed limit functions, this monitoring function cannot be disabled.

However, only when the full speed test is input by the external signal and when the manual brake is released, this monitoring function will be disabled. This allows the speed can be higher than 250 [mm/sec] even during the MANUAL (TEACH) mode.

For the full speed test, refer to "YRC1000 INSTRUCTIONS (RE-CTO-A221) chapter 8.26 Safety Logic Circuit".

For the manual brake release function, refer to chapter 9.2 "Brake Release".



When using the full speed test or manual brake release functions, possible risks attributed to the speed limit release should be sufficiently considered (risk assessment) before operating the manipulator.

MANUAL (TEACH) mode speed limit is set in No.33 as "MANUAL (TEACH) Mode Speed Limit".

- 11 Safety Function
- 11.4 Functional Safety Functions

In the MANUAL (TEACH) mode speed limit setting, editing parameter are limited as following.

| Speed Limit #33: Mai | nual(Teach) Mode S | Speed Limi | t | |
|-----------------------------|--------------------|------------|-----------|-------------------|
| DName Manual(Teach) Mode | | 2 Enable (| Condition | |
| (3) Speed | 1 250.0 mm/sec | 1 | YASKAWA D | 5 |
| 4 Position Tolerance | · mm | | | |
| 5 Detection Delay Time | e 1.00 sec | | | |
| | | | | |
| Advanced Settings | | | | ~ |
| 6 Setting Activation Signal | gnal | Status | Condition | (\tilde{l}) |
| signal 1 | ~ | 0 | | |
| | WSIGNAL | | | |
| Output Signal | | | | |
| Signal | | Status | | |
| signal | ~ | 0 | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | Robot Jog Panel ∧ |

1 Name

It is set as MANUAL (TEACH) Mode Speed Limit". It cannot be modified.

2 Enable Condition

This monitoring function cannot be disabled. But, only when the full speed test is input by the external signal and when the manual brake is released, this monitoring function will be disabled.

③ Speed

It is set as 250mm/sec. It cannot be modified.

- 11 Safety Function
- 11.4 Functional Safety Functions

④ Position Tolerance

It cannot be modified.

5 Detection Delay Time

Specify a time frame from validating the condition of the speed limit to start the alarm detection. It is set as the time for decreasing the speed slower than 250 mm/sec when the full speed test function is released.

6 Setting Activation Signal

It cannot be specified.

⑦ Output Signal


Specify the safety output signal for output the monitoring result.

11.4.7 Axis Speed Monitor

Axis speed monitor function is a function which monitors whether each axis does not exceed the limit.

When "0" is set to the speed limit, it becomes the stop position monitoring. This monitors the axis whether it does not move to exceed the limit of specified range from the point where the monitoring is started.

In case an abnormality is detected, the power supply to the motor is stopped using the machine safety, and alarm is notified.



- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.7.1 Condition Setting

Contents are as following.

| Name | (|
|--|---|
| S °/sec ° L 30.0 °/sec ° U °/sec ° R 90.0 °/sec ° B °/sec ° T 150.0 °/sec ° Speed Unit */sec ° */sec - - Setting Activation Signal Status Condition Signal 1 SFBIN(Fieldbus)01 ~ O N ~ • NEW SIGNAL Output Signal Status Status | C |
| L Signal Status Condition Signal Status Condition Signal Status Condition Signal Status Condition Output Signal Signal Status Condition | |
| U°/sec R 90.0 °/sec B°/sec T 150.0 °/sec T 150.0 °/sec Speed Unit '/sec ' Advanced Settings | |
| R Q 90.0 °/sec ° B °/sec ° T T 150.0 °/sec ° Speed Unit */sec ° Advanced Settings Setting Activation Signal Signal 1 SFBIN(Fieldbus)01 ON | |
| B °/sec ° T I 150.0 °/sec - ° Speed Unit */sec ~ Advanced Settings Setting Activation Signal Signal Status Condition GN ~ () N | |
| T I 150.0 °/sec - ° Speed Unit */sec ~ Advanced Settings Setting Activation Signal Signal Status Condition Signal 1 SFBIN(Fieldbus)01 ~ O N ~ • NEW SIGNAL Output Signal Signal Status | |
| Speed Unit */sec */sec Advanced Settings Setting Activation Signal Signal Status Signal 1 SFBIN(Fieldbus)01 ON ON Output Signal Signal Status | |
| */sec ✓ Advanced Settings Setting Activation Signal Signal Status Condition ignal I SFBIN(Fieldbus)01 ✓ O ON ✓ • NEW SIGNAL Output Signal Signal Status | |
| Setting Activation Signal Signal Signal 1 SFBIN(Fieldbus)01 ON Output Signal Signal Signal | |
| Signal Status Condition Signal SFBIN(Fieldbus)01 ON ON NEW SIGNAL Signal Status | |
| signal 1 SFBIN(Fieldbus)01 ~ ON ~ | (|
| NEW SIGNAL Output Signal Signal Status | |
| Output Signal Status | |
| Signal Status | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Robot Jog | |

① Name

Set Name of the setting.

- 11 Safety Function
- 11.4 Functional Safety Functions

② Enable Condition

Set Enable Condition of the setting.

In order for the change to take effect, it is necessary to complete WRITE.

| Value | Description |
|------------|---|
| Always OFF | Always disable the monitoring by the setting. |
| Always ON | Always enable the monitoring by the setting. |
| Signal | Change the monitoring state by referring the safety input signal. For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions". |

③ Defined

Specify Enable/Disable for a target axis.

This setting is referred when the setting is enabled and is not referred when it is disabled.

Followings show the combination of conditions.

| Monitoring Status | Defined | Result |
|-------------------|-------------|--|
| Enabled | Defined | O Monitoring for the target axis is enabled. |
| Enabled | Not Defined | Х |
| Disabled | Defined | Monitoring for the target axis is disabled. |
| Disabled | Not Defined | |

④ Speed

To each target axis, set the upper limit of motion speed.

When "°/sec" is set as the unit of the speed, "°/sec" is used for a rotating axis.

When "%" is set as the unit of the speed, calculate and set the upper limit by considering the maximum speed as 100%. This unit "%" is the same as the unit of the set value used when the target axis is independently operated by JointMove Speed=xx%.

(5) Position Tolerance

Specify the position tolerance for the stop position monitoring. This item can be specified when "0" is set to "Speed".

Although the stop position monitoring monitors the difference between the stop position monitoring start position and the present position, to avoid any alarms from occurring due to tiny motions such as turning ON of the servo during the monitoring, "Position Tolerance" is specified. An alarm occurs when {ACCEP.RNG} is set in \pm direction from the stop position monitoring starting position and the axis moves to exceed the position.

6 Speed Unit

Specify the unit of speed in the setting. When "°/sec" is set, "°/sec" is used for a rotating axis. When "%" is set, percentage is used.



- 11 Safety Function
- 11.4 Functional Safety Functions

⑦ Setting Activation Signal

Specify the safety input signal for enable the setting when "Enable Condition" is "Signal".

For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions".

® Output Signal

Specify the safety output signal for output the monitoring result.

Signal output as following.

| Monitoring State | Monitoring Result | Output |
|---------------------|--|--------|
| Disabled | | OFF |
| Enabled | All monitoring axes are normal within the speed limit. | ON |
| | Some axes are detected the limited speed error. | OFF |

11.4.7.2 Starting the Axis Speed Monitor

Specify the axis speed monitor function and press {WRITE}, the axis speed monitor function will be enabled.

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.8 Tool Angle Monitor

The tool angle monitor function is a function that monitors the angle of the tool by specifying the standard value of manipulator tool tilting angle and the limit of the tool angle, and then, using the software, monitors whether the standard value-centered tool angle does not exceed the specified limit angle. In case the tool file is not specified, it monitors the tilling angle of the flange.

For details on Tool Angle Monitor, refer to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576) chapter 4.5 Tool Angle Monitor Function".

To set the Tool Angle Monitor, use of the Software Pendant is required. For the details on Software pendant, refer to chapter 12 "Software Pendant".

11.4.9 Tool Change Monitor

When performing monitoring functions of the safety such as the Robot range limit function or the speed limit function in the functional safety function, appropriate tool information is required to be selected. In the system where the tool change is required, the function safety function changes the tool number in accordance with the specified value from the master CPU.

This tool change monitor function monitors whether the tool is appropriately changed. The monitoring is performed comparing the master CPU-specified tool number and the tool number which is specified to a safety signal-specified condition file. It is judged as an abnormality when a manipulator operates when these numbers are not consistent.

For details on Tool Change Monitor, refer to "YRC1000 OPTIONS INSTRUCTIONS FOR FUNCTIONAL SAFETY FUNCTION (HW1483576) chapter 4.6 Tool Change Monitor Function".

To set the Tool Change Monitor, use of the Software Pendant is required. For the details on Software pendant, refer to chapter 12.


11.4.10 External Force Monitor

External Force Monitor function suspends the Robot according to the external force applied to the Robot when the collaborative operation is enabled.


External Force Monitor function monitors the external force applied to the manipulator's TCP and each joint axis. If the external force exceeds the limitation value that is preset, the Robot stops for protection with a Category 2 stop. After the manipulator stops, its stopped state is monitored by the functional safety unit to ensure that there is no motion of the manipulator. When the collaborative operation is enabled, the Collaborative Operation LED (green color) lights up.

Also, when the state of stop monitoring is valid, the resume switch (orange color) which is located below the LED lights up. Press the resume button to resume manipulator motion from the position at which the manipulator stopped.

- 11 Safety Function
- 11.4 Functional Safety Functions



11-88



NOTICE

By default, each MOTOMAN-HC10 is shipped with one external force monitor with 100N to external force limitation value (TCP resultant force and each X/Y/Z axis direction external force).

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.10.1 Condition Setting

Contents are as following.

| Name Sample Ford | e Monitor | ② Enable Condition Always ON ~ | (|
|---------------------|---------------|-----------------------------------|------|
| 3)TCP Force L | | | Fz |
| Resultant | 100 N | (100 - 300 N) | FY |
| Fx | 100 N | (50 - 100 N) | AZ P |
| Fy | 100 N | (50 - 100 N) | Y |
| | | | |
| Fz | 100 N | (50 - 100 N) | |
| Advanced Se | ettings | | |
| Joint Torque | | ~ | |
| s 🗹 | 90.0 Nm | (90 - 450 Nm) | |
| L 🗹 | 90.0 Nm | (90 - 450 Nm) | 0 |
| U 🗆 | Nm | (40 - 200 Nm) | |
| R 🗌 | Nm | (10 - 45 Nm) | |
| в | Nm | (10 - 45 Nm) | 25 |
| т 🗆 | Nm | (10 - 45 Nm) | |
| 5)Setting Activ | vation Signal | | |
| | Signal | Status Condition | (|
| signal 1 | | ~ O ~ ~ | |
| 6)Output Signa | | | |
| | Signal | Status | |
| signal | | \sim \bigcirc | |

① Name

Set Name of the setting.

- 11 Safety Function
- 11.4 Functional Safety Functions

2 Enable Condition

Set Enable Condition of the setting.

In order for the change to take effect, it is necessary to complete WRITE.

| Value | Description |
|------------|---|
| Always OFF | Always disable the monitoring by the setting. |
| Always ON | Always enable the monitoring by the setting. |
| Signal | Change the monitoring state by referring safety input signal. For the details of the safety signal usage, refer to chapter 11.4 "Functional Safety Functions". |

③ TCP Force Limit

Use this to specify the maximum value of the forces on the TCP of the manipulator in world coordinate frame. When external force exceeds these values, this safety monitor will get activated and will stop the manipulator. These forces must be specified in Newtons [N]. The value specified in {Resultant} must be greater than the maximum of X, Y, and Z values. Most applications may need the Resultant force equivalent to X, Y, Z forces. This value is specified as a force and in Newtons [N] (Allowable range: 0 - 300 [N], though a value below 50N should not be specified).

Specify Enable/Disable for a target axis.

④ Joint Torque Limit

Use this to specify the maximum value of external torques for each joint axis of the Robot. When external torque for any of the axes that has been set exceeds the defined value, this safety monitor will get activated and will stop the Robot. This value is specified as a moment and in Newton-Meters [N•m]. (The allowable range varies depending on the type of the manipulator.)

⑤ Setting Activation Signal

Specify the safety input signal for enable the setting when "Enable Condition" is "Signal".

For the details of the safety signal usage, refer to chapter 11.4.

6 Output Signal

Use this to specify an output signal that will turn ON when external force applied to the Robot exceeds the value of external force monitor.

11.4.10.2 Confirming and Starting the External Force Monitor

After the {WRITE}, External Force Monitor requires to confirm. After confirming, press {CONFIRM}, the axis speed monitor function will be enabled.

- 11 Safety Function
- 11.4 Functional Safety Functions

11.4.10.3 Temporarily Disable All External Force Monitors

Refer to chapter 11.3.9.6 for the proper instructions to temporarily disable PFL. Any External Force Monitor settings that are ON will be disabled when PFL is OFF.



11.4.10.4 Daily Inspection

Periodic Inspection of Torque Sensors

11-91

MOTOMAN-HC10 torque sensors require periodic calibration, as their readings can drift due to environmental changes, accidental collisions between the manipulator and its surroundings, or general misuse of the manipulator.

One method to verify whether the manipulator's torque sensors require calibration is to use the Force/Torque Watch function that is accessible through $\{MENU\} \rightarrow \{Utility\} \rightarrow \{Force/Torque Watch\}$. This window shows the current and maximum readings of all joint torques and TCP forces. Current "Joint Data" (in fig. 11-11 "Force / Torque Watch") is most important for torque sensor inspection purposes.

- 11 Safety Function
- 11.4 Functional Safety Functions

Fig. 11-11: Force / Torque Watch

| Force/Torque | e Watch | ж | | | |
|--------------|----------------|-------------|--------------|-----------------|--|
| | | Current | Maximum | PFL Violation | |
| | Resultant | 4.0 N | 4.5 N | 0 | |
| | F _X | -2.8 N | -3.1 N | 0 | |
| | F _Y | 2.0 N | 2.2 N | 0 | |
| TCP Data | Fz | -2.2 N | -2.6 N | 0 | |
| | M _X | 0.0 N·m | 0.0 N·m | | |
| | M _Y | 0.0 N·m | 0.0 N·m | | |
| | Mz | 0.0 N·m | 0.0 N·m | | |
| | | | | | |
| | S | 1.4 N·m | 1.7 N·m | 0 | |
| | L | 1.6 N·m | 1.9 N·m | 0 | |
| Joint Data | U | 1.3 N·m | 1.5 N·m | 0 | |
| | R | 0.5 N·m | 0.6 N·m | 0 | |
| | В | -0.1 N·m | -0.1 N·m | 0 | |
| | т | 0.6 N·m | 0.7 N·m | 0 | |
| test BR | OWSE USER P | FL SETTINGS | RESET MAXIMU | JM VALUE FIELDS | |
| | | | | | |
| | | | | | |

YASKAWA recommends maintaining a log of acceptable torque values for a MOTOMAN-HCxx or MOTOMAN-HCxxDT installation. Any time the user makes and verifies a change to the system (e.g. swap a tool), the {Joint Data} values on the Force/Torque Watch window should be recorded with the manipulator at a position convenient for the user. The user can compare this recorded data to the "Current" values during an inspection.

This comparison between allowable and current torque values is valid <u>only</u> if the following four conditions are satisfied:

- 1. Tool number on the screen matches the currently installed tool
- 2. Accurate physical properties of the current tool are properly set
- 3. Posture of the manipulator during inspection matches the posture when the "acceptable torque values" were initially recorded.



- 11 Safety Function
- 11.4 Functional Safety Functions
- 4. Current {Joint Data} (in *fig. 11-11 "Force / Torque Watch"*) values do not exceed the data found in *table 11-20 "Torque Sensor Torque Value Inspection"*.

If the current joint torques values exceed one or multiple values shown in table 11-20 "Torque Sensor Torque Value Inspection", the error in external force calculation increases (thereby negatively affecting PFL functionality). Thus, a re-calibration of torque sensor offset data is required. Refer to "Calibrating Torque Sensor Offset Data" in chapter 11.4.10.4 "Daily Inspection".

Table 11-20: Torque Sensor Torque Value Inspection


| Axis | S | L | U | R | В | Т |
|-------|----------|----------|----------|---------|---------|---------|
| Value | 27.0 N•m | 27.0 N•m | 12.0 N•m | 3.0 N•m | 3.0 N•m | 3.0 N•m |

Daily inspection is recommended.




Calibrating Torque Sensor Offset Data

- Navigate to {MENU} → {Safety Settings} → {Torque Sensor Calibration}.
- Prior to performing the calibration procedure, MOTOMAN-HC10 must be moved to a position where the gravitational torque applied to the manipulator (e.g. by a tool or other external loads) is near zero for all axes. The following positions shown in the *fig. 11-12 "Torque Sensor Calibration Positions"* are recommended for calibration of all axes simultaneously.
- Fig. 11-12: Torque Sensor Calibration Positions



HC10 Torque Calibration Pos. 1 (Home Position)




HC10 Torque Calibration Pos. 2 (U-axis: 180 degrees)



- 11 Safety Function
- 11.4 Functional Safety Functions

A button-link is provided to navigate to the Move Robot screen. If the manipulator is already at a recommended calibration position above, this button will appear green in color.





- The Robot cannot reach to the Torque Sensor Calibration position with the tool attached.
- The Robot cannot reach to the Torque Sensor Calibration position due to the workspace limitation.
- The tool is not symmetrical.
- The tool is mounted with an offset.

- 11 Safety Function
- 11.4 Functional Safety Functions
- 3. After moving the manipulator to a recommended position, select one of the following methods to calibrate torque sensor offset value(s):

A. Standard Option: All Axes Update

Press the {CALIBRATE ALL TORQUE SENSORS AT CURRENT POSITION} to update all torque sensor offset values. This method is recommended for most cases.

B. Advanced Option: Single Axis Update

Press a {CALIBRATE AXIS} to update the torque sensor offset values of a single axis. This method may be used when only a few axes require calibration.

Example: If a user swaps tools for one with dramatically different physical properties, the T-axis torque sensor may drift due to the large change of the attached load. The geometry of this new tool may prevent the user from moving to one of the recommended positions while attached. Thus, a single axis calibration for the

T-axis can be performed at its zero-torque position (refer to fig. 11-12 "Torque Sensor Calibration Positions").




"Advanced Options" checkbox must be checked to calibrate axes individually.

C. Advanced Option: Manual Update

Enter offset values manually. This method may be used if the YRC1000 Controller or its internal boards (CPU or PFL) are replaced and the previously recorded offset values are available.

Note: "Advanced Options" checkbox must be checked to manually edit these values.

Fig. 11-13: Torque Sensor Calibration





- 11 Safety Function
- 11.4 Functional Safety Functions
- Any edit to an offset value will cause a "READBACK" button to appear that allows the user to read data from both the YRC1000 and PFL safety board. A "CANCEL" button also appears that allows the user to abort editing.
- 5. Press the "READBACK".
 - A "WRITE" button and "Display" Option control will appear.

Display options are provided for viewing the readback data. These options are:

- Edit value: shows values entered by user.
- Readback Value (PFL): shows temporary values saved on the PFL board.
- Comparison Result: (default)
- 6. Check the "READBACK" result. In general, the user should only check the "Comparison Result" to determine if all values match, meaning the edit was successful. If the data differs, the value of the "Comparison Result" will be displayed as "***" instead of the value. At this point, the operator should check to see which data on which board was not updated.
- 7. Press "WRITE".
 - A confirmation pop-up window will appear prompting the user to finish the process, provided the data was updated correctly.

11.4.11 Safety Signal

Functional Safety Function and Collaborative operation function can be Enabled/Disabled by safety input signal.

Also, these functions can output the monitoring result by safety output signal.

Followings are the safety signal available for the functional safety function.

| Signal | Signal Point | Note | |
|--|--|--|--|
| Functional safety general purpose signal | (for JANCD-ASF02-E) Input : 8 points/terminal Output : 8 points/terminal | The functional safety general-purpose signal is connected per safety circuit board. The number of the signals differ depending on the | |
| | (for JANCD-ASF03-E) Input : 16 points/terminal Output : 16 points/terminal | minal erminal - when connecting to "JANCD-ASF02-E", 8 inp points and 8 output points - when connecting to "JANCD-ASF03-E", 16 inp points and 16 output points | |
| Safety fieldbus signal | Input:64 points/system Output:64 points/system | The safety fieldbus signal is connected per system. Depending on the settings, up to 64 points can be used from one safety circuit board. The safety fieldbus is an optional function other than the functional safety. | |
| Safety logic circuit extended signal | Input:64 points/system Output:64 points/system | The safety logic circuit extended signal (64 input points and 64 output points) is connected per system. The output of the safety logic circuit (MS-OUT) can be used as the input of the functional safety. The output of the functional safety (FS-OUT) can be used as the input of the safety logic circuit. | |

- 11 Safety Function
- 11.4 Functional Safety Functions

If the safety fieldbus signal and the safety logic circuit signal are included, up to 144 points can be used from one safety circuit board.

To condition files, as many safety signals as desired can be allocated within the possible signal points, thus signals are flexibly used even if the board has small numbers of signal points.

Followings are the safety signal available for the collaborative operation function.

| Signal | Signal Point | Note |
|---------------------|---|---|
| PFL function signal | Input:16 points/terminal Output:16 points/terminal | PFL function signal is connected per PFL circuit board. |

11.4.11.1 Allocation of Safety Logic Circuit Extended Signal

The safety logic circuit extended signal can be used as the input signal or the output signal of the functional safety. The number of the signal points are 64 input points and 64 output points. These signals are shared by the whole system and can be used from any board of the safety circuit board.

Regarding the FS-OUT (safety logic circuit functional safety output signal), allocation of the signal and the board must be performed in advance.

To allocate Safety Logic Circuit Extended Signal, refer to chapter 11.3.4.5.

11.4.11.2 Allocation of Safety Fieldbus Signal

The safety fieldbus function is not a functional safety function but an optional function. When it is valid, the safety fieldbus signal can be used in the functional safety function.

Safety fieldbus signal transmits/receives the safety-guaranteed "safety data" through the fieldbus communication path. It has 64 input signal points and 64 output signal points.

These signals are commonly used in the whole system and thus they can be referred from both machine safety board and functional safety board.

In this consequence, "SAFETY SIG. BOARD ALLOC" function is prepared to define which signal is to be used in which board.

To allocate Safety Fieldbus signal, refer to chapter 11.3.4.4.

11.4.11.3 Enable Condition of Safety Functions Setting

The setting of safety function, it can be enabled/disabled by safety input signal when Enable Condition is "Signal".

Judging the safety input signals are explained as following.

| | Signal | | Status | Condit | ion |
|----------|---------|---|--------|--------|-----|
| signal 1 | MSOUT01 | ~ | • | ON | ~ |
| signal 2 | MSOUT02 | ~ | 0 | OFF | ~ |
| signal 3 | MSOUT03 | ~ | 0 | OFF | ~ |
| signal 4 | MSOUT04 | ~ | 0 | OFF | * |
| signal 5 | | ~ | 0 | | ~ |

The input signal is judged line-by-line.

- 11 Safety Function
- 11.4 Functional Safety Functions

When performing a setting as marked with the red square, the condition of signal 1 line is defined as satisfied. because "ON" is set to {Condition} at the input signal {MSOUT01}, and \bullet (=ON)} is set to {Status}.

Up to 5 signals can be set to a setting (up to 4 for the tool change monitor function).

Conditions of the lines from signal 1 line to signal 5 line are judged by the safety input signal respectively, the setting is enabled only when all the conditions are satisfied.

The line "----" (undefined) is disregarded for this judgement

| Setting Acti | vation Signal | | | | <i>(i)</i> |
|--------------|---------------|---|--------|-----------|------------|
| | Signal | | Status | Condition | \smile |
| signal 1 | MSOUT01 | ~ | • | on 🗸 | |
| signal 2 | MSOUT02 | ~ | 0 | OFF 🗸 | |
| signal 3 | MSOUT03 | ~ | 0 | OFF 🗸 | |
| signal 4 | MSOUT04 | ~ | 0 | OFF 🗸 | |
| signal 5 | | ~ | 0 | ~ | |

| Setting Activ | vation Signal | | | | | <i>(i)</i> |
|---------------|---------------|---|------------|---------|----|------------|
| | Signal | | Status | Conditi | on | Ŭ |
| signal 1 | MSOUT01 | ~ | \bigcirc | ON | ~ | |
| signal 2 | MSOUT02 | ~ | • | OFF | ~ |] |
| signal 3 | MSOUT03 | ~ | 0 | OFF | ~ | |
| signal 4 | MSOUT04 | ~ | \bigcirc | OFF | ~ | |
| signal 5 | | ~ | 0 | | ~ | |

There can be a time difference after the first signal and before the last signal. In the functional safety function, an interval of 32 [ms] is equipped to the system to be totally switched to internally settled after the last signal change.

For this reason, please take this into consideration when performing the following operations.



- When switching several signals, do not take more than 32 [ms].
 - The signals may be settled with half-specified values.
- Do not use signals that continue shifting ON/OFF within the interval of less than 32 [ms].
 - Signals will not be settled.

Based on above mentioned judging methods, settings can be enabled/ disabled by the multi signals.

For example, there are following methods when Enable/Disable settings by 3 signals (MSOUT1, MSOUT2, MSOUT3).

Example 1: Switching one file using 1 signal

Enable/Disable the setting individually by one signal.



11 Safety Function

11.4 Functional Safety Functions

Easy to configure the simultaneous monitoring.

| Setting | Signal | Condition | Enable Condition |
|----------|--------|-----------|------------------|
| Setting1 | MSOUT1 | ON | MSOUT1: ● |
| Setting2 | MSOUT2 | ON | MSOUT2: ● |
| Setting3 | MSOUT3 | ON | MSOUT3: ● |

Example 2: Switching multi files using 3 signals

Select one file out of several files by the condition of 3 signals.

Many files can be managed with less signals. This pattern is effective when simultaneous monitoring is not necessary.

| Setting | Signal | Condition | Enable Condition |
|----------|--------|-----------|------------------|
| Setting1 | MSOUT1 | OFF | MSOUT1: O |
| | MSOUT2 | OFF | MSOUT2: O |
| | MSOUT3 | OFF | MSOUT3: O |
| Setting2 | MSOUT1 | ON | MSOUT1: ● |
| | MSOUT2 | OFF | MSOUT2: O |
| | MSOUT3 | OFF | MSOUT3: O |
| Setting3 | MSOUT1 | OFF | MSOUT1: O |
| | MSOUT2 | ON | MSOUT2: ● |
| | MSOUT3 | OFF | MSOUT3: O |
| Setting4 | MSOUT1 | ON | MSOUT1: ● |
| | MSOUT2 | ON | MSOUT2: ● |
| | MSOUT3 | OFF | MSOUT3: O |
| Setting5 | MSOUT1 | OFF | MSOUT1: O |
| | MSOUT2 | OFF | MSOUT2: O |
| | MSOUT3 | ON | MSOUT3: ● |
| Setting6 | MSOUT1 | ON | MSOUT1: ● |
| | MSOUT2 | OFF | MSOUT2: O |
| | MSOUT3 | ON | MSOUT3: ● |
| Setting7 | MSOUT1 | OFF | MSOUT1: O |
| | MSOUT2 | ON | MSOUT2: ● |
| | MSOUT3 | ON | MSOUT3: ● |
| Setting8 | MSOUT1 | ON | MSOUT1: ● |
| | MSOUT2 | ON | MSOUT2: ● |
| | MSOUT3 | ON | MSOUT3: ● |

11.4.11.4 Safety Signal Output Value


The output signal outputs the status of safety or not safety over the monitoring conditions when the setting is enabled.



- 11 Safety Function
- 11.5 Safety Caution

11.5 Safety Caution

11.5.1 How to Restart the YRC Controller



To turn off and back on the power to the YRC Controller, always use the main power switch.

Wait at least 10 seconds after turning off the main power switch until turning it on.

11.5.2 Check Items before Operating the Manipulator

Before operating the manipulator in any mode, check the following items carefully:

- Whether collaborative operation is enabled or disabled Make sure that the collaborative operation enable/disable setting is correct.
- Operation check of the PFL function
 Make sure that the PFL function is correctly configured.
 In particular with collaborative operation enabled (i.e., with the collaborative operation lamp lit in green), make sure in advance that the PFL function works correctly by adding an external force to the manipulator.

11 Safety Function

11.5 Safety Caution

11.5.3 About the Behavior near Singularity

With collaborative operation enabled, the behavior of the manipulator near singularity is limited to operating on an axis by axis basis.


An attempt to operate the manipulator along more than one axis at a time, in any operation mode, results in AL.6002 "NEAR SINGULARITY (PFL)".

The MOTOMAN-HCxx or MOTOMAN-HCxxDT has the following three singularities.

Singularity 1: The U-axis is at an angle within the range of 0° or 180° ±15°.

Singularity 2: The rotation center of the B-axis (P-point) is near the vertical line of the S-axis (within 300 mm).

Singularity 3: The B-axis is at an angle within the range of 0° or 180° ±15°. *Table 11-21: Example of Singularity Postures*



- 11 Safety Function
- 11.6 Data Protection

11.6 Data Protection

11.6.1 Duplicate Data

The data related to the safety function is copied to the safety circuit board's memory or PFL circuit board's memory for safety.

When the control power is turned ON, check is performed to see that duplicate data are set the same. If they are different when the control power is turned ON, the following alarm occurs.

When there is difference in the Safety Circuit Board:

Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [10]"

When there is difference in the PFL Circuit Board:

Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [13]"

In the system with the functional safety function, a message "Select 'Safety Board FLASH Reset' in the maintenance mode" is displayed after the following operations.

Turning ON or OFF causes error without FLASH Data Reset.

- The data related to the safety function is loaded from an external storage in Software Pendant.
- A parameter related to the safety function is rewrote by setting operations in maintenance mode.
- The zeroing function is performed.
- · Encoder is reset

In case one of the above-mentioned operations is performed, FLASH Data Reset is required.

In the maintenance mode, there are cases when parameters related to the safety function are rewritten by several setting operations.

For this reason, the message "Select 'Safety Board FLASH Reset'" may be displayed. Perform the safety board FLASH reset operation in this case.

11.6.2 Safety Board FLASH Reset

If the following alarm occurs when the control power supply is turned ON,

Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [10]"

Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [13]"

11-102

perform the Safety Board FLASH RESET to reset the data of the safety circuit board and PFL circuit board. To perform FLASH Data Reset, refer to chapter 12.4.3.3 "Safety Board Flash Reset".



When FLASH Data reset is required, Smart Pendant cannot operate the YRC Controller. Use Software Pendant and perform Safety Board FLASH Reset.

For detail on the Software Pendant, refer to *chapter 12 "Software Pendant"*.

- 11 Safety Function
- 11.6 Data Protection

11.6.3 Verify Safety Settings (CRC)

11.6.3.1 Overview

The Cyclic Redundancy Check (CRC) is an error-detecting code that is used for storage devices to detect accidental or intentional changes. Specific to the YRC controller, the a CRC is added to files associated with functional safety settings. The value for the CRC is computed based on the contents of these files.

The CRC value, which is created based on the file data, is a fixed value unless the contents of the file are modified.

By verifying that the CRC value has not changed, the user can confirm that the data in the associated file has not changed.

Table 11-22: Files CRC Supports

| File | File Name for External Memory Device |
|-------------------------------|---|
| Safety Logic Circuit (System) | YSFLOGIC.DAT (System) |
| Safety Logic Circuit (User) | YSFLOGIC.DAT (User) |

| Table 11-23: Additional Files CRC Supports with Functional Safety | |
|---|--|
| Function Enabled | |

| File | File Name for External Memory Device |
|------------------------------------|---|
| Tool data | TOOL.CND |
| Tool interfere data | TOOLINTF.DAT |
| Home position calibrating data | ABSO.DAT |
| Axis range limit data | AXRNGLMT.DAT |
| Axis speed monitor data | AXSPDMON.DAT |
| Robot range limit data | RBRNGLMT.DAT |
| Speed limit data | SPDLMT.DAT |
| Tool angle monitor data | TLANGMON.DAT |
| Tool change monitor data | TLCHGMON.DAT |
| Function definition parameter | FD.PRM |
| System definition parameter | SD.PRM |
| Servo parameter | SV.PRM |
| Servo motor parameter | SVM.PRM |
| Robot matching parameter | RC.PRM |
| Coordinate home position parameter | RO.PRM |
| Motion function parameter | MF.PRM |
| Robot control expand parameter | RE.PRM |
| Safety function parameter | FMS.PRM |
| System matching parameter | SC.PRM |

- 11 Safety Function
- 11.6 Data Protection

11.6.3.2 Verify Safety Settings (CRC) Screen

Verify Safety Settings (CRC) supports checking the CRC value and the Last modified date.

| File 🔺 | CRC | Last Modified \$ | |
|------------------------------------|----------------|---------------------|--|
| Tool data | (2) 0381761669 | 3) 2019-11-07 16:01 | |
| Tool interfere data | 1 | - | |
| Home position calibrating data | _ | | |
| Axis range limit data | 1022308666 | 2019-11-07 16:01 | |
| Axis speed monitor data | 1240835465 | 2019-11-07 16:01 | |
| Robot range limit data | 2145054300 | 2019-11-07 16:01 | |
| Speed limit data | 3729081368 | 2019-11-07 16:01 | |
| Tool angle monitor data | 1558066036 | 2019-11-07 16:01 | |
| Tool change monitor data | 1336928352 | 2019-11-07 16:01 | |
| Safety logic circuit data(User) | - | - | |
| Safety logic circuit data(System) | | - | |
| Function definition parameter | - | - | |
| System definition parameter | 1.77 | 100 | |
| Servo parameter | | - | |
| Servo motor parameter | 1.77 | | |
| Robot matching parameter | - | 17 | |
| Coordinate home position parameter | - | - | |
| Motion function parameter | - | - | |
| Robot control expand parameter | | 121 | |
| Safety function parameter | | | |
| System matching parameter | - | | |

4 File

Show the setting file name.

4 CRC

CRC value calculated from file data. This value is same value as the file transferred using the File Transfer screen. If the file has not modified since the system started operating, "----" will be shown.

The file is usually updated simultaneously when modifying the data. However, when performing the modification in which the Functional Safety Board FLASH Reset is necessary, "----" will be shown, and then the value is shown after resetting the Functional Safety Board Flash.

④ Last Modified

The last modified (edited, loaded, initialized) date and time is shown. If the file has not modified since the system started operating, "----" will be shown.

④ Export CRC

Export the screen contents into a text file and a screenshot in to a PNG file. A USB drive must be attached to the Smart Pendant for this function.

- 11 Safety Function
- 11.6 Data Protection

11.6.3.3 Change of Condition File by an External Device

When using functional safety functions, the data used for the setting of safety monitoring must not be modified by an external device. Therefore, when loading the condition file from the external memory device, loading is allowed only when it is confirmed that the contents of the saved file have not been modified.

(e.g.) Tool file

```
//TOOL 0
///CRC 4294967294 (CRC value)
///NAME standard tool
0.000, 0. 000, 0. 000, 0. 0000, 0.0000, 0. 0000
0.000, 0. 000, 0. 000
0.000.
0.000, 0. 000, 0. 000
0.000, 0. 1
```



Since the CRC value has not been added to the file saved in the system in which functional safety is invalid, the file cannot be loaded in the system in which functional safety is valid


- 11 Safety Function
- 11.7 Setting Example of the Safety Functions

11.7 Setting Example of the Safety Functions

11.7.1 Single Safety Laser Scanner to Pause Robot Motion

This is an example how to setup a single safety laser scanner to pause Robot motion with a Functional Safety Speed Limit when a person or object is inside the safety laser scanner area.

 Connect the safety output of your safety laser scanner (it is written as OSSD etc.) to a safety relay then take the two pairs of outputs from the safety relay and properly connect them to the YRC Controller as per your YRC Controller's instruction manual. For this example, we will be using the Functional Safety Board Input #1 (FSBIN01). Note that wiring diagrams for this input may refer to the two pairs as XIN1_1-/ XIN1_1+ and XIN1_2-/XIN1_2+.



2. Prior to performing any changes to safety related settings, you must be in Safety level. Press the {MENU} button on the top left and open the {Security} screen. Select SAFETY level, enter in the current safety passcode, and press SAVE.



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions

| Security Access | | | | |
|---|-------------------|------------|--|--|
| 🖏 Please sele | ect access level: | (i) | | |
| OPERATION | EDIT | MANAGEMENT | | |
| SAFETY | (current) | | | |
| Please enter passcode: | | | | |
| Safety allows all Management actions in addition to | | | | |
| chaging Safety rel | | | | |
| | | | | |
| | | L SAVE | | |

 Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Logic Circuit}.



4. Press the {Setting} on the top right, select {Signal Setting} to open the screen.



 Select the {Physical Discrete Safety I/O} tab and then select the {FSBIN} tab. Give the FSBIN01 a relevant name such as "Laser Scanner Detect Area1"




HW1485509

- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- 6. Once completing the changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 7. Press the {MENU} button on the top left, select Safety Settings, and select Safety Functions.



 Select {+ NEW SETTING} at the top of the Safety Function Settings screen, select {SPEED LIMIT}, then press {CREATE NEW SETTING} to open a blank Robot speed limit



9. Give the speed limit a relevant name such as "Area Scanner Robot Pause", change the speed limit to a speed of 0 mm/sec, then change the Enable Condition to Signal in the drop-down menu.



 After changing the Enable condition to Signal, the "Advanced Settings" screen will pop-up and you can select a signal for your "Setting Activation Signal" drop-down.

| Advanced Settings | \checkmark |
|---------------------------|--------------|
| Setting Activation Signal | (i) |
| Signal | us Condition |
| signal 1 🗸 | — ~ () |
| + NEW SIGNAL | |

- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- 11. Select the "Physical Discrete Safety I/O" tab and choose the input where your area scanner is wired. For this example, the area scanner is wired into FSBIN01. After selecting your area scanner input press the Select button. Please note that depending on your area scanner's polarity you may have to change the activation condition from the default "ON" to "OFF" next to the signal name.


| Setting Activation Signa | l : Signal 1 | | | × |
|---------------------------------|--------------|----------------|--------------------------------|---|
| Select Safety Signal | | | | |
| Physical Discrete Safety I/O | | dbus ty I/O | Virtual Discrete Safety I/O | |
| Signal | Status | Name | | |
| FSBIN01 | 0 | Laser S | canner Detect Area1 | |
| FSBIN02 | 0 | Resume | Switch for PFL | |

- 12. Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 13. You are now complete and the Robot will stop all motion while someone is within the area scanner range.

11.7.2 Single Safety Laser Scanner to Activate Collaborative Operation

This is an example for collaborative operation of HC10 Robot where a single safety laser scanner is used to activate the collaborative operation mode when a person or object is inside the safety laser scanner area.

 Connect the safety output of your safety laser scanner (it is written as OSSD etc.) to a safety relay then take the two pairs of outputs from the safety relay and properly connect them to the YRC Controller as per the controller's instruction manual. For this example, we will be using the Functional Safety Board Input #1 (FSBIN01). Please note that wiring diagrams for this input may refer to the two pairs as XIN1_1-/ XIN1_1+ and XIN1_2-/XIN1_2+.



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- 2. Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Logic Circuit}.



3. Press the {Setting} on the top right, select {Signal Setting} to open the screen.

| ŝ | Signal Setting |
|------------|----------------|
| ŵ | Status Setting |
| <i>(i)</i> | Help Info. |

 Select the {Physical Discrete Safety I/O} tab and then select the {FSBIN} tab. Give the FSBIN01 a relevant name such as "Laser Scanner Detect Area1"

| Signal Setting | | | | | | × |
|---------------------------------|--------|----------------------|--------------------------------|---------|----------------------|---|
| Physical Discrete Safety I/O | | ieldbus ifety I/O | Virtual Discrete Safety I/O | Э | Other I/O Signals | |
| FSBIN | F | SBOUT | | | | |
| Signal | Status | Name | | Enabled | | |
| FSBIN01 | 0 | Laser Scanne | r Detect Area1 | Enabled | | |
| FSBIN02 | 0 | Resume Swite | ch for PFL | Enabled | | |

- 5. Close the signal setting screen by pressing {X} button on the top right.
- 6. Set the input relay to FSBIN01, and the output relay to MSOUT54. Please note that this setting is same as factory default. Depending on your laser scanner's polarity you may have to change the input relay to "Normally Open", or "Normally Closed".

| Coll | laborative Operation | |
|------|----------------------|----------------|
| 1 | FSBIN01 | Collaborequest |

- Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 8. You are now complete and the Robot will be collaborative operation mode while someone is in the area scanner range.

11 Safety Function

11.7 Setting Example of the Safety Functions



When switching from collaborative operation disabled (muting) to collaborative operation enabled, there is a delay of about 1000 ms until the signal input actually switches.



Whenever you use a presence detection sensor, ensure the safety distance based on ISO13855.

11.7.3 Reduce the Robot Speed by Robot Position

This is an example to reduce the Robot speed by the speed limit function when the Robot move into an area which is defined by Robot range limit function.

1. Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Logic Circuit}.



2. Press the {Setting} on the top right, select {Signal Setting} to open the screen.



 Select the {Physical Discrete Safety I/O} tab and then select the {FSBIN} tab. Change {Output From} to "Safety Setting(F-SAFE #1)".


| Signal Setting | | | > |
|---------------------------------|--------|--|------------------------------|
| Physical Discrete Safety I/O | | ieldbus Virtual Discreated by I/O Safety I/O | otto |
| FSOUT | Ν | ISOUT | |
| Signal | Status | Name | Output From |
| FSOUT01 | 0 | Safety Settings Logical Output 1 | Safety Settings(F-SAFE #1) ~ |
| FSOUT02 | | Safety Settings Logical Output 2 | |



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 5. Press the {MENU} button on the top left, select Safety Settings, and select Safety Functions.



 Select {+ NEW SETTING} at the top of the Safety Function Settings screen, select {ROBOT RANGE LIMIT}, then press {CREATE NEW SETTING} to open a blank Robot range limit.



7. Give the Robot range limit a relevant name such as "Low Speed Area". Change the {Action} to "Status" to mute the alarm even if the Robot move into this area. Change the shape type to cubic for this example. Change the {Monitor Type} to "Keep Robot Outside". If you select "Keep Robot Outside", outside of the specified will be defined as safe area, you can detect the Robot entering the area. Change X,Y,Z of the Point 1 and Point 2 to specify the area for reducing the Robot speed.




- 8. After changing the Action to Status, the "Advanced Settings" screen will pop-up and you can select a signal for your "Output Signal" drop-down.
- 9. Select the "Virtual Discrete Safety I/O" tab and choose the FSOUT01.
- 10. Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 11. Confirm the output signal is changed by Robot position as specified area. After confirmed, press {CONFIRM}.
- 12. Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Logic Circuit}.
- 13. Select {+ NEW LOGIC} at the top of the Safety Logic Circuit screen.



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- 14. Give the setting a relevant name such as "Activate Low Speed by Area". Change the input relay to FSOUT01 as Normally Closed, and the output relay to MSOUT01. By this setting, MSOUT01 will be ON when the Robot enter the specified area.



- 15. Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Functions}.
- 17. Select {+ NEW SETTING} at the top of the Safety Function Settings screen, select {SPEED LIMIT} , then press {CREATE NEW SETTING} to open a blank Robot speed limit.



18. Give the speed limit a relevant name such as "Low Speed Area Speed Limit", change the speed limit to a speed of 50 mm/sec for example, then change the {Enable Condition} to "Signal" in the drop-down menu.



 After changing the Enable condition to Signal, the "Advanced Settings" screen will pop-up and you can select a signal for your "Setting Activation Signal" drop-down.

| Advanced Settings | \sim |
|---------------------------|-----------|
| Setting Activation Signal | (i) |
| Signal Status | Condition |
| signal 1 ——— V O | — ~ (!) |
| + NEW SIGNAL | |



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions
- 20. Select the "Virtual Discrete Safety I/O" tab. Choose the MSOUT01 which is connected from FSOUT01 in Safety Logic Circuit.


| Setting Activation Signa | l : Signal 1 | | | \times |
|---------------------------------|--------------|----------------|--------------------------------|----------|
| Select Safety Signal | | | | |
| Physical Discrete Safety I/O | | dbus ty I/O | Virtual Discrete Safety I/O | |
| Signal | Status | Name | | |
| MSOUT01 | 0 | Safety L | ogic Circuit Logical Output 1 | |
| MSOUT02 | 0 | Safety L | ogic Circuit Logical Output 2 | |

- 21. Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 22. You are now complete and the Robot will reduce the speed while someone is within specified area.

11.7.4 Reduce the Robot Speed by Robot Position only when Collaborative Operation Mode

For collaborative operation Robot such as HC10, this is an example to use safety laser scanner to activate the collaborative operation mode when a person or object is inside the safety laser scanner area. Also, reduce the Robot speed by the speed limit function when the Robot moves into the area which is defined by Robot range limit function. However, Robot will move at high speed even if the Robot is in the specified area when the Robot is not in collaborative operation mode.

- 1. Refer to chapter 11.7.2 "Single Safety Laser Scanner to Activate Collaborative Operation", and chapter 11.7.3 "Reduce the Robot Speed by Robot Position", to complete the setup.
- 2. In Safety Logic Circuit, add MSOUT54 as AND in the line that output to MSOUT01.



- Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.
- 4. You are now complete and the Robot will reduce the speed while someone is within specified area only when collaborative operation mode.

11 Safety Function


11.7 Setting Example of the Safety Functions

11.7.5 Add the Resume Switch for Collaborative Operation

For collaborative operation Robot such as HC10, this is an example to add the customer's resume switch in addition to the resume switch on the Robot.

 Connect your push button switch to the YRC Controller. For this example, we will be using the Functional Safety Board Input #2 (FSBIN02). Please note that wiring diagrams for this input may refer to the two pairs as XIN1_1-/XIN1_1+ and XIN1_2-/XIN1_2+.

YRC1000



2. Press the {MENU} button on the top left, select {Safety Settings}, and select {Safety Logic Circuit}.



3. Press the {Setting} on the top right, select {Signal Setting} to open the screen.



 Select the {Physical Discrete Safety I/O} tab and then select the {FSBIN} tab. Give the FSBIN02 a relevant name such as "Resume Switch"

| Signal Setting | | | | \times |
|---------------------------------|------------------------|--------------------------------|----------------------|----------|
| Physical Discrete Safety I/O | Fieldbus Safety I/O | Virtual Discrete Safety I/O | Other I/O Signals | |
| FSBIN | FSBOUT | | | |
| Signal | Status Name | Er | nabled | |
| FSBIN01 | O Laser Scar | nner Detect Area1 E | nabled | |
| FSBIN02 | O Resume Sv | vitch for PFL E | nabled | |

- 5. Close the signal setting screen by pressing {X} button on the top right.
- 6. Select {+ NEW LOGIC} at the top of the Safety Logic Circuit screen.



- 11 Safety Function
- 11.7 Setting Example of the Safety Functions

11-116

- 7. Give the setting a relevant name such as "Resume PFL". Change the input relay to FSBIN02 as Normally Closed, and the output relay to MSOUT57.
- 8. Once you have completed your changes press {READBACK} to readback the data. Check the readback data is correct, then press {WRITE} to save your setting.



9. You are now complete and Robot will resume operation by pressing the push button switch.

HW1485509


- 12 Software Pendant
- 12.1 Introduction

12 Software Pendant

12.1 Introduction

12.1.1 Overview of Software Pendant

The Software Pendant application software provides supplementary functions for using the Smart Pendant with the YRC Controller. The Software Pendant application should be installed on a Windows PC.



12.1.2 Functions

The Software Pendant should be used for the following functions:

- Variable Allocation
- Functional Safety Unit Settings
 - Tool Angle Monitor
 - Tool Change Monitor
- Safety Logic Circuit
- Safety board and PFL board flash reset
- Position Limit Setup
- Installation Angle
- I/O Allocation
- CMOSBK Load (Restore function for CMOS backup)
- All maintenance mode functions

12-1

When the Software Pendant is connected to the YRC Controller, jogging of the manipulator is not allowed from the Software Pendant. Playing a JOB is also not allowed from the Software Pendant. However, if a JOB is playing, Smart Pendant can be switched to REMOTE mode and Software Pendant can be connected. The job will continue to play.



The {SERVO ON/OFF} on the Software Pendant is disabled if the Smart Pendant option installed.

- 12 Software Pendant
- 12.1 Introduction

While the Software Pendant is connected to the YRC Controller, communication between the YRC Controller and Smart Pendant is disconnected. Therefore, the manipulator cannot be jogged by the Smart Pendant.

- 12 Software Pendant
- 12.2 Software Pendant Installation

12.2 Software Pendant Installation

12.2.1 Export Software Pendant Application from Smart Pendant

The Software Pendant application installer is stored internally on the Smart Pendant. This installer file can be exported to a USB drive using the following steps:

- 1. Navigate to {Menu} \rightarrow {System Settings} \rightarrow {General}.
- 2. Switch operation mode to MANUAL (TEACH).
- 3. Insert a USB drive with sufficient free space in to the Smart Pendant.
- 4. Toward the bottom of the {General Settings} screen is an {Export} under {Bundled Resources}. Select the check box for "Software Pendant" Application and then press the {Export} as shown below:

| Bundled Re | sources | | |
|------------|---------------|-------------------------------|----------|
| EXPORT | Documentation | Software Pendant* Application | Licenses |
| | | | |


- 5. The Software Pendant installer will be copied to the USB drive.
- Remove the USB drive and then use it to install Software Pendant on a PC as described in the next section.

12.2.2 Install Software Pendant for YRC Controller on PC

- 1. Open folder "Pendant\SoftwarePendantInstall\YRC controller".
- Select and double-click "setup.exe".

| 🔯 setup.exe | 8/28/2017 3:05 PM | Application | 362 KB |
|----------------|-------------------|-------------------|----------|
| 🔂 SwpSetup.msi | 8/28/2017 3:05 PM | Windows Installer | 4,836 KB |

3. Follow the instructions: press "Next".





- 12 Software Pendant
- 12.2 Software Pendant Installation
- 4. Review the License Agreement: choose "I Agree", and then select "Next".

| icense Agreemen | it | |
|--|---|----------------------------------|
| lease take a moment to read t gree", then "Next". Otherwise | he license agreement now. If you a click "Cancel". | accept the terms below, click "I |
| Software License Ag | reement | |
| Name of the softwar Licensed number : 1 | e : Software Pendant | |
| using this software Yaskawa Electric Co | ad this Agreement befor rporation (hereinafter se the non-transferable | referred to as |
| I Do Not Agree | I Agree | |
| | | |

5. Choose the installation folder and select the user, then click "Next".

| Select Installation Folder The installer will install SoftwarePendant_YRC to the following fold To install in this folder, click "Next". To install to a different folder, o Eolder: | |
|--|-----------------------------------|
| To install in this folder, click "Next". To install to a different folder, (| |
| | enter it below or click "Browse". |
| <u>F</u> older: | |
| - | |
| C:\Program Files (x86)\YASKAWA\SoftwarePendant_YRC\ | Browse |
| | Disk Cost |
| Install SoftwarePendant_YRC for yourself, or for anyone who us | es this computer: |
| Everyone | |

- 12 Software Pendant
- 12.2 Software Pendant Installation

6. Confirm the installation.


| SoftwarePendant_YRC | |
|---|---------------|
| Confirm Installation | |
| The installer is ready to install SoftwarePendant_YRC on yo | our computer. |
| Click "Next" to start the installation. | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Cancel | <pre></pre> |

- 12 Software Pendant
- 12.2 Software Pendant Installation

12.2.3 Network Configuration

To connect the Software Pendant to the YRC1000, communication must be allowed through the PC's Windows Firewall.

1. Click "Windows Firewall" from "Control Panel".



2. Click "Allow a program or feature through Windows Firewall", and check "YPP" programs to get through the firewall.

| 00-1 | Windows Firewall Allowed Programs Allow programs to communicate thr To add, change, or remove allowed programs ar What are the risks of allowing a program to com | nd ports, cl | indows Firewall lick Change settings. | | earch Control Par | | ٩ |
|------|---|--------------|--|---|--|---|---|
| | For your security, some settings are managed | jed by you | r system administrato | or. | | | |
| | Allowed programs and features: | Domain | Home/Work (Pri | Public | Group Policy | | |
| | Windows Media Player Network Sharin Windows Media Player Network Sharin Windows Peer to Peer Collaboration Fo Windows Remote Management Wireless Portable Devices XLRCSReport(CP) YppMain YppMain YppMain YppMain YppMain | | | U U U U U U U U U U Etail | No No No No No No S Removi | | |
| | | | | Allow | another program | n | |

- 12 Software Pendant
- 12.3 Connection Process

12.3 Connection Process

12.3.1 Wiring

Use an LAN cable to directly connect the network port on the PC to the LAN2 ethernet port (CN106) on the YRC1000 or the LAN ethernet port on the YRC1000micro.

Fig. 12-1: YRC1000 (LAN2 (CN106) Connector)





Fig. 12-2: YRC1000micro (LAN Connector)

12-7



HW1485509

- 12 Software Pendant
- 12.3 Connection Process

12.3.2 IP Setting

Change the IPv4 address of the computer to match the IP address of the YRC Controller. The IP address of LAN2 of YRC Controller can be viewed on the Smart Pendant as described in *chapter 8.6 "Network"*.

1. Enter "Network and Sharing Center" through the Control Panel

| Control Panel Home | View your basic network in | formation and set | t up connections | |
|-------------------------------------|--|-------------------|---|--------------------|
| Manage wireless networks | N | | | See full ma |
| Change adapter settings | AXDEMO1 | Multiple networks | Internet | |
| Change advanced sharing settings | (This computer) View your active networks | maniple networks | | onnect or disconne |
| | Work network | | Access type: Internet Connections: M Wireless Net (MotoTexas) | work Connection |
| | Unidentified network | | Access type: No network a | access |

2. Click the "Change adapter settings" on the left and double click the "Local Area Connection".



3. In the Local Area Connection Properties window, choose "Internet Protocol Version 4 (TCP/IPv4)", and click "Properties".

12 Software Pendant

12.3 Connection Process

| 45 | | | |
|----------------------|--|-----------------|-----|
| Connect using: | | | |
| Realtek PCIe | GBE Family Controller | | |
| | | Configu | e |
| This connection uses | the following items: | | |
| | ne Network Services | | * |
| QoS Packet | | | |
| | er Sharing for Microsoft Netw | orks | |
| | col Version 6 (TCP/IPv6) | | = |
| | col Version 4 (TCP/IPv4) opology Discovery Mapper I | | 1 |
| | pology Discovery Mapper (| | - |
| < | III | | • |
| Install | Uninstall | Propertie | s |
| Description | | | - |
| Allows your comp | uter to access resources on a | a Novell networ | ·k. |
| | | | |
| | | | |

4. Choose "Use the following IP address", and change subnet mask to the value shown on Smart Pendant as described in *chapter 8.6* "*Network*". For IP address of the PC, use the same first three values as the YRC Controller. For the fourth value, select a number different from the YRC Controller. For example, if the YRC Controller LAN2 network setting is:

 YRC IP Address:
 192.168.255.1

 YRC Subnet mask:
 255.255.255.0

The PC network settings should be as follows:

| PC IP Address: | 192.168.255.[2 to 254] |
|-----------------|------------------------|
| PC Subnet mask: | 255.255.255.0 |

12-9

The last number of the IP address of the computer must be different from the last number of the IP address of the YRC1000 LAN2 and YRC1000micro LAN.




12 Software Pendant

12.3 Connection Process


| General | | | | |
|----------------------------|--|--|--|--|
| | ed automatically if your network wise, you need to ask your network ate IP settings. | | | |
| Obtain an IP address aut | omatically | | | |
| OUSE the following IP addr | ess: | | | |
| IP address: | 192.168.255.2 | | | |
| Subnet mask: | 255.255.255.0 | | | |
| Default gateway: | x 🔉 x | | | |
| Obtain DNS server addre | ss automatically | | | |
| OUSE the following DNS se | rver addresses | | | |
| Preferred DNS server: | | | | |
| Alternate DNS server: | | | | |
| 🔲 Validate settings upon e | xit Advanced | | | |

12.3.3 Startup of Software Pendant

1. Startup the "Software Pendant". The "Safety Precautions" window appears, and the user should click "agree" all precautions listed are agreed upon.



- 12 Software Pendant
- 12.3 Connection Process
- 2. Click "Connect" in the programming pendant startup window.



3. Select the IP Address of the YRC Controller the user wants to connect to.

| Select Contro | oller | | |
|--------------------|-----------------------------|---------------------|--------------------|
| RC Name YRC1000 | IP Address 192.168.255.1 | RC Status normal | Connect connect |
| | Search Co | nnect | Back |


- 12 Software Pendant
- 12.3 Connection Process
- 4. Change the YRC Controller mode to REMOTE using the physical key switch on the Smart Pendant.
- 5. Click "Connect".

| RC Name | IP Address | RC Status | Connect |
|---------|---------------|-----------|---------|
| YRC1000 | 192.168.255.1 | normal | connect |
| | | | |
| | | | |
| | | | |
| | | | |
| • | Ш | | • • |

6. Verify Software Pendant is connected on Smart Pendant. Once Software Pendant successfully connects to the YRC Controller, the following message will appear on the Smart Pendant.

| "Software Pendant" Connected |
|--|
| "Software Pendant" is connected to the controller and Smart Pendant use has been disabled. Once the "Software Pendant" disconnects, you can reconnect Smart Pendant and resume use. |
| RECONNECT |

- 12 Software Pendant
- 12.3 Connection Process
- 7. The programming pendant screen and the keyboard display will appear on PC once the Software Pendant has successfully connected to the YRC Controller.




- 12 Software Pendant
- 12.4 Software Pendant Function

12.4 Software Pendant Function


12.4.1 Screen & Keyboard Function Locations

There are 6 areas on the Software Pendant screen:

- Pendant Switch Area
- Main Menu Area
- Menu Area
- Status Display
- General-Purpose Display Area
- Human Interface Display Area



As Software Pendant is typically used for setting values in functions, the following keys will be used frequently: Cursor Key, Select Key, Enter Key, and Numeric Keys.




- 12 Software Pendant
- 12.4 Software Pendant Function

12.4.2 Pendant Switch

The Operation Mode of Software Pendant must be selected carefully when using Software Pendant.

- MANUAL (TEACH) Mode: Editing is allowed on the Software Pendant.
- AUTOMATIC (PLAY) Mode: Editing is not allowed.
- REMOTE Mode: If Teach Mode is selected on the Smart Pendant, settings can be edited only on the Smart Pendant (and not Software Pendant).



12.4.3 Settings on Software Pendant

The following examples of Software Pendant use are provided:


- Security Mode Change
- Safety Logic Circuit Editing
- File Transfer
- Safety Board Flash Reset

- 12 Software Pendant
- 12.4 Software Pendant Function

12.4.3.1 Security Mode Change

The security mode setting of Software Pendant independent of Smart Pendant. To change the security mode through the Software Pendant:

1. Select "SYSTEM INFO" from the Main Menu, and then select "SECURITY".



2. Select the target security mode.

| SWP Ver.1.4 | .0.0 : YRC1000 | D | | | - - × |
|-------------|----------------|-----------|---------|----------------------------------|---|
| | PLAY Q | TEACH | START | HOLD | SERVO OFF |
| DATA | EDIT | DISPLAY | UTILITY | 12 🖻 🖬 | ● ● |
| | | CURITY | | N MODE MODE NT MODE ODE | |
| Main Menu | Simple Menu | I/F Panel | <u></u> | a robot riti | hout setting tool info. ma |

- 12 Software Pendant
- 12.4 Software Pendant Function
- 3. Enter the respective password for the target security mode.

| SECURITY | | |
|----------|---------------|---|
| MODE | | _ |
| Curr | ent Password= | |
| | | |

The default password for the security mode are:

- Management Mode: 99999999999999999 (16 digits of 9)
- 12.4.3.2 Safety Logic Circuit Editing

The Safety Logic Circuit is used to design FSU/PFL function details and to edit the logical relationship of various safety signals.

1. Change the security mode to **Safety Mode**, and the operation mode of the Software Pendant to **Teach Mode**.



2. Select "SAFETY FUNC." On the main menu, and then select "SAFETY LOGIC CIRCUIT".

| SWP Ver.1.4.0.0 : Y | TEACH | | SERVO OFF R.STOP |
|---------------------|-------------------------|---------------------------|--|
| | DIT DISPLAY U | | |
| EX. MEMORY | AXIS RANGE | SLC EXT. SIGNAL | |
| | AXIS SPEED MONITOR | SLC SIGNAL DISPLAY | |
| SETUP | ROBOT RANGE | SLC SIGNAL DISPLAY SET | |
| SAFETY FUNC. | SPEED LIMIT | SPIN COMMENT | |
| PM | TOOL ANGLE MONITOR | ROBOT RANGE DISPLAY | |
| DISPLAY SETUP | E TIMER DELAY SET | TOTAL CRC DISPLAY | |
| | SAFETY LOGIC CIRCUIT | | AGE |
| Main Menu Simple | Menu I/F Panel | robot without set! | ting tool info, may resul [.] |



- 12 Software Pendant
- 12.4 Software Pendant Function
- 3. Select the block, and a drop-down menu will appear to allow the user to choose a signal, condition, or logic relationship. The circle next to each signal will indicate the signal status: filled circle is ON, and empty circle is OFF.

| SAFETY | LOGIC CIRCUIT STS : DONE INPUT1 LOGIC INPU | JT2 | OUTPUT | |
|--------|---|-----|--------|-----|
| 001 | | 0 | | 0 |
| 002 | EXESP | 0 | | 0 |
| 003 | #1 GSIN[x] | 0 | | 000 |
| 004 | #1 GSOUT[x] | 0 | | 0 |
| 005 | MS-OUT[xx] | 0 | | 0 |
| 006 | #1 ONEN[x] | 0 | | 0 |
| 007 | PBESP | 0 | | 0 |
| 008 | PLAY PPDSW | 0 | | 000 |
| 009 | PPESP | 0 | | |
| 010 | AUXILIARY RELAY(R[xxx]) | 0 | | 0 |
| 011 | REMOTE | 0 | | 000 |
| 012 | S-EXDSW S-EXESP | 0 | | 0 |
| 013 | S-FST | 0 | | 0 |
| COMMEN | #1 S-ONEN[x] | | | |

The standard expression of the safety logic circuit is:

(Condition) (Input Signal 1) And/Or (Condition) (Input Signal 2) => Output Signal

| SAFET | Y LOGIC CIRCUI | T STS : | DONE | |
|-------|----------------|---------|----------|----------------|
| | INPUT1 | LOGIC | INPUT2 | OUTPUT |
| 001 | #1 FSBIN02 | | | O MS-0UT54 |
| 002 | #1 FSBIN01 | AND NOT | FS-OUT01 | 0 R001 0 |
| 003 | #1 FSBIN01 | AND NOT | FS-OUT02 | • R002 • |
| 004 | R001 | OR | R002 | • #1 PFLIN02 • |
| 005 | #1 PFLIN02 | | | O MS-OUTO2 |
| 006 | #1 FSBIN01 | AND NOT | FS-OUT03 | O #1 PFLIN03 O |
| 007 | #1 PFLIN03 | | | O MS-OUTO3 O |
| 008 | | | | |

See the safety logic circuit above as an example.

In line 001, "#1 FSBIN02" is the safety input signal 2 from the safety board, and "MS-OUT54" is the PFL function trigger. So, line 001 means that when safety input signal 002 is ON, the PFL function will take effect.

For more detail on the Safety Logic Editor please refer to the INSTRUCTIONS of the YRC Controller

HW1485509

- 12 Software Pendant
- 12.4 Software Pendant Function

12.4.3.3 Safety Board Flash Reset

If the following alarms occur when control power is turned ON, perform the following operations to reset the data of the safety circuit board and PFL circuit board.

- Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [10]"
- Alarm 0300: "VERIFY ERROR (SYSTEM CONFIG-DATA) [13]"

The Safety Board Flash Reset can only be performed in maintenance mode.

 In the Start Window (close the software and restart, if software pendant is already connected to the YRC Controller), select the "Special Mode", and click "Maintenance Mode".

| Special Mo | ode | |
|------------|------------------|--|
| Select st | artup mode. | |
| | Maintenance Mode | |
| | | |
| | | |
| | | |

2. Select {SYSTEM} under the Main Menu, and then select {SECURITY} to change the security mode to the safety mode.





- 12 Software Pendant
- 12.4 Software Pendant Function
- 3. Select "FILE", and then "INITIALIZE" under the Main Menu
 - The "INITIALIZE" window appears.

| SYSTEM | INITIALIZE JOB |
|--|--|
| FILE | INITIALIZE |
| EX. MEMORY SD MotoPlus APL. SD DISPLAY SETUP CA | SYSTEM DATA Functional Safety Related Files Safety Board FLASH Erase Safety Board FLASH Reset |
| | |

4. Move the cursor to the "Safety Board FLASH Reset" in the Initialize window, and press {SELECT}.

- The dialog box "Reset? displays

| INITIALIZE |
|----------------------------------|
| □JOB |
| 🗆 FILE/GENERAL DATA |
| PARAMETER |
| □I/O DATA |
| SYSTEM DATA |
| □Functional Safety Related Files |
| 🗆 Safety Board FLASH Erase |
| Safety Board FLASH Reset |
| □3DGraphics Robot Model Reset |

- 5. Click "YES" to confirm.
 - The data of the safety circuit board is re-set.
 - A few seconds later, a beep sounds, and the data setting is complete.

| SYSTEM | INITIALIZE | | |
|---------------|--|------|--|
| FILE | □JOB □FILE/GENERAL DATA □PARAMETER | | |
| EX. MEMORY | | set? | |
| MotoPlus APL. | YES | NO | |
| DISPLAY SETUP | | d | |

- 12 Software Pendant
- 12.5 Changing IP address of the YRC Controller
- 6. Perform a PFL FLASH Reset (Safety FLASH Reset) if the YRC Controller supports the collaborative operation function.
- Turn control power OFF and back ON when the Safety Board FLASH Reset is complete.

12.5 Changing IP address of the YRC Controller

The default IP address of the YRC Controller must be changed to connect the YRC Controller to the customer facility network. The YRC Controller network setting procedure is described in *chapter 8.6.4 "Setting IP Address"*.

12.6 Connect the Software Pendant to the YRC Controller using Wireless (Wi-Fi)

To connect the Software Pendant (PC) to the YRC Controller wirelessly:

1. Set up the Wi-Fi connection to the PC

12-21

- Connect the YRC Controller (CN106) to the Wi-Fi router using a LAN cable
- Match the IP address of the YRC Controller and the computer to the Wi-Fi router setting

- 13 External Memory Device
- 13.1 Memory Device

13.1 Memory Device

Memory devices allow operators to save and load data such as jobs and parameters. The following memory devices can be used with the YRC Controller.

- USB memory stick to Smart Pendant (The Smart Pendant is equipped with a connector.)
- USB memory stick to the YRC Controller (The CPU board (JANCD-ACP01) is equipped with a connector.)

13.1.1 USB Memory Stick

The Smart Pendant and CPU board (JANCD-ACP01) is equipped with a USB connector. Use the FAT16 or FAT32 formatted USB memory stick for the CPU board, and use the FAT32 formatted USB memory stick only for the Smart Pendant.

13.1.2 Recommended USB Memory Stick

Refer to chapter 9.1.2 "Device" of the INSTRUCTIONS of the YRC Controller for recommended external memory devices to use with YRC Controller.

13.1.3 Notes on Handling USB Memory Stick

- Do not drop or bend or apply any electric shock or strong force to the USB memory stick.
- Keep away from water, oil, organic solvent, dust, dirt, and other potential contaminants.
- Do not use or keep the USB memory stick in places where strong static electricity or electronic noise may occur.
- Do not insert or remove the USB memory stick or turn the power OFF when reading or writing from the USB memory stick.
- To protect data, back it up regularly on other media. This will minimize damage to or loss of data due to operation errors and accidents.

*USB memory sticks have a limited life span, which varies by make and condition. Normal use of a USB memory stick as an external memory device for the YRC Controller does not adversely affect USB memory stick performance. For details, refer to the instruction manuals for each medium.

- 13 External Memory Device
- 13.1 Memory Device

13.1.4 Rules for USB Connectors and USB Memory Sticks

This section contains rules and instructions on how to safely use USB connectors on the CPU board (JANCD-ACP01) and memory sticks.

1. Do not insert/remove the USB memory stick on the YRC Controller when control power is ON A device recognition process is executed when an USB memory

A device recognition process is executed when an USB memory stick is inserted. Do not insert or remove an USB memory stick when the control power supply is turned ON. Failure to observe this rule may affect the manipulator's cycle time.

- Do not disconnect control power or insert/remove an USB memory stick during file access
 Failure to observe this rule may result in FAT file system corruption and data loss.
- 3. **Operating temperature range of USB memory stick** Use a USB memory stick that is guaranteed to function correctly in the same temperature range as the YRC Controller.
- 4. **USB memory stick's falling off by the YRC Controller vibration** To prevent the USB memory stick from falling off due to vibrations from the YRC Controller, consider countermeasures, such as fixing the USB stick with jigs to keep it in place.

5. USB connector on the front surface of the CPU board (JANCD-ACP01)

The USB connector on the front surface of the CPU board (JANCD-ACP01) accepts only the USB memory stick. Do not connect a USB hub or other USB devices.

6. Capacity of USB memory stick

13-2

The capacity of the memory stick is up to four Gigabyte in size for the CPU board, and no limit for the Smart Pendant.

HW1485509

- 13 External Memory Device
- 13.1 Memory Device

13.1.5 Inserting a USB Memory Stick in Smart Pendant

When inserting a USB memory stick always position the Smart Pendant with its back side facing up. Hold the USB memory stick with its top surface facing up, and insert it into the USB memory stick connector on the bottom of the Smart Pendant.

Forcible insertion may cause damage to the USB memory stick or USB connector.

After inserting the USB memory stick, be sure to close the cover of the connector before starting operations.

13.1.6 Inserting a USB Memory Stick in the CPU Board (JANCD-ACP01)


Make sure to insert the USB memory stick in the right direction: Keep the USB memory stick with its top surface to the right, and insert it slowly into the connector on the CPU board.

Forcible insertion may cause damage to the USB memory stick or USB connector.




Failure to observe this may result in electric shock.

Fig. 13-1: USB Memory Stick Inserting Place (YRC1000 CPU Board JANCD-ACP01)



- 13 External Memory Device
- 13.2 Handling Data

Fig. 13-2: USB Memory Stick Inserting Place (YRC1000micro CPU Board JANCD-ACP31)






If the USB memory stick is not recognized or an error message is displayed even if it is inserted, remove the USB memory stick and insert it again slowly.

13.2 Handling Data

For the YRC Controller, data that can be saved externally, and are classified into six categories.

- **(1) JOB**
- **② GENERAL DATA**
- **③ PARAMETER**
- ④ I/O DATA
- **5 SYSTEM DATA**
- **(6) SYSTEM BACKUP (CMOS.BIN)**

Data saved on the external memory device can be loaded again into the YRC Controller.





13.2 Handling Data

| Data Classi | fication | File name | Save | | | | Load | | | |
|-----------------------------|--|--------------|------|-----|-----|-----|------|-----|-----|-----|
| | | (Saved Data) | OPN | EDT | MNG | SFT | OPN | EDT | MNG | SFT |
| 6. SYSTEM BACKUP (CMOS.BIN) | | CMOS.BIN | 0 | 0 0 | 0 | 0 | × | × | × | × |
| 1. JOB | Single job | JOBNAME.JBI | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| 2. GENE | R Tool data ¹⁾ | TOOL.CND | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| AL DATA | User coordinate data | UFRAME.CND | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Zone setting data | CUBEINTF.CND | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Variable data | VAR.DAT | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Timer variable data | TMVAR.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | Shock detection level data | SHOCKLVL.CND | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Interrupt job ¹⁾ | INTJOB.DAT | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Tool interfere data ¹⁾ | TOOLINTF.DAT | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Axis range limit data ¹⁾ | AXRNGLMT.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Axis speed monitor data ¹⁾ | AXSPDMON.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Robot range limit data ¹⁾ | RBRNGLMT.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Speed limit data ¹⁾ | SPDLMT.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Tool angle monitor data ¹⁾ | TLANGMON.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Tool change monitor data ¹⁾ | TLCHGMON.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | External force monitor data ¹⁾ | PFLFLMT.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | Approval warning buzzer data ¹⁾ | APPRBUZR.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 |
| | User menu data | USERMENU.DAT | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |
| | Job registration data | JET.DAT | 0 | 0 | 0 | 0 | × | 0 | 0 | 0 |

Table 13-1: Data List (Sheet 1 of 4)

1) Safety level is required to load for FSU supporting manipulators

2) Software Pendant is required to load

O: Can be done, ×: Cannot be done

OPN: Operation level, EDT: Edit level,

13-5

MNG: Management level, SFT: Safety level

13.2 Handling Data

Table 13-1: Data List (Sheet 2 of 4)

| Dat | ta Classific | ation | File name | Save | | | | Load | | | |
|-----|-------------------|--|--------------|------|-----|-----|-----|------|-----|-----|-----|
| | | | (Saved Data) | OPN | EDT | MNG | SFT | OPN | EDT | MNG | SFT |
| | 3. PARAM ETERS | Batch Parameter ¹⁾ | ALL.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | PARAM ETER | Robot matching parameter ¹⁾ | RC.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | System definition parameter ¹⁾ | SD.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Coordinate home position parameter ¹⁾ | RO.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | System matching parameter | SC.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | CIO parameter | CIO.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Function definition parameter ¹⁾ | FD.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Application parameter | AP.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Transmission (general parameter) | RS.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Sensor parameter | SE.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Servo parameter ¹⁾ | SV.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Servomotor parameter ¹⁾ | SVM.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Operation control parameter | AMC.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Servo power block parameter | SVP.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Motion function parameter ¹⁾ | MF.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | SERVOPACK parameter | SVS.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Converter parameter | SVC.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Robot control expand parameter ¹⁾ | RE.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Safety function parameter ¹⁾ | FMS.PRM | 0 | 0 | 0 | 0 | × | × | 0 | 0 |

1) Safety Level is required to load for FSU supporting manipulators

2) Software Pendant is required to load

O: Can be done, ×: Cannot be done

OPN: Operation level, EDT: Edit level,

13-6

MNG: Management level, SFT: Safety level

13.2 Handling Data

Table 13-1: Data List (Sheet 3 of 4)

| Da | ata Classifica | ation | File name | Save | | | | Load | | | | |
|----|-------------------|---|--------------|------|-----|-----|-----|------|-----|-----|-----|--|
| | | | (Saved Data) | OPN | EDT | MNG | SFT | OPN | EDT | MNG | SFT | |
| 6 | 4. I/O DATA | I/O name data | IONAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | External I/O name data | EXIONAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Register name data | IOMNAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Concurrent I/O program | CIOPRG.LST | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Pseudo input signals | PSEUDOIN.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Safety logic circuit data ²⁾ | YSFLOGIC.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 | |
| | | User group input | USRGRPIN.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | User group output | USRGRPOT.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | 5. SYSTEM DATA | Home position calibrating data ¹⁾ | ABSO.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Work home position data | OPEORG.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Second home position | HOME2.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Torque sensor orgin position data ¹⁾ | PFLORGP.DAT | 0 | 0 | 0 | 0 | × | × | × | 0 | |
| | | Variable name | VARNAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Flag variable name | FLNAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | Timer variable name | TMNAME.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | SETTM setup file | SETTM.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | External IO allocation data | EIOALLOC.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | IP network set data | IPNETCFG.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | High-Speed Ethernet error log | HISPDLOG.DAT | 0 | 0 | 0 | 0 | × | × | × | × | |
| | | Ethernet/IP config data | EHTERIP.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | I/F panel data | IFPANEL.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 | |
| | | I/O message history data | IOMSGHST.DAT | 0 | 0 | 0 | 0 | × | × | × | × | |
| | | Alarm history data | ALMHIST.DAT | 0 | 0 | 0 | 0 | × | × | × | × | |
| | | Log data | LOGDATA.DAT | 0 | 0 | 0 | 0 | × | × | × | × | |
| | | Robot stop factor file | RBSTPFCT.DAT | 0 | 0 | 0 | 0 | × | × | × | х | |

1) Safety level is required to load for FSU supporting manipulators

2) Software Pendant is required to load

O: Can be done, ×: Cannot be done

OPN: Operation level, EDT: Edit level,

13-7

MNG: Management level, SFT: Safety level

13.2 Handling Data

Table 13-1: Data List (Sheet 4 of 4)

| D | ata Classifica | ation | File name | Save | | | | Load | | | |
|---|------------------|-----------------------------------|--------------|------|-----|-----|-----|------|-----|-----|---|
| | | (Saved Data) | OPN | EDT | MNG | SFT | OPN | EDT | MNG | SFT | |
| 6 | 5.SYSTEM DATA | System information | SYSTEM.SYS | 0 | 0 | 0 | 0 | × | × | × | × |
| | | YRC Controller information | PANELBOX.LOG | 0 | 0 | 0 | 0 | × | × | × | × |
| | | Wear detection base position data | SGWEARBP.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Max / Min torque data | TRQDAT.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | PM (reducer file) | PMTRQDB.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | PM (reducer condition) | PMCOND.CND | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Inspection record file | PMLOG.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | PM (Hardware file) | PMHARD.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | PM time management data | PMTMMNG.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | User word | UWORD.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Job monitor data | JOBMONI.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | Step diagnosis data | STEPDIAG.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | Robot monitor data | ROBOMONI.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | SV monitor signal | SVMON.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Arc monitor data | ARCMON.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | Encoder | ENCHEAT.DAT | 0 | 0 | 0 | 0 | × | × | × | × |
| | | Function key allocation data | KEYALLOC.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |
| | | Macro definitions | MACRO.DAT | 0 | 0 | 0 | 0 | × | × | 0 | 0 |

1) Safety level is required to load for FSU supporting manipulators

2) Software Pendant is required to load

O: Can be done, \times : Cannot be done

OPN: Operation level, EDT: Edit level,

13-8

MNG: Management level, SFT: Safety level

13.3 Macro Installation

If macros are enabled, MACRO.DAT is available in the system data file list.

Copy the macro .JBI and MACRO.DAT files to the YRC Controller from the USB.

Once files are copied the macros are available in the command list.

- 14 Startup Error
- 14.1 Startup Errors and Notifications

14 Startup Error

14.1 Startup Errors and Notifications

14.1.1 Startup Error Overview

If an error occurs during startup, startup will stop, a red X will appear next to the startup step where the error occurred, and the STARTUP ERROR window will appear with information about the error. The {Export Logs...} button can be used to save internal logs to a USB storage device to aid troubleshooting by a local YASKAWA Representative.

Have the following information available when contacting a local YASKAWA Representative:


- System
- Primary Application
- YRC Controller and Smart Pendant Software Version:
- Smart Pendant Software Version is located on top left corner of startup screen
- Robot Serial Number (Located on Manipulator data plate)
- Robot Sales Order Number (Located on YRC Controller data plate)
- Warranty Identification Number
- Step that startup failed on
- Active YRC Controller Alarms, if any
- Smart Pendant startup Error Numbers, if any
- Extracted pendant.log file from startup screen



The Smart Pendant startup errors are different from YRC Controller alarms.

- 14 Startup Error
- 14.1 Startup Errors and Notifications

Fig. 14-1: Startup Error Layout



① Smart Pendant Software Version

② Failed Step

A red X appears next to the startup step where the startup error occurred.

③ Startup Error Window

Contains the Startup Error Number in square brackets, a description of the error, possible causes and remedies.

④ Restart App Button

This button restarts the Smart Pendant application.

The Restart App Button will not restart the YRC Controller.

5 Export Resources Button

This button saves Smart Pendant documentation to a USB storage device.

6 Export Logs Button

This button saves internal logs to a USB storage device.

 \bigcirc Scrollbar

If the Startup Error details are too long, a scrollbar will appear along the right edge of the Startup Error Window to allow the user to read all content.



- 14 Startup Error
- 14.1 Startup Errors and Notifications

14.1.2 Startup Errors

| | Table | 14-1: | Startup | Errors |
|--|-------|-------|---------|--------|
|--|-------|-------|---------|--------|

| Startup Error Number | Startup Error Message | Cause | Remedy |
|-------------------------|---|--|--|
| 10 | Pendant network configuration failed | Pendant network configuration failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 20 | Communication between pendant and YRC Controller failed. | Network cable may not be connected. IP settings may not be set correctly on Smart Pendant. | The Smart Pendant requires a fixed network address to communicate with the YRC Controller. Follow these steps to set the IP address: |
| | | | a)Reboot the YRC Controller and pendant |
| | | | b) When '' appears on the screen, press a membrane key |
| | | | c) Select Network and then Ethernet 0 |
| | | | d) Ensure DHCP is not checked |
| | | | e) Set the entries: |
| | | | • IP address: 10.0.0.4 |
| | | | • Mask: 255.255.255.0 |
| | | | • Gateway: 10.0.0.2 |
| | | | f) Press OK to save |
| | | | g) Use Back and Exit to resume startup |
| 30 | YRC Controller Unresponsive. | "Smart Pendant Option" may be disabled. YRC Controller may be in Maintenance mode due to a YRC Controller alarm. | Make sure the YRC Controller "Smart Pendant Option" is enabled. Use the "Software Pendant" to troubleshoot or contact a YASKAWA Representative. |
| 35 | Software pendant is connected. | Software pendant is connected. | Disconnect "Software Pendant" and reboot the YRC Controller. |
| 40 | Some of the YRC Controller parameters are not compatible with Smart Pendant. | "Smart Pendant Option" is disabled. | Only a YASKAWA Representative can enable Smart Pendant Option. Contact a YASKAWA Representative and provide pendant.log file. |
| 50 | YRC Controller version incompatible with the Smart Pendant version. | YRC Controller version incompatible with Smart Pendant version. | Contact a YASKAWA Representative and provide pendant.log file. Refer to message in message box, consider upgrading YRC Controller system software to minimum required version. |
| 52 | Pendant software incompatible with configured YRC Controller languages. | Pendant software incompatible with configured YRC Controller languages. | Contact a YASKAWA Representative and provide pendant.log file. Only English and Japanese are supported. |
| 55 | Reading files from the YRC Controller for jobs, zones, or user frames has failed. | Reading files from YRC Controller for jobs, zones, or user frames has failed. | Contact a YASKAWA Representative and provide pendant.log file and failed step. |
| 57 | Reading files from pendant failed. | Reading files from pendant failed. | Contact a YASKAWA Representative and provide pendant.log file. |

14 Startup Error

14.1 Startup Errors and Notifications

| Startup Error Number | Startup Error Message | Cause | Remedy |
|-------------------------|---|--|---|
| 58 | Manipulator model not supported by Smart Pendant. | Manipulator model not supported by Smart Pendant. | Contact a YASKAWA Representative and provide pendant.log file. |
| 60 | Some of YRC Controller parameters are not correct. | "FTP Server Option" is not set. | Only a YASKAWA Representative can set the FTP Server option. Contact a YASKAWA Representative and provide pendant.log file. |
| 80 | YRC Controller setting is not correct. | FTP CMOS backup is disabled. | Only a YASKAWA Representative can enable the FTP CMOS Backup. Contact a YASKAWA Representative and provide pendant.log file. |
| 90 | Some of the YRC Controller parameters are not compatible with Smart Pendant. | YASKAWA Mode YRC Controller Parameters are not compatible with Smart Pendant. | Setup parameters need to be set correctly and can only be set by a YASKAWA Representative. |
| 95 | Some of the YRC Controller parameters are not compatible with Smart Pendant. | Normal Mode YRC Controller Parameters are not compatible with Smart Pendant. | Use the "Software Pendant" to set the parameters listed on the startup screen to the recommended values or contact a YASKAWA Representative and provide pendant.log file. |
| 96 | Pseudo input signal #87015 (CMD REMOTE SEL) is not compatible with Smart Pendant. | Pseudo input signal #87015 (Command Remote Selection) is not compatible with Smart Pendant. | Use the "Software Pendant" to set the value to ON or contact a YASKAWA Representative and provide pendant.log file. |
| 110 | Initialization of versions failed. | Initialization of versions failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 111 | Initialization of parameters failed. | Initialization of parameters failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 112 | Initialization of robots failed. | Initialization of robots failed. May have failed to initialize second home position, work home position, torque position 1, or torque position 2. | Contact a YASKAWA Representative and provide pendant.log file. |
| 113 | Initialization of zones failed. | Initialization of zones failed. A zone might have been configured as a station or external axis zone. | Contact a YASKAWA Representative and provide pendant.log file. |
| 114 | Initialization of tools failed. | Initialization of tools failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 115 | Initialization of user frames failed. | Initialization of user frames failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 116 | Initialization of tool settings failed. | Initialization of tool settings failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 117 | Initialization of safety settings failed. | Initialization of safety settings failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 118 | Initialization of variables failed. | Initialization of variables failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 119 | Initialization of jobs failed. | Initialization of jobs failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 120 | Initialization of default job (master job) failed. | Initialization of default job (master job) failed. | Contact a YASKAWA Representative and provide pendant.log file. |

- 14 Startup Error14.1 Startup Errors and Notifications

| Startup Error Number | Startup Error Message | Cause | Remedy |
|-------------------------|---|---|--|
| 121 | Final initialization failed. | Final initialization failed. | Contact a YASKAWA Representative and provide pendant.log file. |
| 125 | YRC Controller is in Maintenance Mode. | YRC Controller is in Maintenance Mode. | If this was not intentionally set, use a "Software Pendant" to troubleshoot or contact a YASKAWA Representative. |

- 15 Alarm
- 15.1 Alarm History

15 Alarm

15.1 Alarm History

If an alarm occurs during operation, the manipulator stops immediately and the ALARM pop-up window appears on the pendant. All previous alarms can be viewed on the Alarm History screen.

Go to {Alarm} under {MENU}.

| ltem | Description |
|----------|---|
| Code | Alarm code is shown in 4-digits |
| Sub code | Alarm sub-code is shown |
| Name | Name of the alarm occurred |
| Date | Date of alarm is shown in YYYY-MM-DD format |
| Time | Time of alarm is shown in hh:mm:ss with AM/PM format |
| Туре | Type of alarm is shown. For example, Major, Minor, User System I/O, Off-line etc. |

Table 15-1: Alarm History Information

Table 15-2: Alarm Detail

| ltem | Description |
|-----------------|--|
| Description | Description of the alarm is shown here. |
| Possible causes | Possible causes of the alarm are shown here. |
| Solution | Solutions are shown here. Follow the steps to solve the issue that is causing the alarm. |

HW1485509

15 Alarm

15.1 Alarm History

Fig. 15-1: Alarm History Screen

| ÷ | Alarm His | story | | | | | |
|---|--|---|--|---|---|--|--|
| Code | Subcode | Name | Date | Time | Туре | | |
| 6002 | 0 | NEAR SINGULARITY (PFL) | 2018-10-24 | 02:24:57 AM | Minor | | |
| 8006 | 13 | CANNOT START HAND GUIDING | (ALL 2018-10-22 | 08:24:57 PM | User | | |
| 1926 | 0 | TRQ SENSOR RECEIVING ERROR | 2018-10-21 | 02:24:57 PM | Major | | |
| 4744 | 0 | M-SAF PP ENABLE SW SIG. ERR | OR 2018-10-20 | 08:24:57 AM | Minor | | |
| 9002 | 0 | ARC FAILURE:1 | 2018-10-19 | 02:24:57 AM | User System IO | | |
| 9001 | 0 | MISSING ARC START CONFIRM: | 1 2018- <mark>10-17</mark> | 08:24:57 PM | User System IO | | |
| 300 | 13 | VERIFY ERROR(SYSTEM CONFIG | G-DAT 2018-10-16 | 02:24:57 PM | Off-line | | |
| 4127 | 0 | U-AXIS TIMING BELT BLOWN | 2018-10-16 | 01:54:57 PM | Minor | | |
| 4000 | 0 | MEMORY ERROR(TOOL FILE) | 2018-10-16 | 01:24:57 PM | Minor | | |
| 4000 | | , | 2010 10 10 | | | | |
| | n: NEAR SI | NGULARITY (PFL) | | | vino v | | |
| Alarm DESC If the I | RIPTION: | NGULARITY (PFL) paches a singularity with PFL enab rove will cause this alarm to appea | led, operation will b | be restricted to si | | | |
| Alarm DESC If the I A mul help fi 1: Res | CRIPTION: robot appro tiple axis m ile (top-righ set alarm. Ir | NGULARITY (PFL) paches a singularity with PFL enab rove will cause this alarm to appea | led, operation will b ar. More information | be restricted to sin n on singularities | (i) ngle axis moves. is provided in the | | |
| Alarm DESC If the I A mult help fi 1: Res speed | CRIPTION: robot appro tiple axis m ile (top-righ set alarm. Ir I. | INGULARITY (PFL) baches a singularity with PFL enab love will cause this alarm to appea t). | led, operation will b ar. More information | be restricted to sin n on singularities | (i) ngle axis moves. is provided in the e moves and low | | |
| Alarm DESC If the I A multiperiod help fi 1: Rese speed 2: If th 3: If th | CRIPTION: robot appro tiple axis m ile (top-righ set alarm. Ir l. nis alarm co nis alarm co | NGULARITY (PFL) baches a singularity with PFL enab love will cause this alarm to appea t). a {Teach Mode}, try jogging out | led, operation will the formation of the singularity of the singularity FL $\boxed{2}$ to move the the second s | be restricted to sin n on singularities r using single axis e robot without al | (i) ngle axis moves. is provided in the e moves and low arms. | | |
| Alarm DESC If the I A multip fi 1: Res speed 2: If th 3: If th incom | CRIPTION: robot appro tiple axis m ile (top-righ set alarm. Ir l. nis alarm co nis alarm co | NGULARITY (PFL) baches a singularity with PFL enable ove will cause this alarm to appear t). a {Teach Mode}, try jogging out the track Mode, try jogging out curs in Teach Mode, disable Place provinces in Play Mode, taught points r on segments. | led, operation will the formation of the singularity of the singularity FL $\boxed{2}$ to move the the second s | be restricted to sin n on singularities r using single axis e robot without al | (i) ngle axis moves. is provided in the e moves and low arms. | | |


15 Alarm


15.2 Alarms & Notifications

15.2 Alarms & Notifications

15.2.1 Alarm Overview

Alarms will be displayed when an instruction cannot be processed. One or multiple alarms can occur at once. If multiple alarms exist, all pop-ups will be shown in a scrollable list. An overview of the alarm layout is provided below.





① Hide Button

Allows the user to hide the alarm to continue performing restricted operations on the pendant

2 Alarm Title

Contains the alarm title, code, and subcode. The title bar is also color coded (yellow = minor alarm, red = major alarm). The following sections contain more detail on alarm types.

③ Alarm Details

Contains why the alarm happened and possible solutions.

④ Help Links

Links located in alarm details will direct the user to screen(s) with actions required to resolve the alarm.

5 Alarm History

Directs the user to the Alarm History screen (*fig. 15-1 "Alarm History Screen"*).

6 Multiple Alarms

If multiple alarms are active, the subsequent alarms will appear collapsed in list form. Press the alarm title to expand the alarm to view its contents.

⑦ Reset Button

15-3

Allows the user to reset a Minor alarm. Major alarms cannot be reset.

- 15 Alarm
- 15.2 Alarms & Notifications

8 Help Icon

Some alarms require background information to fully understand the problem. This information will be contained in a help file visible in the Alarm Title (top-right).

9 Scrollbar

If the alarm details are long, a scrollbar will appear to allow the user to read all content.

There are three types of alarms on Smart Pendant: Major, Minor, and User alarms. The following sections will explain the differences for each.

15.2.2 Major Alarm

When a major alarm occurs, the servo power supply will be turned OFF.

| Alarm Code | Alarm Type | Alarm Reset Method |
|-----------------|---|--|
| 0000 to 0999 | Off line alarm: Initial diagnosis/ Hardware diagnosis alarm | It is not possible to reset by pressing the "RESET" button under the ALARM pop- up window or using the specific input signal (Alarm reset). Turn OFF the main power supply and correct the cause of the alarm. Then turn the main power supply ON again. |
| 1000 to 3999 | Major alarm | It is not possible to reset by pressing the "RESET" button under the ALARM pop- up window or using the specific input signal (Alarm reset). Turn OFF the main power supply and correct the cause of the alarm. Then turn the main power supply ON again. |

Table 15-3: Major Alarm Code Classification

Major alarms are shown in a red pop-up window.



Only one action can be performed on Major alarms:

15-4

 HIDE: User can hide the alarm to continue performing restricted operations on the pendant. Reset operation cannot be performed for a Major alarm and the YRC Controller restart is required.

Major alarms cannot be cleared until the problem has been solved. For further information on alarms, read "YRC1000 ALARM CODES (RE-CER-A600)" or "YRC1000micro ALARM CODES (RE-CER-A601)". Use the alarm number (which is displayed under the alarm name) to find the matching alarm information in the document.

HW1485509

- 15 Alarm
- 15.2 Alarms & Notifications

15.2.3 Minor Alarm

When a minor alarm occurs, the operator must reset the alarm after correcting the cause. This process does not require a restart of the YRC Controller.

| Alarm Code | Alarm Type | Alarm Reset Method | |
|-----------------|-------------|---|--|
| 4000 to 7999 | Minor alarm | After correcting the cause, it is possible to reset by pressing the {RESET} in the ALARM pop-up window or the specific input signal (Alarm reset). | |
| 8000 to 8999 | User alarm | After correcting the cause for which user has specified, it is possible to reset by pressing the {RESET} in the Alarm pop- up window or the specific input signal (Alarm reset). | |
| 9000 to 9999 | I/O alarm | After correcting the cause for which the specific input signal for the system or user alarm request turns ON, it is possible to reset by pressing the {RESET} in the ALARM pop-up window or the specific input signal (Alarm reset). | |

Minor alarms are shown in yellow pop-up window.



Read the notification and follow the solution provided on the screen.

Two actions can be performed on Minor Alarm:

15-5

- CLOSE: User can close the alarm to continue performing restricted operations on the pendant.
 - Example 1: If a Zone alarm happens, user can close it and navigate to Zone screen and change the offending zone to status, so that the alarm can be reset.
 - Example 2: When the manipulator jogged over the Soft Limits, user can close the alarm. Open the Limit Release window and disable limits. After this, jogging of the manipulator can be performed to get it within its allowed position limits. Once this is done, Alarm can be Reset.
- RESET: This will reset the alarm. An alarm that is Reset may reappear if the conditions causing the alarm have not been remedied.

For further information about alarms, read YRC1000 ALARM CODES (RE-CER-A600)" or "YRC1000micro ALARM CODES (RE-CER-A601)". Use the alarm number (which is displayed under the alarm name) to find the matching alarm information.

- 15 Alarm
- 15.2 Alarms & Notifications

15.2.4 User Alarm


An User Alarm is an alarm created by a user. The alarm is displayed shown in a yellow pop-up window. One method to set the User Alarm is using the SetUserAlarm command in the job. For further information on User Alarms, refer to YRC1000/YRC1000micro SUPPLEMENTAL INSTRUCTIONS FOR Smart Pendant (INSTRUCTIONS FOR INFORM LANGUAGE) (HW1485511).



15.2.5 Notifications

The Smart Pendant will often display banner messages at the top of the screen to display notify the user of certain pendant states and guide the user through incompatible/error conditions. There are two primary types of notifications on Smart Pendant:

Fig. 15-3: Notification Types



1 High Priority

Notifies user that a physical action is required to proceed with the intended action. An image is typically provided to visually detail the required action.

② Standard

Notifies the user regarding incompatible states (e.g. insufficient access level), user interactions (e.g. item copied/deleted), or screen-specific interactions.

- 16 Help / Support
- 16.1 Take Screenshot

16 Help / Support

16.1 Take Screenshot

Users can take a screenshot of the current screen's contents and save the screenshot as a graphics file in PNG format. Screenshots cannot be taken without the USB memory stick.

- 1. Insert USB memory stick
- 2. Select {Help / Support} under {MENU}
- 3. Select {Screenshot}
- Message appears {Screenshot Saved Picture of screen saved to file...}
- 5. Date and time that the screenshot is taken will be included in the file name



A screenshot can also be taken by pressing the membrane jogging speed [FAST] and [SLOW] keys together.

16.2 YASKAWA Representative

YASKAWA provides support for its products on a global basis. The technical phone and email list can be accessed from the Smart Pendant. Please contact your local YASKAWA Representative. A YASKAWA Representatives can be found on the back cover of this manual.

The YASKAWA Representatives may request log files from the Smart Pendant. Logs can be exported to a USB memory stick by pressing the button {EXPORT LOG FILES...} at the bottom left of the screen.

- 17 Maintenance
- 17.1 Cleaning the Smart Pendant

17 Maintenance

17.1 Cleaning the Smart Pendant

To clean the Smart Pendant safely and effectively, follow these tips:

- Use only soft, lint-free cloth for cleaning. Do not use scrubbing sponges, towels, paper towels or similar items that may cause damage.
- Switch off the power source.
- Use a small amount of water or a diluted neutral detergent as a washing liquid, if needed.
- Do not spray washing liquid etc. directly onto any surface of the Smart Pendant.
- Do not get moisture (including washing liquid etc.) or foreign substances into any openings.
- Pay attention not to adhere chemicals, cutting oil (including coolant), rust preventive oil, organic solvent etc. to the Smart Pendant.

17.2 Cleaning the Smart Pendant Cable

To clean the Smart Pendant cable, follow these tips.

- Do not submerge any parts of the cable.

17-1

- Wipe with a dry cloth.

- 17 Maintenance
- 17.2 Cleaning the Smart Pendant Cable

HW1485509

17-2

Appendix A

A.1 Open Source License

Appendix A

A.1 Open Source License

The Smart Pendant application utilizes some software licensed under Open Source licenses.

License information is available from the Smart Pendant.

- 1. Open {General} under {System Settings} from the {MENU}.
- 2. Check the {Licenses} checkbox under {Bundled Resources}.
- 3. Tap the {EXPORT...}.

| Bundled Resources | | | | |
|-------------------|---------------|--------------------------|----------|--|
| EXPORT | Documentation | Soft Pendant Application | Licenses | |

To obtain source code for the relevant Open Source licensed software components, please contact a YASKAWA Representative. For support contact details for your region, refer to the back cover for the local YASKAWA Representative.

YRC1000/YRC1000micro INSTRUCTIONS FOR Smart Pendant

(JZRCR-APP30-1)

For inquiries or after-sales service on this product, contact your local YASKAWA representative as shown below.

YASKAWA ELECTRIC CORPORATION

2-1 Kurosakishiroishi, Yahatanishi-ku, Kitakyushu, 806-0004, Japan Phone: +81-93-645-7703 Fax: +81-93-645-7802 http://www.yaskawa.co.jp

YASKAWA AMERICA, INC. (MOTOMAN ROBOTICS DIVISION)

100 Automation Way, Miamisburg, OH 45342, U.S.A. Phone: +1-937-847-6200 Fax: +1-937-847-6277 http://www.motoman.com

YASKAWA EUROPE GmbH (ROBOTICS DIVISION)

Yaskawastrasse 1, 85391, Allershausen, Germany Phone: +49-8166-90-100 Fax: +49-8166-90-103 http://www.yaskawa.eu.com

YASKAWA NORDIC AB

Verkstadsgatan 2, Box 504, SE-385 25 Torsas, Sweden Phone: +46-480-417-800 Fax: +46-486-414-10 http://www.yaskawa.se

YASKAWA ELECTRIC (CHINA) CO., LTD.

22F, One Corporate Avenue, No.222 Hubin Road, Huangpu District, Shanghai 200021, China Phone: +86-21-5385-2200 Fax: +86-21-5385-3299 http://www.yaskawa.com.cn

YASKAWA SHOUGANG ROBOT CO., LTD.

No.7 Yongchang North Road, Beijing E&T Development Area, Beijing 100076, China Phone: +86-10-6788-2858 Fax: +86-10-6788-2878 http://www.ysr-motoman.cn

YASKAWA ELECTRIC KOREA CORPORATION

35F, Three IFC, 10 Gukjegeumyung-ro, Yeongdeungpo-gu, Seoul, 07326, Korea Phone: +82-2-784-7844 Fax: +82-2-784-8495 http://www.yaskawa.co.kr

YASKAWA ELECTRIC TAIWAN CORPORATION

12F, No.207, Sec. 3, Beishin Rd., Shindian District, New Taipei City 23143, Taiwan Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 http://www.yaskawa.com.tw

YASKAWA ASIA PACIFIC PTE. LTD.

30A Kallang Place, #06-01, 339213, Singapore Phone: +65-6282-3003 Fax: +65-6289-3003 http://www.yaskawa.com.sg

YASKAWA ELECTRIC (THAILAND) CO., LTD.

59, 1st-5th Floor, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok 10310, Thailand Phone: +66-2-017-0099 Fax: +66-2-017-0199

http://www.yaskawa.co.th

PT. YASKAWA ELECTRIC INDONESIA

Secure Building-Gedung B Lantai Dasar & Lantai 1 Jl. Raya Protokol Halim Perdanakusuma, Jakarta 13610, Indonesia Phone: +62-21-2982-6470 Fax: +62-21-2982-6471 http://www.yaskawa.co.id

YASKAWA INDIA PRIVATE LIMITED (ROBOTICS DIVISION)

#426, Udyog Vihar Phase-IV, Gurgaon, Haryana 122016, India Phone: +91-124-475-8500 Fax: +91-124-475-8542 http://www.yaskawaindia.in

YASKAWA

©2018 YASKAWA ELECTRIC CORPORATION Published by YASKAWA



YASKAWA ELECTRIC CORPORATION

February 2020 20-02

MANUAL NO. HW1485509
